

# **MEASUREMENT AND ALIGNMENT SYSTEMS**

# **PRODUCT CATALOGUE**



INTRODUCTION / DOCUMENTATION	3
MEASUREMENT PROGRAMS	7
SHAFT ALIGNMENT SYSTEMS	12
WIND SYSTEMS	18
SHEAVE/PULLEY ALIGNMENT SYSTEMS	22
DIGITAL PRECISION LEVEL	24
VIBRATION MEASUREMENT TOOL	25
GEOMETRIC MEASUREMENT SYSTEMS	26
DISPLAY UNITS	42
LASER TRANSMITTERS	43
DETECTORS AND OTHER RECEIVERS	45
MEASURING UNITS	47
BRACKETS AND MISCELLANEOUS PRODUCTS	49
SPARE PARTS	70
APPAREL / GIVE AWAYS	74
TECHNICAL SPECIFICATIONS AND DRAWINGS	75
SPECIFICATIONS FOR BATTERIES AND CHARGERS	77
PART NUMBER PAGE LIST	108

SYSTEM	PAGE
XT770 Shaft + GEO	12
XT770 Shaft + Bore	13
XT770 Shaft	14
XT660 Shaft	15
XT550 Shaft Ex/ATEX	16
XT440 Shaft	17
XT660 Shaft SG1 Wind	18
XT660 Shaft WMB Wind	19
Shaft alignment Vestas	20
Shaft alignment Gamesa	21
XT190 BTA	22
D92 BTA	23
XT290 Digital Level	24
XT280 VIB	25
XT980 Sawmill	26
E980 Sawmill	27
E970 Parallelism	28
E960-A Turbine alignme	nt 29
E960-B Turbine alignmen	nt 30
XT950 Bore alignment	31
E950-A Bore alignment	32
E950-B Bore alignment	33
E950-C Bore alignment	34
E950-D Bore alignment	35
E930 Extruder	36
E920 Geometric	37
E915 Flange Spin	38
E910 Flange	39



## **IMPORTANT INFORMATION**

Please read the information on page 76 about specific technical limitations and product compatibilities, as well as explanation of specifications in this catalogue.

We reserve the right to make modifications of the product design and technical specifications without prior notification.

## What the pictures show

System picture. Does only show the main parts of the system, not all items that are included. Always read the Part list for complete system specification.





Easy-Laser® XT770 Shaft+GEO
Part No: 12-1128 (System with XT20 Laser transmitter)
Part No: 12-1334 (System with XT22 Laser transmitter)

For installation and maintenance of all types of rotating machine The XT770 Shaft - GEO system has all the programs and functions need to keep your machines up and running. Configured for install ton and overhaul of rotating machinery, like e.g. gas compressors. Programs for alignment of horizontal, vertical/flange mounted machines, machine trains and cardan/offset mounted machines, anchine trains and cardan/offset mounted machines and to the control of the control o

XT70 measuring units
The XT70 units allow for multipoint, continuous sweep and uncoup sweep measurements. They also support the 360°LIVE move featu

Large 20x20 mm [0.79x 0.79"] 2 axis TruePSD detectors.

Dot-type laser technology for accuracy and versatility.

Bused design 1956/67 approach featuring wiseless technology.

|D| |E| |XT|: Indicates which product range the part is compatible with. If no letter is present, the part fits all three ranges.

Note: If there are other compatibility limitations these are mentioned for each product.



Rotating detector bra Part No: 12-1209 Description: Allows for 360° sv

Main product picture 1

Additional pictures 1

**NOTE!** <sup>1</sup> Be aware that these pictures may show items that are not included for the specific part number.

**DOCUMENTATION**Easy-Laser® Product overview

## Learn more about a specific measurement system or application

In our measurement system brochures you can find more extensive technical specifications and more information on the systems and products in this Product overview. Available for download in many different languages from: www.easylaser.com



Easy-Laser® XT770



Easy-Laser® XT660



Easy-Laser® XT550 Ex



Easy-Laser® XT440



Easy-Laser® XT980



Easy-Laser® XT20/XT22



Easy-Laser® XT290



Easy-Laser® XT280



Easy-Laser® XT190



Easy-Laser® E980



Easy-Laser® E970



Easy-Laser® E960



Easy-Laser® E950



Easy-Laser® E930



Easy-Laser® E920



Easy-Laser® E910/E915



Easy-Laser® E290



Easy-Laser® D92



## A reliable business partner

Easy-Laser® is one of the world's leading manufacturers and suppliers of laser measurement systems for all types of industry. We provide extreme accuracy and precision. But that's not what sets us apart. Today, when virtually anyone with a decent laser can do "straight", to get ahead, you need to be a bit more forward-thinking.

Because, in the long run, what really counts is neither the absolute straightness of an individual component nor the precise alignment of shafts. It's what these measures add up to: Increased productivity and the saving of resources. Those are the things we ultimately deliver. And from that perspective our most important task is to help you make the road leading there as free from bumps and bends as possible.

That means developing user-friendly measurement and alignment systems that are as easy to get your head around, as they are versatile and scalable. It also means shortening delivery times, extending warranties and optimizing training and support.

Moreover, you can always expect us, or any of our partners, to give you an honest opinion on which of our products are crucial to your operations and which you can do without. What really needs to be aligned and what not. So that what we offer you is a solution perfectly aligned with your needs — and your budget.

Regardless of whether you're a service technician, a purchaser or the CFO of a multinational industrial group, you'll find Easy-Laser® truly easy to deal with. Or as we like to put it – straightforward by all measures.

## **Worldwide distribution network**

Easy-Laser® has representatives in over 70 countries. You find your local Easy-Laser retailer at our web page www.easylaser.com > contact

## **Long warranty**

The systems come with a 3 year limited warranty. Learn more at easylaser.com/en-us/support/warranty. The quality system of the company is ISO9001 approved.







## Our service concept

Our service department usually takes care of servicing or calibration within seven working days. All this makes Easy-Laser® a safer working partner for your operation. As an extra service, we provide a 48 hour express service for shaft alignment systems when accidents occur and time is of the essence. Contact us for further information about terms and conditions.





Easy-Laser® is manufactured by Easy-Laser AB, Alfagatan 6, 431 49 Mölndal, Sweden. +46 31 708 63 00, info@easylaser.com, www.easylaser.com



# **SUSTAINABILITY**


# - A RESPONSIBILITY FOR ALL OF US

Easy-Laser works actively with sustainability issues and supports the UN Global Compact's core principles\* on the environment, anti-corruption, human rights and labour conditions. This permeates our entire business, every day.















## **Our working environment**

It is important for us to be an inclusive and open workplace, where people enjoy working and want to stay for a long time. The relationship between us as an employer and our employees should be characterised by openness, respect and empowerment.

We embrace diversity.

We offer flexibility in terms of working hours and choice of workplace.

We work systematically with work environment issues.

We prevent health problems through annual health checks and wellness activities.

We measure satisfaction through a weekly staff survey.

## **Our operations**

We strive to continually reduce the environmental impact of our own operations, large and small.

We recycle as much as possible, both from our production and our other activities.

We use carbon footprint compensated transports.

We use only fossil-free electricity.

## **Our products**

By using Easy-Laser products, our customers can run a more sustainable business; a properly set-up machine will not break down prematurely and will not use more energy than necessary. But what about the environmental impact of our own products?

We strive to use sustainable materials in our products and for them to have a long service life.

We offer repair, calibration and maintenance of our products as close to the customer as possible.

## **Our social responsibility**

We take responsibility in our local community but also globally through our cooperation with suppliers and distributors.


Both distributors and suppliers must meet the requirements set out in our Code of Conduct.

We will be good neighbours and seize opportunities to strengthen the communities in which we operate.

Short-term profitability shall not take precedence over long-term sustainability.



<sup>\*</sup> https://www.unglobalcompact.org/what-is-gc/mission/principles



XT980 XT950 XT770 XT660 XT550 XT440 XT290 XT290 XT280 XT190 XT122 XT120 XT120



























	XT290   -			_							
Please	note that what you can measure is in reality depending on the   XT280   -		_								
	rement equipment included in your system, not the XT Alignment App.   XT190   -	_									
	always includes all programs and functions, and is free to download.										
		<u>+</u>	$\perp$	<u>+</u>	<u> </u>						
	HORIZONTAL 9-12-3						•				
<u> </u>	Shaft alignment measurement mode.										
411 41-	MACHINE TRAIN (UNLIMITED)										
-11-11-1	Shaft alignment program.										
11311	MACHINE TRAIN (3 MACHINES/2 COUPLINGS)										
11211	Shaft alignment program.										
	SOFT FOOT										
<b>Q</b>	Shaft alignment program/feature.										
10 ag	EASYTURN™										
	Shaft alignment measurement mode.										
Joseph Company	MULTIPOINT HORIZONTAL SHAFT										
	Shaft alignment measurement mode.										
Thumber of the state of the sta	CONTINUOUS SWEEP HORIZONTAL SHAFT										
The state of the s	Shaft alignment measurement mode.										
Automorphic .	UNCOUPLED SWEEP										
Manager Market	Shaft alignment measurement mode.										
	WIDE LIVE Shaft alignment function.										
	Allows for live adjustment at larger angles, vertically and horizontally separately.										
	<b>360 LIVE</b> Shaft alignment function.										
	Allows for live adjustment at any position, in both directions simultaneously.										
•	ADJUSTMENT GUIDE Shaft alignment function. Simulate effects of shimming										
<b>←</b>	to decide optimum adjustment. For programs Horizontal and Machine train.										
	VERTICAL/FLANGE MOUNTED										
量	Shaft alignment program.										
	CARDAN/OFFSET MOUNTED										
	Shaft alignment program. (NOTE: Requires the Cardan bracket kit.)						O				
	VALUES (Digital Dial Indicator)										
V 0.00	Versatile program for almost any kind of alignment jobs.										
	LEVEL						_				
	Part of Values program. (NOTE: The level function requires XT290 Level.)				O	O	O	O	$\circ$	O	
	<b>TWIST</b> Check base twist and flatness with the M and S measuring units. (NOTE: Requires magnet bases.)					O	0				
									_		
	<b>BASIC FLATNESS</b> Measure two rows of points, 2 to 8 at each.  To be used with separate laser transmitter like the XT20, XT22 or D22.										
	<b>STRAIGHTNESS</b> For use with separate laser transmitter (e.g. XT20/XT22/D22/										
	D75).										
	BORE CENTER Straightness measurement of bore center lines, bearing journals							0			
	etc. For use with separate laser transmitter (e.g. XT22/D75) and bore brackets.										
	<b>EASYTREND™</b> Monitor and record machine movement over time.							0	0		
	(NOTE: The EasyTrend™ program requires DM-brackets.)										
00	BELT TRANSMISSION ALIGNMENT				0	0	0	0	0	0	0
	(NOTE: The Belt alignment program requires XT190 BTA.)										
<b></b>	VIBRATION MEASUREMENT				0	0	0	0	0	0	0
	(NOTE: The Vibration measurement program requires XT280 VIB.)										



## Power up with Easy-Laser PLUS™

Easy-Laser PLUS™ is our cloud solution where you:

- Collaborate with your maintenance team on job assignments.
- Collect all your team's measurement data in one place for quick overview and analysis.
- Copy your measurement data to a new device if your tablet is lost or damaged.
- Restore accidentally deleted files on your tablet.
- Receive information about the latest software updates.

This is just the beginning. Easy-Laser PLUS™ will offer more possibilities that complement your measuring instrument and make it even more powerful.

## For Easy-Laser XT systems

Easy-Laser PLUS™ works with the XT app on third party tablets/smartphones, and with our XT12 or XT11 rev2 tablets. In your account you pair your device/devices, making the data instantly available in the system everytime wifi is available (or 4G/5G if applicable). You access Easy-Laser PLUS™ from your web browser. All data are securely transferred with SSL/TLS encryption. The data is only accessible for those who have the right user level. At introduction the secure servers are located in the EU.


## Get it now!

To start a subscription, visit *easylaser.plus* and register your account in a few easy steps. It is only after the initial free trial period that you need to connect a credit card to pay the monthly fee to be able to continue using the services. You will then also be able to select from different subscription plans.

At introduction, the free trial period ends 31 August 2024. After that, the free trial period will be 90 days for new accounts. You can learn more about User agreements and Data protection on *easylaser.com/plus*.

## How does it work?

In Easy-Laser PLUS™ you organize your data in "workspaces", in a way that makes most sense for you and your team. For example a project, team, customer or machinery type. Once you have created your workspace, you can start inviting team members.



Above is an example of setups/workflows with Easy-Laser PLUS™.

- The organization (your company account) controls user access.
- You set different user roles (Administrator, Contributor or Viewer).
- Users can access one or more account.
- Each XT app can be paired with one account.

You pair your devices (or XT apps, that is), making them instantly available in Easy-Laser PLUS™.

NOTE: Requires XT App ver 9.0 or higher.

# The most user-friendly

# precision laser transmitters ever designed!



## Two models are available

Both transmitters can be used for flatness and straightness measurement. In addition, the XT22 can direct the laser beam at 90 degrees to the laser plane, which means you can solve virtually all types of geometric measurement jobs. The XT22 also has a higher technical specification for straightness thanks to fiber laser technology, and can take measurements at distances up to 40 m. The XT20 can take measurements at distances up to 20 m, but is also IP55 rated water and dust proof. Find out more in the technical specifications section at the end of this catalogue.

## New technology improves reliability

We have installed electronic precision vials in the XT transmitters. This gives the advantage of faster feedback when levelling and less risk of errors during calibration, because all users see the same angular value (compared with reading spirit levels). The laser transmitters are wirelessly connected to the XT Alignment app. In this way, the user can be guided



during calibration and the measurement procedure. In the event of temperature changes, vibrations or impacts that can affect the measurement result negatively, the app gives a warning during measurement. Data about the transmitter and measurement environment can be downloaded together with the report. This all provides greater reliability and traceability for your measurement jobs.


#### **Functions for easier use**

The rotating head is completely stable and retains its position during measurement. At the same time, it is easy to set the pointing direction of the laser beam to hit the detector, even at distances up to 40 m. We guarantee that this will be very much appreciated by users out in the field. All operation is also managed without the need to lock/unlock rotation, which facilitates use considerably.

Just like Easy-Laser's previous laser transmitter, the new XT20/XT22 can be mounted and positioned in many different ways: with integrated super magnets, on rods to be height adjustable, on stands and magnetic feet etc. We know that this is an important factor in practice to combat all those situations the user faces in reality.

## **Developed for use with the XT Alignment app**

The XT20 and XT22 are used with the Values, Basic Flatness and Straightness programs in the XT Alignment app. The laser transmitters can be purchased separately (as a kit with charger and bracket) but are also included in complete systems, such as the XT770 GEO. The XT70-M device can be used as a detector. They can also be used with E series detectors. Note, however, that the XT Alignment app is required to calibrate the electronic precision vials, and other things in the design of the XT transmitters differ from previous products. They can therefore not be exchanged straight off. Ask your local distributor before purchase.



The Straightness program.



The program for basic flatness.



Calibrating the electronic precision levels is super easy with the step-by-step guidance provided by the software.



The built-in sensors warns on the display on events which can affect the measurement reliability.



| E980 | E970 | E960 | E950 | E930 | E920 | | E915 | E910 | -Please note that the measurement programs which are greyed out requires measuring units for shaft alignment to be used. These units are no longer available for purchase as new ones, but existing units can of course be used with the programs. **HORIZONTAL 9-12-3 SOFT FOOT EASYTURN™** • **MULTIPOINT HORIZONTAL SHAFT VERTICAL/FLANGE MOUNTED CARDAN } MACHINE TRAIN** 41||\_\_11 **OFFSET AND ANGLE VALUES (Digital Dial Indicator)** V 0.00 H 0.00 **BELT TRANSMISSION ALIGNMENT** 00 **STRAIGHTNESS 1-point** STRAIGHTNESS 2-point (Centre of Circle) 0 **STRAIGHTNESS 4-point STRAIGHTNESS Multipoint** STRAIGHTNESS 3-point (Half circle) **ROUNDNESS/OVALITY MEASUREMENT SQUARENESS FLATNESS TWIST FLANGE FLATNESS FLANGE PARALLELISM PARALLELISM** 

**EASY-LASER®** 

# COMPLETE SYSTEMS





















## Easy-Laser® XT770 Shaft+GEO

Part No: 12-1128 (System with XT20 Laser transmitter) Part No: 12-1334 (System with XT22 Laser transmitter)

## For installation and maintenance of all types of rotating machinery

The XT770 Shaft + GEO system has all the programs and functions you need to keep your machines up and running. Configured for installation and overhaul of rotating machinery, like e.g. gas compressors. Programs for alignment of horizontal, vertical/flange mounted machines, machine trains and cardan/offset mounted machines\* plus EasyTrend for dynamic measurements\* are included.

Functions for soft foot check, thermal growth compensation and tolerance check. Flatness program for measurement of foundations and top frames. Twist measurement program for quick base flatness check. The very versatile Values program, together with the dot-type laser technology adds functionality for e.g. checking bearing clearance.

## XT70 measuring units

The XT70 units allow for multipoint, continuous sweep and uncoupled sweep measurements. They also support the 360°LIVE move feature.

- Large 20x20 mm [0.79x 0.79"] 2 axis TruePSD detectors.
- Dot-type laser technology for accuracy and versatility.
- Rugged design, IP66/67 approved, featuring wireless technology.
- Built-in OLED display shows battery status and the angular value of the unit for easy positioning.
- Integrated rechargeable battery, operating time 24 h.

## Multi-platform alignment system

The XT Alignment App runs on your iOS and Android unit<sup>1</sup>. You can also choose to add our ergonomic and rugged, IP66/67 approved shock proof Easy-Laser® XT12 display unit. Choose it with or without IR camera.

#### Geometric measurements

Includes laser transmitter XT20 or XT22, which provides geometrical measurements with the highest reliability and precision. For bore alignment, please see Part No. 12-1354 and 12-1355.

## The XT770 Shaft + GEO system contains:

(1) Laser transmitter XT20 12-1272

12-1273 (1) Laser transmitter XT22

12-1275 Multi-bracket for XT laser transmitter

12-1045 1 Measuring unit XT70-M

12-1046 Measuring unit XT70-S 1

Shaft bracket with chain and rods 12-0963

12-1008 Offset bracket for XT-series 2

12-0013 Magnet base

Magnet base with turnable head 12-1133 1

12-1161 1 Set of Rods 4x75 mm

12-0987 Set of rods (4x120 mm)

12-1060 Extension chain (2x900 mm) 1

03-0707 Measuring tape 5 m 03-0967 Hexagon wrench set 1

03-1256 1 Battery charger (100-240 V AC)

12-0989 DC split cable for charging 1

12-0751 1 DC to USB adapter, for charging

05-0913 Quick manual (Note: Refers to English manual)

03-0878 Cleaning cloth for optics

03-0914 USB memory stick with documentation 1

04-0307 Set of QR code stickers 1

Carrying case Large GEO, with wheels 12-1132 1


WxHxD: 580x460x295 mm [22.8x18.1x11.6"] Weight: 16.0 kg [35.3 lbs] (with XT20)

Weight: 16.2 kg [35.7 lbs] (with XT22)

(1) = Included depending on system Part No.

## Laser transmitter XT20 and XT22

Learn about the differences at page 9, and in the Technical specifications section at the end of this catalogue



12-1292 1 XT12 with IR Camera

12-1291 1 XT12

Both are delivered with shoulder strap for display unit, Part No 12-0997. Weight: 1490 g [52.5 oz]

## **Examples of accessories for XT770:**

12-1151 1 Cardan bracket kit

Dynamic measurement brackets (complete kit) 12-1130

12-1147 Magnetic bracket for XT-series 1

Thin shaft bracket for XT-series 12-1012 1

12-1010 1 Sliding bracket for XT-series

## XT Laser transmitter Upgrade Kits for older XT770 systems:


These kits are for upgrading of older versions of XT770. The interior of the included case fits XT12. Ask your local distributor for more information.

12-1320 1 Upgrade kit XT20

12-1321 1 Upgrade kit XT22

## Please also see the Programs and functions overview on page 7.

- <sup>1</sup> Please see our web site for a complete list of which tablets we recommend: easylaser.com > support > software download
- Requires accessories.



















## Bore kits for Easy-Laser® XT770

Part No: See below.

## Bore alignment for XT

Easy-Laser® XT770 is the perfect starting point for most of your alignment jobs on rotating machinery. The two kits on this page are adding the possibility to deal also with bore applications. Choose if you want the round bore detector XT9 or not. One reason can be that you need to measure smaller diameters (see below).

## Bore Bracket kit, with D75

With this kit added to your XT770 you use the XT70-M unit in your system as detector. Using the XT70-M you can measure diameters 130-500 mm [5.12-19.68"].

## Bore Upgrade kit, with XT9

With this kit added you can measure diameters 80-500 mm [3.15-19.68"]. You need "Kit with D75" as the starting point to get the laser transmitter, all necessary brackets and the carrying case. "Kit with XT9" will then be put in the same case (see pictures).

## Many mounting options

The detectors and brackets can be mounted in many different ways. Below are some examples of what is possible. For more options and measurable diameters, please see section Technical specifications.

Please also see the Programs and functions overview on page 7.





## 54)

Bore br	acl	cet kit, with D75 (Part No. 12-1354)				
12-0075	1	aser transmitter D75				
12-0455	1	Slide bracket Small				
12-0543	1	Slide bracket Medium				
12-0510	1	Slide bracket Large				
12-1368	1	Axial support for slide brackets				
12-1161	1	Set of rods 4x75 mm				
12-0987	1	Set of rods 4x120 mm				
12-0060	1	Set of rods 4x240 mm				
12-0661	1	Offset hub with counterlock for D75				
12-0707	1	Arm kit with magnets				
12-1277	1	Bracket with rotatable bore probe				
12-1357	1	Target for detector rough alignment				
12-1367	1	Carrying case				
		WxHxD: 460x350x175 mm [18.1x13.1x6.9"]				
		Weight: 10.2 kg [22.5 lbs]				

## Bore Upgrade kit, with XT9 (Part No. 12-1355)

12-1350	1	Detector XT9
12-0768	1	Slide bracket 25 mm width
12-0767	1	Rod adapter with built-in target C-C 40 mm
12-1351	1	Rod adapter with built-in target C-C 56 mm
12-0990	1	Adjustable magnet for offset hub arms
		Weight: 532 g [1.17 lbs]



















## Easy-Laser® XT770 Shaft

Part No: 12-1096

#### For all types of rotating machinery

The XT770 system has all the programs and functions you need to keep your machines up and running.

Programs for alignment of horizontal, vertical/flange mounted machines, machine trains and cardan/offset mounted machines\* plus EasyTrend for dynamic measurements\* are included.

Functions for soft foot check, thermal growth compensation and toler-

With the Twist measurement program you easily check the base flatness. The very versatile Values program, together with the dot-type laser technology adds functionality for e.g. checking bearing clearance.

## XT70 measuring units

The XT70 units allow for multipoint, continuous sweep and uncoupled sweep measurements. They also support the 360°LIVE move feature.

- Large 20x20 mm [0.79x 0.79"] 2 axis TruePSD detectors.
- Dot-type laser technology for accuracy and versatility.
- Rugged design, IP66/67 approved, featuring wireless technology.
- Built-in OLED display shows battery status and the angular value of the unit for easy positioning.
- Integrated rechargeable battery, operating time 24 h.

## Multi-platform alignment system

The XT Alignment App runs on your iOS and Android unit<sup>1</sup>. You can also choose to add our ergonomic and rugged, IP66/67 approved shock proof Easy-Laser® XT12 display unit. Choose it with or without IR camera.

## **Geometric measurements**

Add the possibility for geometric measurements, now or in the future. For general applications, please see Part No.12-1128 and 12-1334. For bore alignment, please see Part No. 12-1354 and 12-1355.

Please also see the Programs and functions overview on page 7.

## System XT770 contains:

12-1045	1	Measuring unit XT70-M
12-1046	1	Measuring unit XT70-S
10 0000	^	Chaff breakest with about

Shaft bracket with chain and rods 120 mm

12-1008 Offset bracket for XT-series

12-0013 2 Magnet bases 01-0873 Rods 120 mm

01-2117 4 Rods 75 mm

12-0128 1 Extension chain (2x900 mm)

03-1707 Measuring tape 5 m 1

03-0967 1 Hexagon wrench set 03-1256 Battery charger (100-240 V AC)

12-0989 DC split cable for charging 1 12-0751 DC to USB adapter, for charging

05-0913 Quick manual (Note: Refers to English manual) 1

03-0878 Cleaning cloth for optics

03-0914 USB memory stick with documentation 1

04-0307 1 Set of QR code stickers 12-0973

Carrying case Medium WxHxD: 460x350x175 mm [18.1x13.8x6.9"]

Weight: 9.1 kg [20.0 lbs]

## Add display unit XT12:

12-1292 1 XT12 with IR Camera

12-1291 1 XT12

Both are delivered with shoulder strap for display unit, Part No 12-0997. Weight: 1490 g [52.5 oz]

## **Examples of accessories for XT770:**

12-1151 1 Cardan bracket kit

12-1130 Dynamic measurement brackets (complete kit)

Magnetic bracket for XT-series 12-1147 Thin shaft bracket for XT-series 12-1012 1

12-1010 Sliding bracket for XT-series 1

12-1053 1 XT190 BTA Digital belt alignment tool

12-1090 XT280 Vibrometer 1

12-1354 1 Bore bracket kit

12-1355 Bore upgrade kit

#### XT Laser transmitter Upgrade Kits for older XT770 systems:

These kits are for upgrading of older versions of XT770. The interior of the included case fits XT12. Ask your local distributor for more information.

12-1320 1 Upgrade kit XT20

12-1321 1 Upgrade kit XT22

<sup>&</sup>lt;sup>1</sup> Please see our web site for a complete list of which tablets we recommend: easylaser.com > support > software download

Requires accessories.



















## Easy-Laser® XT660 Shaft

Part No: 12-1058

#### For all types of rotating machinery

The XT660 system comes with programs for alignment of horizontal, vertical/flange mounted machines, machine trains (3 machines) and cardan/offset mounted machines\*.

Functions for soft foot check, thermal growth compensation and toler-

With the Twist measurement program you easily check the base flatness. The very versatile Values program, together with the dot-type laser technology adds functionality for e.g. checking bearing clearance.

## XT60 measuring units

The XT60 units allow for multipoint, continuous sweep and uncoupled sweep measurements.

- Large 20x20 mm [0.79x 0.79"] 1 axis TruePSD detectors.
- Dot-type laser technology for accuracy and versatility.
- Rugged design, IP66/67 approved, featuring wireless technology.
- Built-in OLED display shows battery status and the angular value of the unit for easy positioning.
- Integrated rechargeable battery, operating time 24 h.

## Multi-platform alignment system

The XT Alignment App runs on your iOS and Android unit<sup>1</sup>. You can also choose to add our ergonomic and rugged, IP66/67 approved shock proof Easy-Laser® XT12 display unit. Choose it with or without IR camera.

Please also see the Programs and functions overview on page 7.

## System XT660 contains:

12-1028 1 Measuring unit XT60-M

12-1029	1	Measuring unit XT60-S
12-0963	2	Shaft bracket with chain and rods 120 mm
01-2117	4	Rods 75 mm
12-0128	1	Extension chain (2x900 mm)
03-1707	1	Measuring tape 5 m
03-0967	1	Hexagon wrench set
03-1256	1	Battery charger (100-240 V AC)
12-0989	1	DC split cable for charging

12-0751 1 DC to USB adapter, for charging

Quick manual (Note: Refers to English manual) 05-0863

03-0878 Cleaning cloth for optics 1

03-0914 1 USB memory stick with documentation

04-0307 1 Set of QR code stickers 12-0973 1 Carrying case Medium

WxHxD: 460x350x175 mm [18.1x13.8x6.9"]

Weight: 6.8 kg [14.9 lbs]

## Add display unit XT12:

12-1292 1 XT12 with IR Camera

12-1291 1 XT12

Both are delivered with shoulder strap for display unit, Part No 12-0997.

Weight: 1490 g [52.5 oz]

## **Examples of accessories for XT660:**

12-0013 1 Magnet base (Note: offset bracket also needed for C-C 56 mm.) 12-1008 Offset bracket for XT-series

12-1147 Magnetic bracket for XT-series

12-1012 Thin shaft bracket for XT-series 1

12-1010 1 Sliding bracket for XT-series

12-1161 Rods (4x75 mm)

12-0324 Rods (8x120 mm) 1

12-0060 1 Rods (4x240 mm)

12-1053 XT190 BTA Digital belt alignment tool 1

12-1090 1 XT280 Vibrometer

12-1244 XT290 Digital precision level

<sup>&</sup>lt;sup>1</sup> Please see our web site for a complete list of which tablets we recommend: easylaser.com > support > software download

Requires accessories.























## Easy-Laser® XT550 Ex/ATEX Shaft

Part No: 12-1031

## Shaft alignment system for hazardous areas

Easy-Laser® XT550 is designed for use in potentially explosive environments. It has all the programs and functions you need to keep your machines up and running.

Programs for alignment of horizontal, vertical/flange mounted machines, machine trains and cardan/offset mounted machines\*. Functions for soft foot check, thermal growth compensation and tolerance check. With the Twist measurement program you easily check the base flatness.

The very versatile Values program, together with the dot-type laser technology adds functionality for e.g. checking bearing clearance.

#### XT50 measuring units

The XT50 units allow for multipoint, continuous sweep and uncoupled sweep measurements.

- Large 20x20 mm [0.79x 0.79"] 1 axis TruePSD detectors.
- Dot-type laser technology for accuracy and versatility.
- Rugged design, IP66/67 approved, featuring wireless technology.
- Built-in OLED display shows battery status and the angular value of the unit for easy positioning.
- Integrated rechargeable battery, operating time 20 h.

## Multi-platform alignment system

For a complete system, add the zone 1/21 approved ECOM display unit. Built-in 13+8 MP cameras (rear+front) for documentation. The XT Alignment app also runs on other iOS and Android units.  $^{\rm 1\,2}$ 

## For local purchase, find your ECOM reseller here:

https://www.ecom-ex.com/company/locations/

Please also see the Programs and functions overview on page 7.

## The XT550 system contains:

- 12-1026 1 Measuring unit XT50-M Ex/ATEX
- 12-1027 1 Measuring unit XT50-S Ex/ATEX
- 12-1040 2 Shaft bracket Ex/ATEX, with chain and rods
- 12-1161 1 Set of Rods 4x75 mm
- 01-0873 2 Rods 120 mm
- 12-1038 2 Extension chain (900 mm)
- 03-1707 1 Measuring tape 5 m
- 03-0967 1 Rod tool
- 12-1281 1 Battery charger (100-240 V AC)
- 12-0989 1 DC split cable for charging
- 05-0889 1 Quick manual (Note: Refers to English manual)
- 03-0878 1 Cleaning cloth for optics
- 03-0914 1 USB memory stick with documentation
- 04-0307 1 Set of QR code stickers
- 12-1063 1 Carrying case, made of conductive plastics WxHxD: 450x300x180 mm [17.7x11.8x7.1"] Weight: 6.9 kg [15.2 lbs]

## Add display unit ecom:



## <sup>1</sup> Please see our web site for a complete list of which tablets we recommend: easylaser.com > support > software download

## **Examples of accessories for XT550:**

- 12-0013 1 Magnet base (Note: offset bracket also needed for C-C 56 mm.)
- 12-1008 1 Offset bracket for XT-series
- 12-1147 1 Magnetic bracket for XT-series
- 12-1012 1 Thin shaft bracket for XT-series
- 12-1010 1 Sliding bracket for XT-series
- 12-1161 1 Rods (4x75 mm)
- 12-0324 1 Rods (8x120 mm)
- 12-0060 1 Rods (4x240 mm)

## **CERTIFICATIONS:**

## XT50 measuring units:

EX certificate number: Presafe 17 ATEX 10552X, IECEx PRE 17.0049X EX classification: B II 2 G Ex ib op is IIC T4 Gb, -10°C  $\leq$  Ta  $\leq$  +50°C B II 2 D Ex ib op is IIIC T135°C Db, -10°C  $\leq$  Ta  $\leq$  +50°C

Note! The EX rating above is valid for the XT50 measuring units only, Part No. 12-1026 and 12-1027. Brackets, fixturing equipment, case, and other accessories are not subject to any EX classification, and must be assessed by the user before use in EX environment. Easy-Laser does not take responsibility for the EX safety of accessories.

## ecom display unit TabEx03 DZ1:

EX certificate number: EPS 22 ATEX 1055 X, IECEX EPS 22.0014X ATEX/UKCA Ex classification: ⓐ II 2G Ex db ia IIC T6 Gb IP64,  $-20^{\circ}\text{C} \le \text{Ta} \le +55^{\circ}\text{C}$ , ⓐ II 2D Ex ia tb IIIC T80°C Db,  $-20^{\circ}\text{C} \le \text{Ta} \le +55^{\circ}\text{C}$  IECEX classification: Ex db ia IIC T6 Gb IP64,  $-20^{\circ}\text{C} \le \text{Ta} \le +55^{\circ}\text{C}$ ,

Ex ia tb IIIC T80°C Db, -20°C  $\leq$  Ta  $\leq$  +55°C

<sup>&</sup>lt;sup>2</sup> For use in potentially explosive environments, the display device you use has to be at least approved for the same level of Ex/ATEX requirements as your work zone. Note that the XT12 isn't ATEX approved.

<sup>\*</sup> Requires accessories.



















## Easy-Laser® XT440 Shaft

Part No: 12-0966

## The mid-range entry level system!

The XT440 system comes with programs for alignment of horizontal and vertical/flange mounted machines.

Added to that are functions for soft foot check, thermal growth compensation and tolerance check.

The very versatile Values program adds functionality that normally only comes with mid-range systems, for example checking bearing clearance.

#### XT40 measuring units

- Large 30 mm [1.2"] 1 axis TruePSD detectors.
- Line laser technology for easy and quick operation.
- Rugged design, IP66/67 approved, featuring wireless technology.
- Built-in OLED display shows battery status and the angular value of the unit for easy positioning.
- Integrated rechargeable battery, operating time 24 h.

## Multi-platform alignment system

The XT Alignment App runs on your iOS and Android unit<sup>1</sup>. You can also choose to add our ergonomic and rugged, IP66/67 approved shock proof Easy-Laser® XT12 display unit. Choose it with or without IR camera.

Please also see the Programs and functions overview on page 7.

## The XT440 system contains:

THE AT-	770	system contains.
12-0943	1	Measuring unit XT40-M
12-0944	1	Measuring unit XT40-S
12-0963	2	Shaft bracket with chain and rods 120 mm
01-2117	4	Rods 75 mm
03-1707	1	Measuring tape 5 m
03-0967	1	Hexagon wrench set
03-1256	1	Battery charger (100-240 V AC)
12-0989	1	DC split cable for charging
12-0751	1	DC to USB adapter, for charging
05-0833	1	Quick manual (Note: Refers to English manual)
03-0878	1	Cleaning cloth for optics
03-0914	1	USB memory stick with documentation

04-0307 1 Set of QR code stickers 12-0973 1 Carrying case Medium

WxHxD: 460x350x175 mm [18.1x13.8x6.9"] Weight: 6.0 kg [13.3 lbs] Add display unit XT12:

12-1292 1 XT12 with IR Camera

12-1291 1 XT12

Both are delivered with shoulder strap for display unit, Part No 12-0997.

Weight: 1490 g [52.5 oz]

Exampl	es	of accessories for XT440:
12-1378	1	Bracket accessory kit
12-0013	1	Magnet base (Note: offset bracket also needed for C-C 56 mm.)
12-1008	1	Offset bracket for XT-series
12-1147	1	Magnetic bracket for XT-series
12-1012	1	Thin shaft bracket for XT-series
12-1010	1	Sliding bracket for XT-series
12-1161	1	Rods (4x75 mm)
12-0324	1	Rods (8x120 mm)
12-0060	1	Rods (4x240 mm)
12-0128	1	Extension chain (2x900 mm). For diameters up to 450 mm [12.7"].
12-1053	1	XT190 BTA Digital belt alignment tool
12-1090	1	XT280 Vibrometer
12-1244	1	XT290 Digital precision level

Please see our web site for a complete list of which tablets we recommend: easylaser.com > support > software download

<sup>\*</sup> Requires accessories.



















## Easy-Laser® XT660 Shaft SG1

Part No: 12-1389

## For alignment of generator to gearbox on wind turbines

This version of the XT660 system has brackets included for use on Siemens Gamesa (SG) turbines of different models. Functions for soft foot check, thermal growth compensation and tolerance check are included. By adding accessory brackets like V-brackets you can also use the system to align many other types of rotating machinery.

## XT60 measuring units

The XT60 units allow for multipoint, continuous sweep and uncoupled sweep measurements.

- Large 20x20 mm [0.79x 0.79"] 1 axis TruePSD detectors.
- Dot-type laser technology for accuracy and versatility.
- Rugged design, IP66/67 approved, featuring wireless technology.
- Built-in OLED display shows battery status and the angular value of the unit for easy positioning.
- Integrated rechargeable battery, operating time 24 h.

## Multi-platform alignment system

The XT Alignment App runs on your iOS and Android unit<sup>1</sup>. You can also choose to add our ergonomic and rugged, IP66/67 approved shock proof Easy-Laser® XT12 display unit, but please note that there is no space for XT12 in this case. You can however place a third party tablet in the case lid compartment (WxHxD: 250x220x20 mm).

Please also see the Programs and functions overview on page 38.

## System XT660 Shaft SG1 contains:

System	ΛI	660 Shart SG1 contains:
12-1028	1	Measuring unit XT60-M
12-1029	1	Measuring unit XT60-S
01-2117	4	Rods 75 mm
01-0873	4	Rods 120 mm
12-0013	2	Magnet base
12-1008	2	Offset bracket for XT series
12-1373	2	Flange clamping bracket
03-1707	1	Measuring tape 5 m
03-0967	1	Hexagon wrench set
03-1256	1	Battery charger (100-240 V AC)
12-0989	1	DC split cable for charging
12-0751	1	DC to USB adapter, for charging
05-0863	1	Quick manual (Note: Refers to English manual)
03-0878	1	Cleaning cloth for optics
03-0914	1	USB memory stick with documentation
04-0307	1	Set of QR code stickers
12-0973*	1	Carrying case Medium (*with SG1 insert added)
		WxHxD: 460x350x175 mm [18.1x13.8x6.9"]

Please note that in this case there is no space for an XT12 display unit.

## **Examples of accessories for XT660 Shaft SG1:**

12-0963 1 Shaft bracket with chain and rods 120 mm

12-1147 1 Magnetic bracket for XT-series

12-1161 1 Rods (4x75 mm)

12-0324 1 Rods (8x120 mm)

12-0060 1 Rods (4x240 mm)

Please see our web site for a complete list of which tablets we recommend: easylaser.com > support > software download



















## Easy-Laser® XT660 Shaft WMB

Part No: 12-1393

#### For alignment of generator to gearbox on wind turbines

The XT660 WMB (Wind Multi-Brand) system has brackets included for use on multiple brands and models. The addition of brackets are what sets this system apart from the standard XT660 system. Functions for soft foot check, thermal growth compensation and tolerance check are included.

## XT60 measuring units

The XT60 units allow for multipoint, continuous sweep and uncoupled sweep measurements.

- Large 20x20 mm [0.79x 0.79"] 1 axis TruePSD detectors.
- Dot-type laser technology for accuracy and versatility.
- Rugged design, IP66/67 approved, featuring wireless technology.
- Built-in OLED display shows battery status and the angular value of the unit for easy positioning.
- Integrated rechargeable battery, operating time 24 h.

## Multi-platform alignment system

The XT Alignment App runs on your iOS and Android unit<sup>1</sup>. You can also choose to add our ergonomic and rugged, IP66/67 approved shock proof Easy-Laser® XT12 display unit. Choose it with or without IR camera.

Please also see the Programs and functions overview on page 38.

## System XT660 Shaft WMB contains:

- Measuring unit XT60-M 12-1028 1
- 12-1029 Measuring unit XT60-S 1
- Shaft brackets with chain and rods 120 mm 12-0963 2
- 4 01-2117 Rods 75 mm
- Rods 120 mm 01-0873 4
- 12-0128 1 Extension chain (2x900 mm)
- 12-0013 2 Magnet base
- 12-1008 Offset bracket for XT series
- 12-1373 2 Flange clamping bracket
- 03-1707 1 Measuring tape 5 m
- 03-0967 1 Hexagon wrench set 03-1256 1
- Battery charger (100-240 V AC) 12-0989
- DC split cable for charging 12-0751 DC to USB adapter, for charging 1
- Quick manual (Note: Refers to English manual) 05-0863
- 03-0878 Cleaning cloth for optics 1
- USB memory stick with documentation 03-0914 1
- 04-0307 Set of QR code stickers 1
- 12-0973 1 Carrying case Medium

WxHxD: 460x350x175 mm [18.1x13.8x6.9"]

## Add display unit XT12:

12-1292 1 XT12 with IR Camera

12-1291 1 XT12

Both are delivered with shoulder strap for display unit, Part No 12-0997.

Weight: 1490 g [52.5 oz]

## **Examples of accessories for XT660 Shaft WMB:**

12-1161 1 Rods (4x75 mm)

12-0324 1 Rods (8x120 mm) 12-0060 1 Rods (4x240 mm)

<sup>&</sup>lt;sup>1</sup> Please see our web site for a complete list of which tablets we recommend: easylaser.com > support > software download













Part No: 12-1143 (Vestas 5/VT20025637)

Part No: 12-1284 (Vestas 5.5 - Mechanical bracket kit)

Part No: 12-1142 (Vestas 6/VT20025635) Part No: 12-1183 (Installation Kit Upgrade)

## For shaft alignment with the rotor locked.

Large forces are in action in a wind turbine. The safety of the maintenance technicians is therefore of the utmost importance. With the Easy-Laser® shaft alignment system the generator and gearbox can be aligned with the coupling dismounted and the brake locked.

The Easy-Laser® Vestas shaft alignment systems consist of one general installation kit, one supplement kit for use on more turbines, plus one upgrade kit (or just the bushings, see below).

Installation kit, Wireless, Vestas 5.

#### Mechanical bracket kit, Vestas 5.5.

Same as Vestas 5, but without display unit, measuring units, printer and associated items like cables, see items marked with \* in the list.

Supplement Service kit, Vestas 6.

#### Installation Kit Upgrade

If you have an older system Vestas 4 you can upgrade this for use at MK3E.

Please note that the brackets in all kits fit both E-series and XT-series measuring units. New design of bracket shown below.





#### A Vestas 5 system contains:

12-0700*	1	Display	unit	E52
----------	---	---------	------	-----

01-1379\* 1 Protective case for display unit E52

12-0777\* 1 Measuring unit ELS40, PSD 30 mm, inclinometer

12-0776\* 1 Measuring unit ELM40, PSD 30 mm, inclinometer

12-0712 5 Nut to adapters with magnet M6 V112

12-0714 4 Screw to Adapters V112, L=75mm

12-0713 2 Fixture Kit for V112

01-1520 Adaptor for fixture V112 4

03-0613 1 Distance gauge incl. adaptor, incl. fastening screw L=35mm

03-1034 Distance gauge incl. adaptor, incl. fastening screw L=55mm

01-2163 Bushings for MK3E / V150

Bushings for MK3E / V150 01-2142 1

Washer for MK3E / V150 01-2143 2

12-1140 Screw to bushings V150 L=45mm

12-0495\* 1 Strap to display unit

USB memory stick 4GB 03-0914\* 1

03-0822\* 1 USB cable A to B 1.8 m

03-1243\* 1 Battery charger (100-240 V AC) Lev. 6

DC split cable for charging

12-0751\* 1 DC to USB adapter, for charging

03-1004\* 1 Printer Seiko DPU-S445, including charger, cable and USB

03-0824 1 Measurement tape 3m

05-0954\* 1 Manual E540 Vestas 12-1164 1 Carrying Case Vestas 5

Weight: 28 kg [61.7 lbs]

WxHxD: 670x600x220 mm [26.4x23.6x8.7"]

\* These items are not included with Vestas 5.5. System weight: 25 kg [55.1 lbs]

## A Vestas 6 system contains:

**Detector-fixture Generator flange** 12-0703 1

12-0297 Screw knob to Generator fixture M12

12-0298 2 Screw knob to Generator fixture M16

12-0718 **Detector-fixture Gearbox flange** 

Adapter for Gearbox fixture 25 mm 01-0815 3

01-0816 3 Adapter for Gearbox fixture 24 mm

01-0817 Adapter for Gearbox fixtrure 22 mm

01-0818 3 Adapter for Gearbox fixture 17 mm

12-0296 3 Screw to adapters

12-0299 4 Nut to adapters with magnet M6

12-1165 1 Carrying case Vestas 6

Weight: 12.3 kg [27.1 lbs

WxHxD: 570x470x220 mm [22.4x18.5x8.7"]

#### A Vestas Laser Installation Upgrade Kit contains:

Bushings for MK3E, set of 2 (VT20025636) 12-1154 1

Carrying case Vestas 5

12-1165 1 Carrying case Vestas 6



## Bracket kit GA1 for wind turbines

Part No: 12-1114

## For shaft alignment with the rotor locked.


Large forces are in action in a wind turbine. The safety of the maintenance technicians is therefore of the utmost importance. With the Easy-Laser® shaft alignment system the generator and gearbox can be aligned with the coupling dismounted or in place. This bracket kit is designed especially for Gamesa turbines, and fits turbine types according to image below.

Note: brackets fit both Easy-Laser E-series and XT-series measuring units.









Note: brackets in 12-1114 fit both E-series and XT-series measuring units. New design shown above.

	JOINT ELEMEN	TURBINE MO	DOEL	
M2	4 bolts + small bushings	G9X-G114 2.0 MW; 0	3114 2.5 MW	
M3	0 bolts + large bushings	G126 2.5 MW; G1	32 3.3 MW	
G9X	G114 2.0MW	G114 2.5 MW	G126 2.5 MW	G132 3.3 M
00	0	0	0	60

G9X	G114 2.0MW	G114 2.5 MW	G126 2.5 MW	G132 3.3 MW
(0)	450	100	12	0
8	(Control of	(A)	0	0 0
0 0 0	0 0	1		Citizen O
2000	5	100	60	
00	0	3		0 0

## System 12-1114 contains:

12-0975	1	Detector-fixture Generator flange 6	ìA1
---------	---	-------------------------------------	-----

<sup>01-1889 2</sup> Adapters to Generator flange GA1 M24

Weight: 17.0 kg [37.5 lbs]

WxHxD: 565x455x210 mm [22.2x17.9x8.2"]

<sup>01-1892 2</sup> Adapters to Generator flange GA1 diameter 40 mm

<sup>01-1891 2</sup> Adapters to Generator flange GA1 diameter 31 mm

<sup>01-1890 2</sup> Adapters to Generator flange GA1 diameter 25 mm

<sup>12-0974 2</sup> Screw to Adapters L=120 mm

<sup>12-0712 2</sup> Nut to adapters with magnet M6

<sup>12-0976 1</sup> Detector-fixture Gearbox flange GA1

<sup>12-0977 3</sup> Screw M24 for Gearbox fixture

<sup>12-0978 3</sup> Screw M30 for Gearbox fixture

<sup>01-1884 3</sup> Adapters for M24 Screw to Gearbox fixture

<sup>01-1885 3</sup> Adapters for M30 Screw to Gearbox fixture

<sup>03-0613 1</sup> Distance Gauge (coupling flanges), incl. adapter

<sup>03-1034 2</sup> Ext. adapter distances gauge

<sup>12-1116 1</sup> Plastic carrying case for 12-1114




















XT app for XT12/XT11 and iOS/Android display units.



Belt alignment program for E51 and E52.

## Easy-Laser® XT190 BTA digital Wireless

Part No: 12-1053

## "Live" digital read outs on clear OLED display

The detector reads off the position in relation to the laser plane and digitally displays the parallel and angular misalignment "live" on the clear built-in OLED display. The accuracy of the reading means that you can be within the prescribed alignment tolerances and rely upon the result. Suitable for most types of drive, such as V-belt, timing belt, flat belt and chain drives.

The laser transmitter has two power modes (high/low) which now makes it possible to measure on very long distances. The low power mode saves battery life.

If you connect the detector wirelessly to a separate display unit, e.g. one of our shaft alignment systems, you can read and follow the alignment from where you are standing and making adjustments, instead of only where the detector is mounted. Then you can also set a tolerance and document the result of the alignment.

(Note 1: The XT190 detector unit connects to both the E- and XT-series display units. You can also use it with your iOS and Android phone/tablet. Please see our web site for compatible models.)

(Note2: There is no separate display unit included. The detector connects wireless to the E51/E52 and XT12/XT11 display units with Belt alignment program.)

#### A complete system contains:

12-1325 1 Laser transmitter

12-1054 1 Detector unit with built-in display, wireless

12-0394 2 Targets

03-1256 1 Charger (100-240 V AC) and cable

03-0247 1 Battery R6 (AA) 1.5 V


03-0914 1 USB memory stick with documentation

05-0865 1 Quick manual (Note: Refers to English manual)


12-0804 1 Carrying case














## Easy-Laser® D92 BTA

Part No: 12-1332

## For quick and easy alignment of sheaves/pulleys

Easy-Laser® D92 is installed in a few seconds, and the laser line that is projected on the targets clearly shows how to adjust the machines. The tool has targets that can be read out "visually" and which give excellent degrees of accuracy that are sufficient for most users.

The laser transmitter has two power modes (high/low) which now makes it possible to measure on very long distances. The low power mode instead saves battery life.

If, in the future, you wish to have the option of digital readouts with the corresponding advantages, you can add a digital detector (see system XT190).

D92 BTA is compact and light. Suitable for most types of drive, such as V-belt, timing belt, flat belt and chain drives.

## A complete system contains:

12-1325 1 Laser transmitter

12-0394 2 Target

05-0352 1 Manual

03-0247 1 Battery R6 (AA) 1.5 V

03-0591 1 Padded cover




















XT app for XT12/XT11 and iOS/Android display units.



Legs for measurement on large cylindrical surfaces.

## Easy-Laser® XT290 Digital precision level

Part No: 12-1244

#### For reliable machinery installation

Digital levels are extremely useful tools for setting-up and aligning most types of machines, for example, levelling machine bases, rolls, tables, etc. 0.1 mm/m [mils/inch] is a normal requirement for level at machine installations to ensure correct functionality. Other applications include checking straightness, flatness and parallelism. Easy-Laser® XT290 is simply the must-have addition to your laser-based alignment system.

Accuracy is guaranteed by the precision-ground, hardened steel base. Wide measurement range, very fast inclinometer/value stabilisation, and an easy-to-read TFT colour display with graphics makes the measurement procedure quick and easy. Two mounting holes allow for your own adaptations and brackets.

## Connect to a separate display unit

The XT290 connects to the free XT Alignment app (iOS/Android) and our XT12/XT11 display unit. Using a separate display unit, for example your smartphone, makes it all even easier as you can read off and follow the adjustment at the point on the machine where the adjustment is made. It is also safer for some applications, where you can leave the unit inside the safety fence, then follow the measurement outside it.

You can make a measurement report with pictures and share it (PDF and Excel). Using the app you can also record values during a set time and frequency, i.e. dynamic measurements. Another possibility with the app is to connect up to four digital levels (or e.g. two levels and two measuring units) at the same time, displayed in the same screen view.

Precision level accuracy:  $\pm 0.02$  mm/m  $\pm 1\%$  [ $\pm 0.02$  mils/inch  $\pm 1\%$ ] Inclinometers accuracy:  $\pm 0.2^\circ$  (within range  $\pm 5^\circ$ ),  $\pm 1^\circ$  (within range  $\pm 180^\circ$ ) Please see chapter *Technical specifications and drawings* for more data. (Note: The XT290 does not work with the E-series display units. You can of course still use it as a separate tool.)

#### A complete system contains:

12-1241 1 Digital Precision Level

01-1402 1 Screw for mounting safety strap\*

03-1256 1 Charger (100-240 V AC) and cable

03-0914 1 USB memory stick with documentation

05-0990 1 Quick manual (Note: Refers to English manual)

12-1243 1 Carrying case

## Complete system:

Weight: 2.2 kg [4.85 lbs]

WxHxD: 270x240x120 mm [10.6x9.4x4.7"]

#### **Examples of accessories:**

12-0901 1 Legs for measurement on cylindrical surfaces 55-800 mm

03-1406 1 Safety strap Bahco 3875-LY2\*


\*Please note that safety regulations differ from country to country.




















## XT280 Vibrometer

Part No: 12-1090

## FOR QUICK VIBRATION ANALYSIS

Easy-Laser® XT280 is an easy-to-use vibration monitoring and analysis tool that allows easy display of vibration signals. The XT280 automatically performs vibration analysis functions based on machine running speed to help diagnose faults such as unbalance, misalignment and looseness. The system is designed to enable you to take vibration measurements from assets like pumps, motors, fans and bearings. The unit displays vibration frequency plots and allows vibration severity and bearing condition to be monitored.

For documentation purpose, you can connect the XT280 to the XT Alignment App. Run the app on your phone or tablet\*, or the XT12/XT11 display unit.

\* Please see our web site for compatible models.

## A complete system contains:

12-1050 1 Vibrometer (with short tip)

05-0934 1 Quick manual

03-0914 1 USB memory stick with documentation

03-1429 1 Screw driver Torx T8

03-1336 1 Padded case

## **Examples of accessories:**

03-1327 1 Accelerometer magnet

03-1326 1 Stinger (100 mm)



















## Easy-Laser® XT980 Sawmill

Part No: 12-1335

#### Measurement and alignment of sawmill machinery

Easy-Laser® XT980 is a laser based measurement and alignment system that helps sawmills to make optimal use of their machines. By setting the machines up correctly it is possible to maintain a high rate of production with the highest quality end products hour after hour. Laser transmitter XT22 has a manually rotated laser head with an angular prism, making it very versatile and suitable for most geometrical measurements.

With Easy-Laser® XT980 measuring and adjustment of reducers, counterholds, saw blades and discs become a simple and quick task. The laser line works as an absolutely straight ruler for 40 metres, and is very practical for the demanding and dusty environment of a sawmill. It replaces the long wire used traditionally, and gives many more possibilities for aligning the saw equipment. It can be used equally well for circular saws and band saws.

## Benefits of using Easy-Laser® XT980 are:

- Higher production speed
- · Less unplanned downtime
- · Better product quality
- · Longer lifetime for blades
- · Longer lifetime for bearings
- Less vibration
- Less waste material

There is a standard system configuration plus some useful accessories. Together with our Easy-Laser representative, the system is adapted to best fit your actual machinery.

The measurement app runs on your iOS and Android unit<sup>1</sup>. You can also choose a complete system with our ergonomic and rugged, IP66/67 approved shock proof Easy-Laser® XT display unit. Choose it with or without IR camera.

Please also see the Programs and functions overview on page 38.

## The XT980 system contains:

- 12-1273 1 Laser transmitter XT22
- 12-1045 1 Measuring unit XT70-M
- 03-0833 2 Electronic target
- 12-1275 1 Multi bracket for XT laser
- 12-1133 1 Magnet base with turnable head
- 12-0013 1 Magnet base
- 12-0963 1 Shaft bracket with chain
- 12-1008 2 Offset bracket
- 12-0624 2 Bracket for electronic target
- 12-1209 1 Rotating detector bracket for rods
- 12-1210 1 Magnet bracket long, with turnable head 12-1211 1 Magnet bracket short, with turnable head
- 12-1087 1 Set square bracket for index table
- 12-1083 1 Index table 90°
- 12-0987 2 Set of Rods (4x120 mm)
- 12-1161 1 Set of Rods (4x75 mm)
- 12-1232 2 Large target with magnets
- 05-0993 1 Quick Guide (English)
- 03-0842 1 Measuring tape 5 m
- 12-1299 1 Documentation folder GEO
- 03-0822 1 USB cable
- 03-1256 1 Battery charger (100-240 V AC)
- 12-0989 1 DC split cable for charging
- 12-0751 1 DC to USB adapter
- 03-0878 1 Cleaning cloth for optics
- 03-0914 1 USB memory stick with documentation
- 03-1419 2 Screw clamps
- 03-0967 1 Hexagon wrench set
- 12-1300 1 Toolbox XT GEO
- 12-1298 1 Transportation case, with wheels

## Add display unit XT12:

12-1292 1 XT12 with IR Camera

12-1291 1 XT12

Both are delivered with shoulder strap for display unit, Part No 12-0997.

Weight: 1490 g [52.5 oz]

## **Examples of accessories:**

12-1010 1 Sliding bracket for XT-series

12-0060 1 Rods (4x240 mm)

12-1262 1 Detector bracket for centering on wire position

12-0503 1 Bracket (Set square) for transmitter

12-1123 1 Extension for set square 12-1087, 295 mm

12-1124 1 Extension for set square 12-1087, 430 mm

12-1060 1 Extension chain (2x900 mm). For diameters up to 450 mm [12.7"].

12-1053 1 XT190 BTA Digital belt alignment tool

12-1090 1 XT280 Vibrometer

12-1244 1 XT290 Digital precision level

## Complete system:

Weight: 28.0 kg [61.7 lbs]

WxHxD: 622x492x310 mm [24.5x19.4x12.2"]

Please see our web site for a complete list of which tablets we recommend: easylaser.com > support > software download















## Easy-Laser® E980 Sawmill

Part No: 12-0727

#### Measurement and alignment of sawmill machinery

Easy-Laser® E980 is a laser based measurement and alignment system that helps sawmills to make optimal use of their machines. By setting the machines up correctly it is possible to maintain a high rate of production with the highest quality end products hour after hour.

With Easy-Laser® E980 measuring and adjustment of reducers, counterholds, saw blades and discs become a simple and quick task. The system has the D23 Spin laser transmitter (motor driven laser head), which makes it easier for just one person to measure, if required. It replaces the long wire used traditionally, and gives many more possibilities for aligning the saw equipment. Thanks to the user friendliness of a laser measurement system the alignment work is properly done when necessary. The investment is quickly returned through fewer production stoppages and more even quality in the sawn timber. It can be used equally well for circular saws and band saws.

Benefits of using Easy-Laser® E980 are:

- Higher production speed
- · Less unplanned downtime
- Better product quality
- · Longer lifetime for blades
- Longer lifetime for bearings
- Less vibration
- Less waste material

There is a standard system configuration plus some useful accessories. Together with our Easy-Laser representative, the system is adapted to best fit your actual machinery.

Please note that the application picture show older design of index table.

#### A complete system contains:

12-0418	1	Display unit E51
12-0168	1	Laser transmitter D2

12-0509 1 Detector E5 12-0436 1 Wireless unit

03-0833 2 Electronic target

12-0074 1 Cable 2 m

12-0108 1 Cable 5 m, extension

12-1133 1 Magnet base with turnable head

12-0013 1 Magnet base

12-0016 1 Shaft bracket with chain

12-1008 2 Offset bracket

12-0624 2 Bracket for electronic target

12-1209 1 Rotating detector bracket for rods

12-1210 1 Magnet bracket long, with turnable head

12-1211 1 Magnet bracket short, with turnable head

12-1087 1 Set square bracket for index table

12-1083 1 Index table 90°

12-1161 1 Set of Rods (4x75 mm)

12-0987 2 Set of Rods (4x120 mm)

12-1232 2 Large targets

05-0685 1 Manual (Note: Refers to English manual)

 $03\text{-}0842 \quad 1 \quad \text{Measuring tape 5 m}$ 

03-0914 1 USB memory stick with documentation

03-0822 1 USB cable

03-1243 1 Battery charger (100-240 V AC)

03-0967 1 Hexagon wrench set (incl. with 12-0168)

03-1419 2 Screw clamps

12-0495 1 Shoulder strap for Display unit

03-0878 1 Cleaning cloth for optics

12-1007 1 Transportation case, with wheels

## Examples of accessories:

12-1010 1 Sliding bracket (for vertical support rolls)

12-0022 1 Laser transmitter D22 (add or exchange the D23)

12-0752 1 Detector E7 (add an extra unit for more measurement possibilities)

12-0060 1 Rods (4x240 mm)

12-1262 1 Detector bracket for centering on wire position

12-0503 1 Bracket (Set square) for transmitter

12-1060 1 Extension chain (2x900 mm). For diameters up to 450 mm [12.7"].

12-1053 1 XT190 BTA Digital belt alignment tool

12-1090 1 XT280 Vibrometer

12-1244 1 XT290 Digital precision level

Note: always check number of items included for each Part No. before ordering.

## Complete system:

Weight: 29.0 kg [63.9 lbs]

WxHxD: 622x492x310 mm [24.5x19.4x12.2"]















## Easy-Laser® E970 Parallelism

Part No: 12-0853

#### For parallelism measurement

For parallelism measurement of rolls and other objects in numerous applications. This system use the traditional method where the laser beam (reference) is pointed alongside the machine, and then deflected 90° towards the detector on the measurement object by a penta prism. Measurement values for the horizontal position are registered in both ends of the object. The included precision level is used for the vertical position. Any chosen object or the baseline can be used as a reference. For rolls with diameter 40 mm [1.6"] and larger. Maximum measurement distance with a standard system is 80 metres [260 feet] (40 metres in each direction from the transmitter).

Easy-Laser® E970 is a very versatile system. You can also use it to measure level, straightness and flatness on wire sections (suction boxes), flatness on bases and straightness on rolls. This makes Easy-Laser® a very cost effective solution for your maintenance department.

#### A complete system contains:

12-0418 1 Display unit E-series E51

12-0022 Laser transmitter D22 incl. tilt table

12-0752 **Detector E7** 1

12-0436 Wireless unit for E7 1

12-0846 E290 Digital Precision Level

12-0901 Extension Kit for E290 1

12-0074 Cable 2 m

12-0108 Cable 5 m, extension

12-1352 1 Angular prism Mk2

Target for laser transmitter (small hole) 12-1188

12-1261 Target for laser transmitter (large hole)

01-2232 Tripod adaptor for Angular prism

12-0269 Tripod 2

12-0203 Parallelity kit

12-0060 Set of Rods 4x240 mm

12-0987 1 Set of Rods 4x120 mm

Set of Rods 4x60 mm 12-0059

Manual (Note: Refers to English manual) 05-0685

03-0842 Measuring tape 5 m

03-0914 USB memory stick with documentation 1

03-0822 1 **USB** cable

03-1243 1 Battery charger (100-240 V AC)

12-0989 1

DC charging cable 12-0751 DC to USB adapter

03-0967 Hexagon wrench set

12-0495 Shoulder strap for Display unit

03-0878 1 Cleaning cloth for optics

12-0869 1 Carrying case

## **Examples of accessories:**

12-1053 1 XT190 BTA

12-0856 Roll alignment Kit Thermal printer 03-1004

12-0455 Slide bracket Small

12-0543 Slide bracket Medium

12-0510 Slide bracket Large 1

12-0269 Tripod

03-1406 Safety strap Bahco 3875-LY2 1

Note: always check number of items included for each Part No. before ordering.

#### Complete system:

Weight: 19.9 kg [43.9 lbs]

WxHxD: 620x490x220 mm [24.4x19.3x8.7"]

Tripod:


Weight: 7.9 kg [17.4 lbs]

Transport length: 1110 mm [44"]















## Easy-Laser® E960-A Turbine alignment

Part No: 12-0710

#### Reliability and precision

Easy-Laser® E960-A has a measuring probe with a stroke of 10 mm (Short stroke). The slidable tube makes it possible to measure several positions in a row without moving the bracket. Suitable for gas turbines and smaller steam turbines. Makes the measurement and adjustment work of diapraghms and bearings easier thanks to the wireless detector unit and measurement programs that guides you through the measurement process. All of the parts included in the systems are designed and built for even the most demanding workplace and for easy setup on any machinery. The versatile design solves the straightness measurement problems quickly and with precision for any kind of application. Objects up to 40 m [132 feet] can be measured. The detector reads measurement values with a resolution of 0.001 mm [0.05 mils]. Measures diameters 150–1700 mm [5.9–67"].

## Versatile programs

The straightness programs of system E960 are very versatile, and let you work in the way that suits every job best. You can add, remove and remeasure measurement points at any time during the measurement. Up to 999 points can be handled by the program. You can include both full bores and half bores in any possible combination in one measurement, the program will calculate the correct centre line in all cases. The measurement program includes many different methods for straightness measurement:

1-point measurement, 4-point measurement, Multipoint measurement (also ovality measurement), 3-point measurement, 3-point measurement with arbitrary angles. Optionally a reference detector can be used to monitor the laser transmitter position at long distances.

#### The measurement result

Thanks to the large colour display with clear graphs and measurement data you can evaluate the result directly on site. Any point can be set as reference and you can set an offset to which the centre line will be recalculated. You can also calculate waviness (short and long) and best-fit for the points. If you want, the result can also be checked against a tolerance value. The measurement system takes care of all these complicated calculations for you.

## A complete system contains:

12-0418	1	Display unit E-series E51
12-0075	1	Laser transmitter D75

12-0752 1 Detector E7

12-0436 1 Wireless unit

12-0074 1 Cable 2 m

12-0385 1 Laser transmitter bracket

12-0661 1 Offset hub for Laser transmitter

12-0438 1 Detector bracket Short stroke

12-0443 2 Centering target

12-0495 1 Shoulder strap for Display unit

05-0685 1 Manual (Note: Refers to English manual)

03-0842 1 Measuring tape 5 m

03-0914 1 USB Memory stick with documentation

03-0822 1 USB Cable

03-1243 1 Battery charger (100-240 V AC)

03-0878 1 Cleaning cloth for optics

12-0724 1 Carrying case with wheels

#### Complete system:

Weight: 33.5 kg [73.8 lbs]

WxHxD: 1260x550x220 mm [4.6x21.6x8.7"]

#### **Examples of accessories:**

12-0805 1 Measuring probe ruby, diameter 5 mm

12-0801 1 Measuring probe ruby, diameter 2.5 mm

12-1047 1 Measuring probe cylindrical

12-0707 1 Offset hub arm kit for diameters 100-500 mm

12-0752 1 E7 (as reference detector)

12-0187 1 Magnetic bracket for D75

12-0107 1 Magnetic Bracket for B7

03-1004 1 Thermal printer

12-0022 1 Laser transmitter D22

12-0706 1 Laser transmitter D25


Note: always check number of items included for each Part No. before ordering.















## Easy-Laser® E960-B Turbine alignment

Part No: 12-0711

#### Reliability and precision

Easy-Laser® E960-B has a measuring probe with a stroke of 60 mm (Long stroke). Suitable for larger turbines. The system makes the measurement and adjustment work of diapraghms and bearings easier thanks to the wireless detector unit and measurement programs that guides you through the measurement process. All of the parts included in the systems are designed and built for even the most demanding workplace and for easy setup on any machinery. The versatile design solves the straightness measurement problems quickly and with precision for any kind of application. Objects up to 40 m [132 feet] can be measured. The detector reads measurement values with a resolution of 0.001 mm [0.05 mils]. Measures diameters 200–1700 mm [7.8–67"] as standard, and up to 4000 mm [157"] with accessory brackets.

## Versatile programs

The straightness programs of system E960 are very versatile, and let you work in the way that suits every job best. You can add, remove and remeasure measurement points at any time during the measurement. Up to 999 points can be handled by the program. You can include both full bores and half bores in any possible combination in one measurement, the program will calculate the correct centre line in all cases. The measurement program includes many different methods for straightness measurement:

1-point measurement, 4-point measurement, Multipoint measurement (also ovality measurement), 3-point measurement, 3-point measurement with arbitrary angles. Optionally a reference detector can be used to monitor the laser transmitter position at long distances.

#### The measurement result

Thanks to the large colour display with clear graphs and measurement data you can evaluate the result directly on site. Any point can be set as reference and you can set an offset to which the centre line will be recalculated. You can also calculate waviness (short and long) and best-fit for the points. If you want, the result can also be checked against a tolerance value. The measurement system takes care of all these complicated calculations for you.

#### A complete system contains:

12-0418	1	Display unit E-series E5
12-0075	1	Laser transmitter D75

12-0752 1 Detector E7 12-0436 1 Wireless unit

12-0436 1 Wireless uni

12-0385 1 Laser transmitter bracket

12-0661 1 Offset hub for Laser transmitter

12-0715 1 Detector bracket Long stroke

12-0443 2 Centering target

12-0495 1 Shoulder strap for Display unit

05-0685 1 Manual (Note: Refers to English manual)

03-0842 1 Measuring tape 5 m

03-0914 1 USB Memory stick with documentation

03-0822 1 USB Cable

03-1243 1 Battery charger (100-240 V AC)

03-0878 1 Cleaning cloth for optics

12-0724 1 Carrying case with wheels

## Complete system:

Weight: 36.5 kg [80.5 lbs]

WxHxD: 1260x550x220 mm [4.6x21.6x8.7"]

#### **Examples of accessories:**

12-0805 1 Measuring probe ruby, diameter 5 mm

12-0801 1 Measuring probe ruby, diameter 2.5 mm

12-1047 1 Measuring probe cylindrical

12-0707 1 Offset hub arm kit for diameters 100-500 mm

12-0752 1 E7 (as reference detector)

12-0187 1 Magnetic bracket for D75

12-0282 1 Set of extension arms

03-1004 1 Thermal printer

12-0022 1 Laser transmitter D22

12-0706 1 Laser transmitter D25

Note: always check number of items included for each Part No. before ordering.



















## Easy-Laser® XT950 Bore alignment With laser transmitter D75

Part No: 12-1356

## Bore alignment for a wide range of applications

The Easy-Laser® XT950 system is primarily designed for applications like engines, compressors and gearboxes, but can be used in many more applications. The XT9 detector makes it possible to measure bores with diameter 80–500 mm [3.15–19.68"] as standard.

The bracket system is very versatile and provides many possibilities to mount the detector in bores with different widths, and they can also be assembled in many ways for different situations. The magnetic feet holds the detector in perfect position for stable and precise measurements.

Learn more about the brackets in the Technical specifications section at the end of this catalogue.

The Bore Center program guides the user through the entire measurement process which contributes to simple operation. The system automatically calculates the bearing journals positions in relation to each other, both horizontally and vertically. You can then evaluate the results with different Best fit calculation methods, analyse different choices of reference points and set tolerance values.

All parts are designed for maximum accuracy and stability, and measure with a resolution of 0.001 mm [0.05 mils]. Measurement distance up to 40 m [130 feet]. Easy-Laser® XT950 is suitable for use both in manufacturing and in field services activities.

#### Also for other straightness measurements

With the systems, you can also measure the straightness of shafts, linear guides, foundations, etc. without any additional accessories.

## System XT950 contains:

12-0075 1 Laser transmitter D75

12-1350 **Detector XT9** 1

12-0661 Offset hub with counterlock for D75 1

12-0707 1 Arm kit with magnets

12-1161 1 Set of rods 4x75 mm

12-0987 Set of rods 4x120 mm

Set of rods 4x240 mm 12-0060 1

12-0455 Slide bracket Small

12-0543 Slide bracket Medium 1

12-0510 1 Slide bracket Large

12-1277 1 Bracket with rotatable bore probe, XT

12-1357 Target for detector rough alignment

Axial support for slide brackets 12-1368

12-1351 Rod adapter with built-in target C-C 56 mm 1 12-0767 Rod adapter with built-in target C-C 40 mm

12-0768 Slide bracket, 25 mm width 1

03-1256 1 Battery charger (100-240 V AC)

03-0914 USB memory stick with documentation

03-1707 Measuring tape 5 m 1

03-0967 Hexagon wrench set

12-0751 DC to USB adapter, for charging 1

12-0989 1 DC split cable for charging

03-0878 Cleaning cloth for optics 1 12-1394 1 Carrying case XT Linebore

WxHxD: 546x432x244 mm [21.5x17.0x9.6"]

## Add display unit XT12:

12-1292 1 XT12 with IR Camera

12-1291 1 XT12

Both are delivered with shoulder strap for display unit, Part No 12-0997.

Weight: 1490 g [52.5 oz]

#### **Examples of accessories for XT950:**

12-0553 1 Bore bracket adapter plate

12-0314 Detector arms Linebore

12-0187 Magnetic bracket for D75

12-0282 1 Set of extension arms

12-0580 Axial extension arms 12-0990 1 Adjustable magnet for offset hub arms

31















## Easy-Laser® E950-A Bore alignment

Part No: 12-0676

#### Bore alignment with the highest reliability and precision

Easy-Laser® E950-A is primarily designed for diesel engines (for example crank and camshaft bearings), gearboxes, compressors and similar applications. Positioning workpieces in machine tools is also an appropriate application.

Easy-Laser® E950 makes checking and aligning bearings and bearing journals easier thanks to wireless detectors and versatile brackets. A large colour display with clear graphics and software that guides the user through the entire measurement process contributes to simple operation. The system automatically calculates the bearing journals positions in relation to each other, both horizontally and vertically. You can then evaluate the results directly on-site with different calculation methods such as Best fit around zero and Waviness. It is also possible to analyse the different choices of reference points and set the offset and tolerance values.

A great feature is the check of ovality, for example, to analyse the wear rate. The measurement system takes care of all these complicated calculations for you. You measure and align both full and half bearing journals with equal simplicity. The wireless detector eliminates uncertain factors such as cable pull. All parts are designed for maximum accuracy and stability, and measure with a resolution of 0.001 mm [0.05 mils]. Measurement distance up to 40 m [130 feet]. Easy-Laser® E950 is suitable for use both in production and out in the field.

## Also straightness of shafts

With the systems, you can also measure the straightness of shafts, foundations, etc. without any additional accessories.

#### A complete system contains:

12-0418	1	Display unit E-series E5
10 0075	4	Lacar transmitter D7F

Laser transmitter D75

12-0752 **Detector E7** 1

12-0436 1 Wireless unit

12-0074 1 Cable 2 m

Cable 5 m. extension 12-0108 1

12-0661 Offset hub for Laser transmitter

12-0384 Set of offset hub arms for diameters 100-500 mm 1

12-0154 1 Set of magnets for offset hub arms

12-0990 1 Adjustable magnet for offset hub arms

Slide bracket Small 12-0455 1

12-0543 Slide bracket Medium

12-0510 Slide bracket Large 1

12-0588 Large target E-series

12-0013 Magnet base

Set of rods (4x60 mm) 12-0059 1

01-0938 2 Rods 30 mm

01-0873 Rods 120 mm 4

01-0044 Rods 240 mm

12-0495 Shoulder strap for Display unit 1

05-0685 Manual (Note: Refers to English manual)

03-0842 Measuring tape 5 m 1

USB Memory stick with documentation 03-0914 1

03-0822 **USB Cable** 

Battery charger (100-240 V AC) 03-1243

03-0967 Hexagon wrench set

03-0878 Cleaning cloth for optics 1

12-0684 1 Carrying case Linebore A

## **Examples of accessories:**

12-0187 Magnetic bracket for D75

12-0282 Set of extension arms

12-0580 Axial extension arms

03-1004 1 Thermal printer

12-0022 Laser transmitter D22

Note: always check number of items included for each Part No. before ordering.

## Complete system:

Weight: 14.0 kg [30.8 lbs], WxHxD: 550x450x210 mm [21.6x17.7x8.3"]















## Easy-Laser® E950-B Bore alignment

Part No: 12-0677

## Bore alignment with the highest reliability and precision

Easy-Laser® E950-**B** is primarily designed for propeller shaft installations on ships with stern tubes, support bearings, gearboxes and engines.

Easy-Laser® E950 makes checking and aligning bearings and bearing journals easier thanks to wireless detectors and versatile brackets. A large colour display with clear graphics and software that guides the user through the entire measurement process contributes to simple operation. The system automatically calculates the bearing journals positions in relation to each other, both horizontally and vertically. You can then evaluate the results directly on-site with different calculation methods such as Best fit around zero and Waviness. It is also possible to analyse the different choices of reference points and set the offset and tolerance values.

A great feature is the check of ovality, for example, to analyse the wear rate. The measurement system takes care of all these complicated calculations for you. You measure and align both full and half bearing journals with equal simplicity. The wireless detector eliminates uncertain factors such as cable pull. All parts are designed for maximum accuracy and stability, and measure with a resolution of 0.001 mm [0.05 mils]. Measurement distance up to 40 m [130 feet]. The included aluminium beams for the laser transmitter bracket are 1100 mm [43.31"] (main beam) and 500 mm [19.86"] (vertical support beam). Easy-Laser® E950 is suitable for use both in production and out in the field.

## Also straightness of shafts

With the systems, you can also measure the straightness of shafts, foundations, etc. without any additional accessories.

#### A complete system contains:

12-0418	1	Display unit E-series Es
12-0075	1	Laser transmitter D75
12-0752	1	Detector E7
12-0436	1	Wireless unit
12-0074	1	Cable 2 m

12-0108 1 Cable 5 m, extension

12-0661 1 Offset hub for Laser transmitter

12-0385 1 Laser transmitter bracket for sterntube

12-0341 1 Self centering detector bracket for diameter 300-1200 mm

12-0588 1 Large target E-series

12-0013 1 Magnet base

12-0059 1 Set of rods (4x60 mm)

01-0938 2 Rods 30 mm

01-0873 4 Rods 120 mm

01-0044 2 Rods 240 mm

12-0495 1 Shoulder strap for Display unit

05-0685 1 Manual (Note: Refers to English manual)

03-0842 1 Measuring tape 5 m

03-0914 1 USB Memory stick with documentation

03-0822 1 USB Cable

03-1243 1 Battery charger (100-240 V AC)

03-0967 1 Hexagon wrench set

03-0878 1 Cleaning cloth for optics

12-0685 1 Carrying case Linebore B

## Complete system:

Weight: 32.0 kg [70.5 lbs]

WxHxD: 1260x550x220 mm [4.6x21.6x8.7"]

#### **Examples of accessories:**

12-0187 Magnetic bracket for D75 12-0282 Set of extension arms 03-1004 Thermal printer 12-0022 Laser transmitter D22 12-0455 Slide bracket Small 12-0543 Slide bracket Medium 12-0510 Slide bracket Large 03-0769 Aluminium extension beam L=500 mm

03-0770 1 Aluminium extension beam L=600 mm 03-0771 1 Aluminium extension beam L=1100 mm

Note: always check number of items included for each Part No. before ordering.















## Easy-Laser® E950-C Bore alignment

Part No: 12-0772

## Bore alignment with the highest reliability and precision

Easy-Laser® E950-C is primarily designed for diesel engines, compressors, gearboxes and similar applications. This system is much like the E950-A, but has for example instead the round detector E9. One of the brackets has a width of 25 mm [0.99"] to fit in narrow bearing journals. Measures bores diameter 80–500 mm [3.15–19.68"] as standard, and down to 50 mm [2.00"] with customized brackets.

Easy-Laser® E950 makes checking and aligning bearings and bearing journals easier thanks to wireless detectors and versatile brackets. A large colour display with clear graphics and software that guides the user through the entire measurement process contributes to simple operation. The system automatically calculates the bearing journals positions in relation to each other, both horizontally and vertically. You can then evaluate the results directly on-site with different calculation methods such as Best fit around zero and Waviness. It is also possible to analyse the different choices of reference points and set the offset and tolerance values.

A great feature is the check of ovality, for example, to analyse the wear rate. The measurement system takes care of all these complicated calculations for you. You measure and align both full and half bearing journals with equal simplicity. The wireless detector eliminates uncertain factors such as cable pull. All parts are designed for maximum accuracy and stability, and measure with a resolution of 0.001 mm [0.05 mils]. Measurement distance up to 40 m [130 feet]. Easy-Laser® E950 is suitable for use both in production and out in the field.

## Also straightness of shafts

With the systems, you can also measure the straightness of shafts, foundations, etc. without any additional accessories. With additional accessories extruder machines can also be measured.

#### A complete system contains:

12-0418	1	Display unit E-series E51
12-0075	1	Lacar transmitter D75

12-0759 1 Detector E9, 2-axis

12-0759 1 Detector E9,

12-0661 1 Offset hub for Laser transmitter

12-0384 1 Set of offset hub arms for diameters 100–500 mm

12-0154 1 Set of magnets for offset hub arms

12-0990 1 Adjustable magnet for offset hub arms

12-0768 1 Slide bracket, Width 25 mm, Min. Diameter 80 mm

12-0767 1 Rod adapter with built in target

12-0455 1 Slide bracket Small

12-0543 1 Slide bracket Medium

12-0510 1 Slide bracket Large

12-0013 1 Magnet base

12-0059 1 Set of rods (4x60 mm)

01-0938 2 Rods 30 mm

01-0873 4 Rods 120 mm

01-0044 2 Rods 240 mm

12-0495 1 Shoulder strap for Display unit

05-0685 1 Manual (Note: Refers to English manual)

03-0842 1 Measuring tape 5 m

03-0914 1 USB Memory stick with documentation

03-0822 1 USB Cable

03-1243 1 Battery charger (100-240 V AC)

03-0967 1 Hexagon wrench set

03-0878 1 Cleaning cloth for optics

12-0782 1 Carrying case

## Examples of accessories:

12-0553 1 Bore bracket adapter plate

12-0314 1 Detector arms Linebore

12-0752 1 Detector E7 reference detector

12-1336 1 Wireless unit

01-0777 1 Tube adapters (manufactured on request to specified diameter)

12-0792 1 Set of extension rods for Tube measurements

12-0187 1 Magnetic bracket for D75

12-0282 1 Set of extension arms

12-0580 1 Axial extension arms

03-1004 1 Thermal printer

12-0022 1 Laser transmitter D22

Note: always check number of items included for each Part No. before ordering.

## Complete system:

Weight: 14.3 kg [31.5 lbs]

WxHxD: 550x450x210 mm [21.6x17.7x8.3"]















## Easy-Laser® E950-D Bore alignment

Part No: 12-0954

## Bore alignment with the highest reliability and precision

Easy-Laser® E950-D is primarily designed for propeller shaft installations on ships with stern tubes, support bearings, gearboxes and engines.

Easy-Laser® E950 makes checking and aligning bearings and bearing journals easier thanks to wireless detectors and versatile brackets. A large colour display with clear graphics and software that guides the user through the entire measurement process contributes to simple operation. The system automatically calculates the bearing journals positions in relation to each other, both horizontally and vertically. You can then evaluate the results directly on-site with different calculation methods such as Best fit around zero and Waviness. It is also possible to analyse the different choices of reference points and set the offset and tolerance values.

A great feature is the check of ovality, for example, to analyse the wear rate. The measurement system takes care of all these complicated calculations for you. You measure and align both full and half bearing journals with equal simplicity. The wireless detector eliminates uncertain factors such as cable pull. All parts are designed for maximum accuracy and stability, and measure with a resolution of 0.001 mm [0.05 mils]. Measurement distance up to 40 m [130 feet]. Easy-Laser® E950 is suitable for use both in production and out in the field.

## Also straightness of shafts

With the systems, you can also measure the straightness of shafts, foundations, etc. without any additional accessories.

#### A complete system contains:

12-0418	1	Display unit E-series E51
40 0075	_	1 III D7F

Laser transmitter D75

12-0752 **Detector E7** 1

12-0436 1 Wireless unit

12-0074 Cable 2 m

Cable 5 m, extension 12-0108 1

12-0661 Offset hub for Laser transmitter

12-0707 Arm kit with magnets

12-0990 1 Adjustable magnet for offset hub arms

12-0282 **Extension arms Linebore** 

Self centering detector bracket for diameter 300-1200 mm 12-0341

12-0588 Large target E-series

12-0495 Shoulder strap for Display unit

05-0685 Manual (Note: Refers to English manual)

03-0842 Measuring tape 5 m

03-0914 1 **USB Memory stick with documentation** 

03-0822 **USB Cable** 

03-1243 Battery charger (100-240 V AC) 1

03-0792 Toolbox

03-0967 Hexagon wrench set 1 03-0878 Cleaning cloth for optics 12-0986 1 Carrying case Linebore D

Complete system:

Weight: 18.3 kg [40.3 lbs] WxHxD: 550x450x210 mm [21.6x17.7x8.3"]

#### **Examples of accessories:**

E30 Long Range laser 12-0823 12-0187

Magnetic bracket for D75 12-0282 Set of extension arms

03-1004 Thermal printer

12-0022 Laser transmitter D22

12-0455 Slide bracket Small 1

12-0543 Slide bracket Medium

12-0510 Slide bracket Large

Note: always check number of items included for each Part No. before ordering.
















## Easy-Laser® E930 Extruder alignment

Part No: 12-0788

#### For aligning extrusion machines

Easy-Laser® E930 is designed to measure straightness and pointing direction, primarily on extruder barrels. Another application can be hydraulic pipes for example. With the system, barrels with diameters from 50 mm to 250 mm can be measured. The actual measurable length depends on the diameter and type of barrel, therefore always consult your Easy-Laser representative for further discussions. The transmitter's laser beam can be compared to an absolutely straight and weightless ruler, that is to say a perfect starting point for precision measurement.

During the alignment procedure both detector and spindle are rotated, thus self calibrating the system. This way you can determine how the centre line of the spindle is, relative to the tube's centre at the inlet end.

## **Document your measurement results**

The detector's measurement value is transferred to the display unit wirelessly, which means that you can measure more freely. The measurement system has programs that guide you step-by-step, using clear graphics on a large 5.7" colour screen. You can also produce full documentation for your measurement job, with direct generation of PDF reports, and database programs for PC for example.

## Complete system with all the measuring programs

Easy-Laser® E930 is a complete system in itself, with laser transmitter, detector and display unit. You can also add other parts from our extensive range to build a system that suits your specific needs and requirements.

A. Detector with tube brackets mounted

B. The brackets are manufactured on order to specified diameter

C. Special brackets with metal points available on request.

#### A complete system contains:

- 12-0418 1 Display unit E-series E51
- 12-0075 1 Laser transmitter D75
- 12-0759 1 Detector E9
- 12-0074 1 Cable 2 m
- 12-0187 1 Bracket for D75 with magnets
- 01-0777 (1) Set of brackets for detector (Single barrel)
- 01-2222 (1) Set of brackets for detector (Dual barrel)
- 12-0792 1 Set of extension rods for detector (6.3 m)
- 12-0810 1 Target for extruder
- 12-0495 1 Shoulder strap for Display unit
- 05-0685 1 Manual (Note: Refers to English manual)
- 03-0842 1 Measuring tape 5 m
- 03-0914 1 USB Memory stick with documentation
- 03-0822 1 USB Cable
- 03-1243 1 Battery charger (100-240 V AC)
- 03-0967 1 Hexagon wrench set
- 03-0878 1 Cleaning cloth for optics
- 12-0811 1 Carrying case

(1)=Included depending on customer choice.

#### **Examples of accessories:**

12-0767 1 Rod adapter with built in target

12-0022 1 Laser transmitter D22

12-0553 1 Bore bracket adapter plate

12-0314 1 Detector arms Linebore


03-1004 1 Thermal printer

Note: always check number of items included for each Part No. before ordering.















#### Easy-Laser® E920 Geometric

Part No: 12-0771

#### Measurement system for all types of geometric measurement

This system can be used to carry out all the most common geometric measurements; straightness, flatness, squareness, plumb and level. Measurement is quick and precise. Displayed resolution is 0.001 mm [0.05 mils]. The laser transmitter is our well known big seller, the D22 with levelling table, strong magnetic feet, and a range of up to 40 m. The transmitter's laser beam can be compared to an absolutely straight and weightless ruler, that is to say a perfect starting point for precision measurement. The swivelling laser head gives a laser plane parallel to the measured object and can also angle the laser beam 90° to the sweep for squareness measurement.

The display unit has a large and clear 5.7" colour screen. The programs guide you step-by-step through the measuring process, which makes it easy even for inexperienced users. The system can provide full documentation, with direct generation of PDF reports, and database programs for PC for example. The detector transfers the measurement data to the display unit wirelessly, or by cable if required. The advantages of wireless are especially clear on mechanical constructions and objects where cables can snag or get in the way.

The most common method is to fix the laser transmitter to the measurement object using the mounting magnets, or mounting it on a tripod (accessory) to one side. A pin is also provided to secure the laser transmitter to a machine spindle or equivalent, to check straightness and spindle alignment for example.

Easy-Laser® E920 is a complete system in itself, with laser transmitter, detector and display unit. But it is also an excellent starting point for creating a measurement system that suits your specific needs and requirements, because all the measurement programs are included as standard! Add extra laser transmitters, measuring units and brackets as well as other accessories from the wide Easy-Laser® range. Now or in the future.

#### A complete system contains:

12-0418	1	Display unit E51
---------	---	------------------

12-0022 1 Laser transmitter D22 incl. tilt table

12-0752 1 Detector E7

12-0436 1 Wireless unit

12-0074 1 Cable 2 m

01-1333 1 Machine/magnet base pin for D22

12-0045 1 Magnet base with turnable head

12-0544 2 Targets for rough alignment

01-1165 1 Offset bracket

01-0043 6 Rods 60 mm

01-0873 6 Rods 120 mm

05-0685 1 Manual (Note: Refers to English manual)

 $03\text{-}0842 \quad 1 \quad \text{Measuring tape 5 m}$ 

03-0914 1 USB memory stick with documentation

03-0822 1 USB cable

03-1243 1 Battery charger (100-240 V AC)

03-0967 1 Hexagon wrench set

12-0495 1 Shoulder strap for Display unit

03-0878 1 Cleaning cloth for optics

12-0781 1 Carrying case

#### Complete system:

Weight: 12.3 kg [27.1 lbs]

WxHxD: 550x450x210 mm [21.6x17.7x8.3"]

#### Examples of accessories:

12-0759 1 Detector E9, 2-axis

12-1053 1 XT190 BTA

03-1004 1 Thermal printer

12-0455 1 Slide bracket Small

12-0543 1 Slide bracket Medium 12-0510 1 Slide bracket Large

12-0269 1 Tripod

12-1136 1 Angular prism

01-2232 1 Tripod adaptor for Angular prism

03-1406 1 Safety strap Bahco 3875-LY2

Note: always check number of items included for each Part No. before ordering.




















Sectional flatness program

### Easy-Laser® E915 Flange Spin

Part No: 12-0526

#### Measure flatness easily with spinning laser

This system is mainly for wind turbine tower producers who want to measure flatness of flanges. Similar applications can be e.g. slewing bearings. You can see the result as a true 3D image in the display unit directly after measuring. Then evaluate the result easily with different calculation settings, for example three point reference, best fit or all positive. This can also be done directly on site without having to stop to go to a PC with separate analysis programs, which was the case previously. This makes production much more efficient.

The system includes laser transmitter D23 Spin with power rotating head. This is how it works in brief: The laser beam from the transmitter rotates constantly and creates a reference plane over the entire measurement object. Measurements are performed quicker as you do not have to align the beam for each new measurement position. You place the detector at the desired measurement points and register the reading by a push of a button. In principle, one person can perform the measurement themselves. It is then possible to generate a PDF report containing graphs and measurement data directly from the measurement system's display unit. All information about the measurement object is documented.

Includes the sectional measurement flatness program\*. A tower section with diameter over 4 meters represents a significant weight. This weight causes the flanges to deform when the sections are manufactured. With sectional measurement program the flatness is measured in four sections which are mathematically merged into a full circle, which solves this measurement problem. The program also makes it possible to perform the complete measurement on ground. No climbing on ladders or skylift is therefore required. With traditional methods the operator has to work on hazardous high levels, and often more men are needed.

\*The sectional measurement flatness program is patented in Sweden, Germany, China and USA.

#### A complete system contains:

12-0418	1	Display unit	E-series E51
---------	---	--------------	--------------

12-0168 1 Laser transmitter D23 incl. tilt table

12-0509 1 Detector E5

12-0436 1 Wireless unit

12-0074 1 Cable 2 m

12-0108 1 Cable 5 m. extension

12-0321 1 Cable support

12-0544 3 Targets for rough alignment

12-0045 1 Magnet base with turnable head

01-0043 6 Rods 60 mm

01-0873 6 Rods 120 mm

12-0495 1 Shoulder strap for Display unit

05-0400 1 Manual (Note: Refers to English manual)

05-0545 1 Quick manual (Note: Refers to English manual)

03-0914 1 USB Memory stick with documentation

03-0822 1 USB Cable

03-1243 1 Battery charger (100-240 V AC)

03-0967 1 Hexagon wrench set

03-0878 1 Cleaning cloth for optics

12-0781 1 Carrying case

#### **Examples of accessories:**

03-1004 1 Thermal printer

12-0455 1 Slide bracket Small

12-0543 1 Slide bracket Medium

12-0510 1 Slide bracket Large

03-1406 1 Safety strap Bahco 3875-LY2

Note: always check number of items included for each Part No. before ordering.

#### Complete system:

Weight: 12.1 kg [26.7 lbs]

WxHxD: 550x450x210 mm [21.6x17.7x8.3"]

















#### Easy-Laser® E910 Flange

Part No: 12-0525

#### Measurement system for flange measurements

This system is mainly for wind turbine tower producers who want to measure flatness and parallelism of flanges. Similar applications can be e.g. slewing bearings. You can see the result as a true 3D image in the display unit directly after measuring. Then evaluate the result easily with different calculation settings, for example three point reference, best fit or all positive. This can also be done directly on site without having to stop to go to a PC with separate analysis programs, which was the case previously. This makes production much more efficient.

The system includes laser transmitter D22 with manual rotatable head, and with the option of deflecting the laser beam 90°. With a few more accessories the system can also be used to check the parallelism of the two tower flanges. In the measurement system's display unit it is possible to generate a PDF report containing graphs and measurement data. All information about the measurement object is documented.

Includes the sectional measurement flatness program\*. A tower section with diameter over 4 meters represents a significant weight. This weight causes the flanges to deform when the sections are manufactured. With sectional measurement program the flatness is measured in four sections which are mathematically merged into a full circle, which solves this measurement problem. The program also makes it possible to perform the complete measurement on ground. No climbing on ladders or skylift is therefore required. With traditional methods the operator has to work on hazardous high levels, and often more men are needed.

\*The sectional measurement flatness program is patented in Sweden, Germany, China and USA.

#### A complete system contains:

12-0418	1	Display unit E-series Es	51
---------	---	--------------------------	----

12-0022 1 Laser transmitter D22 incl. tilt table

12-0752 1 Detector E7

12-0436 1 Wireless unit

12-0074 1 Cable 2 m

12-0321 1 Cable support

12-0544 3 Targets for rough alignment

12-0045 1 Magnet base with turnable head

01-0043 6 Rods 60 mm

01-0873 6 Rods 120 mm

12-0495 1 Shoulder strap for Display unit

05-0400 1 Manual (Note: Refers to English manual)

05-0545 1 Quick manual (Note: Refers to English manual)

03-0842 1 Measuring tape 5 m

03-0914 1 USB Memory stick with documentation

03-0822 1 USB Cable

03-1243 1 Battery charger (100-240 V AC)

03-0967 1 Hexagon wrench set

03-0878 1 Cleaning cloth for optics

12-0781 1 Carrying case

#### **Examples of accessories:**

03-1004 1 Thermal printer

12-0455 1 Slide bracket Small

12-0543 1 Slide bracket Medium

12-0510 1 Slide bracket Large

12-0269 1 Tripod

12-1136 1 Angular prism

01-2232 1 Tripod adaptor for Angular prism

03-1406 1 Safety strap Bahco 3875-LY2

Note: always check number of items included for each Part No. before ordering.

#### Complete system:

Weight: 12.1 kg [26.7 lbs]

WxHxD: 550x450x210 mm [21.6x17.7x8.3"]

[ This page left blank intentionally ]

## **EASY-LASER®**

# **PARTS**

DISPLAY UNITS

Easy-Laser® Product overview





### XT12 Display unit

Part No: 12-1291

**Description:** Wireless display unit for Generation XT. Rugged design, shock proof, IP66 and IP67. Glove enabled touch screen. Water and dust proof connectors: USB A, USB C, HDMI, Charger.

**Note:** When ordering this item, Shoulder strap Part No. 12-0997 will automatically be added.

The XT12 is not approved for Ex/ATEX areas. Charger is not included.





#### XT12 Display unit with IR Camera

Part No: 12-1292

**Description:** Wireless display unit for Generation XT. Rugged design, shock proof, IP66 and IP67. Glove enabled touch screen. Water and dust proof connectors: USB A, USB C, HDMI, Charger.

With built-in thermal camera (IR).

**Note:** When ordering this item, Shoulder strap Part No. 12-0997 will automatically be added.

The XT12 is not approved for Ex/ATEX areas. Charger is not included.





### Removal of camera on XT12 Display unit

Part No: 12-1362

**Description:** If you for security reasons don't want a camera on your

XT12, please order 12-1291 + 12-1362 Removal of camera.

**Note:** Only possible for new purchases, no retrofit.





## ECOM Tab-Ex® 03 DZ1 – Display unit for Generation XT, Intrinsically safe, EX/ATEX approved

Part No: 12-1327

**Description:** Wireless display unit for Generation XT, especially the XT50-M/S Ex/ATEX approved shaft alignment measuring units. Rugged design, with glove enabled touch screen.

**Note:** For Zone 1/21 & DIV1, not mining. Charger is included. For more detailed information, please see the ecom web site: https://www.ecom-ex.com






#### Display unit E-series: E51

Part No: 12-0418

**Description:** Available in different measurement program configurations. Which programs are available depends on in which system the display unit is included. Connectors: USB A, USB B, Easy-Laser® equipment, Charger.

**Note:** Dust and splash guard for connectors open on picture to the right. The look of the display unit keyboard can vary depending on market. Charger is not included.





#### **Laser transmitter XT20**

Part No: 12-1272 (only transmitter)


**Part No:** 12-1293 (Kit in case, incl. Multibracket and charger/cables) **Description:** Laser transmitter XT20 can be used to measure flatness and straightness. The laser beam can sweep 360° with a measurement

distance of up to 20 metres [66'] in radius.

Can also be used with D- and E-series systems, but with limitations. Please also see *Technical specifications* at the end of this catalogue.

Note: The laser beam is used only for a 360° sweep.






#### **Laser transmitter XT22**

Part No: 12-1273 (only transmitter)

**Part No:** 12-1294 (Kit in case, incl. Multibracket and charger/cables) **Description:** Laser transmitter XT22 can be used to measure flatness, straightness, squareness and parallelism. The laser beam can sweep 360° with a measurement distance of up to 40 metres [132'] in radius. Can also be used with D- and E-series systems, but with limitations. Please also see *Technical specifications* at the end of this catalogue.

**Note:** Option A. The laser beam is used for a 360° sweep. Option B. The laser beam is pointed 90° to the sweep.






#### Laser transmitter D22 Swivel

Part No: 12-0022

**Description:** Laser transmitter D22 can be used to measure flatness, straightness, squareness and parallelism. The laser beam can sweep 360° with a measurement distance of up to 40 metres [130′] in radius. For specifications, please see *Technical specifications* at the end of this catalogue. Tilt table and tool kit included.

**Note:** Option A. The laser beam is used for a 360° sweep. Option B. The laser beam is angled at 90° to the sweep.





#### Laser transmitter D23 Spin

Part No: 12-0168

**Description:** Laser transmitter D23 has a motor driven, rotating head that gives a 360° laser plane. Because the laser beam sweeps across the surface you do not need to align the beam for every detector position. Tilt table and tool kit included.

Measurement distance up to 20 metres [65'] in radius. **Note:** A. The laser beam is used for a 360° sweep.





#### Laser transmitter D75

Part No: 12-0075

**Description:** For measuring straightness and spindle direction. M6 threads on ends and sides offer alternative mounting options. Mea-

surement distance 40 m [130'].

**Note:** With tilting screws for laser beam angle adjustment.





#### **Laser transmitter D25**

Part No: 12-0594

**Description:** For measuring straightness primarily in turbine applications. Measurement distance 40 m [130']. The laser beam can sweep 360°, and can be angled 90° to the sweep.

**Note:** Battery adaptor included. Brackets, arms and/or offset hub may also be needed, but are not included. See also 12-0706.

Option A. The laser beam is used for a 360° sweep. Option B. The laser beam is angled at 90° to the sweep.





#### Laser transmitter D25 with offset hub

Part No: 12-0706

**Description:** For measuring straightness primarily in turbine applications. Measurement distance 40 m [130']. The laser beam can be angled 90° to the sweep, within 0.01 mm/m [0.5 mils/INCH]. **Note:** Battery adaptor (not pictured) and offset hub included. Brackets/arms may also be needed, but are not included. See also 12-0594.

A. Transmitter mounted to point laser through hub.

B. Transmitter mounted to point laser in opposite direction.





#### **Laser transmitter E30 Long Range**

Part No: 12-0823

**Description:** For measuring straightness on long distances. Measurement distance 100 m [328'] with a 20 mm PSD, >200 m [656'] with 30 mm PSD. M6 threads on front and bottom offer alternative mounting options. Built-in rechargeable battery and Oled display.

**Note:** Coordinate table or tilt table needed for accurate functionality. No charger or bracketing included (compare with Part No. 12-0858).





#### Laser transmitter E30 Long Range, with tilt table

Part No: 12-0858

**Description:** For measuring straightness on long distances. Measurement distance 100 m [328'] with a 20 mm PSD, >200 m [656'] with 30 mm PSD. M6 threads on front and bottom offer alternative mounting options. Built-in rechargeable battery and Oled display.

**Note:** With tilt table (12-0864), which can be used with magnets or mounted on tripod, Battery charger 100–240 V AC (03-1243), USB memory stick with documentation, and Carrying case (12-0872).





#### Laser transmitter for sheave alignment systems

Part No: 12-1325

**Description:** Laser transmitter producing a laser line parallel to the

object it is mounted to.

**Note:** Only transmitter as pictured, no targets included. (Complete

system, see Part No. 12-1053 and 12-1332.)





### **Detector XT9, 2-axis PSD**

Part No: 12-1350

**Description:** Detector diameter 44 mm [1.73"]. 2 axis PSD, 20x20 mm [0.79x0.79"]. Built-in 360° electronic inclinometer. Built-in wireless communication and rechargeable battery. Charger connector on one end. Mounting threads on both ends for suitable brackets (e.g. 12-0767 and 12-1351).

Note: Make sure you have a suitable bracket!





#### **Detector E9, 2-axis PSD**

Part No: 12-0759

**Description:** Detector diameter 44 mm [1.73"]. 2 axis PSD, 20x20 mm [0.79x0.79"]. Built-in 360° electronic inclinometer. Built-in wireless communication and rechargeable battery. There is also a connector on the back side for standard "red cable" (charging and data transfer). Mounting threads on both ends, for tube adapters (01-0777) or other

suitable brackets (e.g. 12-0767 and 12-0553). **Note:** Make sure you have a suitable bracket!





#### **Detector E7**

Part No: 12-0752

**Description:** Detector for the E-series. 2 axis PSD, 20x20 mm [0.79"x0.79"]. Built-in 360° electronic inclinometer. Two connectors for making it possible to connect two detectors or more in series. Normally mounted on rods, but has many additional mounting possibilities thanks to threads on two sides.

**Note:** Optimised for fixed point laser/does not detect a spinning laser.





#### **Detector E5**

Part No: 12-0509

**Description:** Detector for the E-series. 2 axis PSD, 20x20 mm [0.79"x0.79"]. Built-in 360° electronic inclinometer. Two connectors for making it possible to connect two detectors or more in series. Normally mounted on rods, but has many additional mounting possibilities thanks to threads on two sides.

**Note:** With Dual Detection Technology, making it possible to read both fixed point laser and spinning laser, but is optimised for spinning laser.





#### **Detector E3**

Part No: 12-0799

**Description:** Detector for the E-series. 2 axis PSD, 30x30 mm [1.18"x1.18"]. Built-in wireless communication. Battery status indicator. Built-in 360° electronic inclinometer. One connector on top side. Normally mounted on rods, but also has additional mounting threads on back side.

**Note:** Target/Dust cover for PSD included. Does not detect a spinning laser.





## **XT & E-series wireless Detector for belt alignment**

**Part No:** 12-1054

**Description:** Detector that reads off the sheaves position in two directions (horizontal+vertical) at the same time. With built-in display showing offset and angular values. Note: Laser transmitter also needed. **Note:** Also for wireless connection to separate display units E51 and E52 which have the BTA digital program. Or connect it to the XT Alignment App on your iOS/Android display, or Easy-Laser XT12/XT11. A. Super magnets x 4, for attachment to sheave side.





## **Digital Precision Level E290**


**Part No: 12-0846** 

Description: Digital precision level. Built-in OLED display and recharge-

able battery.

Note: For complete kit, see Part No. 12-0857 below.





## Digital Precision Level E290, complete kit

Part No: 12-0857

**Description:** Digital precision level (12-0846), complete kit with Battery charger 100–240 V AC (03-1243), safety strap (12-0915) and USB

memory stick with documentation (03-0914). **Note:** Delivered in plastic case (12-0873).

MEASURING UNITS

Easy-Laser® Product overview





### Measuring unit XT40-M, line laser, PSD 30 mm

Part No: 12-0943

**Description:** Laser diode and PSD detector in one housing. Built-in wireless communication. OLED display shows battery status and angle of the unit on shaft. Built-in electronic 360° inclinometer. For shaft alignment. 1 axis PSD 30 mm [1.18"].

Note: To be used in pair with S unit 12-0944. XT-series measuring unit.





## Measuring unit XT40-S, line laser, PSD 30 mm

Part No: 12-0944

**Description:** Laser diode and PSD detector in one housing. Built-in wireless communication. OLED display shows battery status and angle of the unit on shaft. Built-in electronic 360° inclinometer. For shaft alignment. 1 axis PSD 30 mm [1.18"].

**Note:** To be used in pair with M unit 12-0943. XT-series measuring

unit.





### Measuring unit XT60-M, dot laser, PSD 20x20 mm

Part No: 12-1028

**Description:** Laser diode and PSD detector in one housing. Built-in wireless communication. OLED display shows battery status and angle of the unit on shaft. Built-in electronic 360° inclinometer. For shaft alignment. 1 axis PSD 20x20 mm [0.79x0.79"].

**Note:** To be used in pair with S unit 12-1029. XT-series measuring unit.





#### Measuring unit XT60-S, dot laser, PSD 20x20 mm

Part No: 12-1029

**Description:** Laser diode and PSD detector in one housing. Built-in wireless communication. OLED display shows battery status and angle of the unit on shaft. Built-in electronic 360° inclinometer. For shaft alignment. 1 axis PSD 20x20 mm [0.79x0.79"].

**Note:** To be used in pair with M unit 12-1028. XT-series measuring unit.





## Measuring unit XT50-M, EX/ATEX, dot laser, PSD 20x20 mm

Part No: 12-1026

**Description:** Laser diode and PSD detector in one housing. Built-in wireless communication. OLED display shows battery status and angle of the unit on shaft. Built-in electronic 360° inclinometer. For shaft alignment. 1 axis PSD 20x20 mm [0.79x0.79"].

**Note:** Intrinsically safe design. To be used in pair with S unit 12-1027. XT-series measuring unit. Please also read the Technical specifications!





## Measuring unit XT50-S, Ex/ATEX, dot laser, PSD 20x20 mm

Part No: 12-1027

**Description:** Laser diode and PSD detector in one housing. Built-in wireless communication. OLED display shows battery status and angle of the unit on shaft. Built-in electronic 360° inclinometer. For shaft alignment. 1 axis PSD 20x20 mm [0.79x0.79"].

**Note:** Intrinsically safe design. To be used in pair with M unit 12-1026. XT-series measuring unit. Please also read the Technical specifications!

MEASURING UNITS

Easy-Laser® Product overview





## Measuring unit XT70-M, dot laser, PSD 20x20 mm, 2-axis

Part No: 12-1045

**Description:** Laser diode and PSD detector in one housing. Built-in wireless communication. OLED display shows battery status and angle of the unit on shaft. Built-in electronic 360° inclinometer. For shaft

alignment. 2 axis PSD 20x20 mm [0.79x0.79"].

Note: To be used in pair with S unit 12-1046, or as a separate detector

for GEO-programs. XT-series measuring unit.





## Measuring unit XT70-S, dot laser, PSD 20x20 mm, 2-axis


Part No: 12-1046

**Description:** Laser diode and PSD detector in one housing. Built-in wireless communication. OLED display shows battery status and angle of the unit on shaft. Built-in electronic 360° inclinometer. For shaft

alignment. 2 axis PSD 20x20 mm [0.79x0.79"].

Note: To be used in pair with M unit 12-1045. XT-series measuring unit.





## Bracket accessory kit in box

Part No: 12-1378

**Description:** Includes 2 magnet bases (12-0013), 2 offset brackets (12-1008), 2 extension chains 12-0128), 4 rods 120 mm (01-0873), 1 box

with padding (03-1697).

**Note:** This box/kit fits in the case for XT440, beneath display unit XT12. **Note 1:** The box itself is included as standard with XT770 and XT660, but with different content. Please see each system for more info. **Note 2:** With cutout to fit also 2 pcs Magnetic bracket 12-1147.





#### Magnet base

Part No: 12-0013

**Description:** Versatile magnet base with On/Off function and many

optional rod mounting possibilities. Holding power 800N.

Note: Three sides are magnetic. \*For use with XT-series offset bracket

12-1008 is also needed.





### Magnet base with turnable head

Part No: 12-0045

**Description:** Versatile magnet base with On/Off function and 360°

turnable head with two rod mounting possibilities.

Note: \*For use with XT-series offset bracket 12-1008 is also needed.





### Magnet base with turnable head

Part No: 12-1133

**Description:** Versatile magnet base with On/Off function and 360° turnable head with two rod mounting possibilities, for both C–C40 mm and C–C56 mm. It has a screw and washer with which you can lock the top rotation, and therefore still use it for jobs like shaft alignment.

Note: -





#### Rotating detector bracket for rods

Part No: 12-0169

Description: Allows for 360° swivel.

Note: -





#### Rotating detector bracket for rods

Part No: 12-1209

Description: Allows for 360° swivel.





## Magnet bracket long, with turnable head

Part No: 12-1210

**Description:** Allows for 360° swivel.

Note: -





### Magnet bracket short, with turnable head

Part No: 12-1211

**Description:** Allows for 360° swivel.

Note: -





#### **Detector bracket for centering on wire position**

Part No: 12-1262

**Description:** Mainly for sawmill applications.

Note: -





#### Radial support for magnet base

Part No: 12-0508

**Description:** Can be used for supporting the magnet base in many different ways. Makes it easier to position the detector correctly. Espe-

cially useful on flywheels.

Note: -





#### Pointing bracket on magnet base

Part No: 12-0583

Description: For wind tower flanges. Makes it possible to measure

near the edge of a surface.

Note: Probe does not touch surface. Rods and detector not included.



## Extension for set square 12-1087, 295 mm

**Part No:** 12-1123

**Description:** Extension plate for set

square Part. No. 12-1087.

Note: -



## Extension for set square 12-1087, 430 mm

Part No: 12-1124

**Description:** Extension plate for set

square Part. No. 12-1087.



## Bracket (Set square) for transmitter

Part No: 12-0503 Description: -

Note: Mainly for sawmill applica-

tions



## Magnetic brackets and rods, kit

Part No: 12-1017

**Description:** 2 magnetic brackets and 4pcs rods 120 mm [4.72"] in

small case.
Note: -





#### Magnetic bracket

Part No: 12-1147

Description: For axial mounting on flanges or shafts. With M6 screws

working as radial supports, and four super magnets.

Note1: For rod C-C 40 and 56 mm.

Note2: Older design of bracket on rightmost picture.





#### Flange clamping bracket

Part No: 12-1373

**Description:** For mounting on flange edge. Maximum clamping width 27 mm [1.06"]. With locking knob, radial supports, and four super

magnets.

Note1: For rod C-C 56 mm.





#### V-bracket with chain

Part No: 12-0016

**Description:** For mounting on shaft or coupling. The V-bracket fits shafts with diameters 20–450 mm [0.8–17.7"]. The standard chain included can be used on shaft diameters up to 150 mm [6"].

Bracket width 18 mm [0.7"].

Note: Extension chains available for shafts larger than diameter 150

mm [6"]. Does not fit the XT series.





#### V-bracket with chain and rods 120 mm

Part No: 12-0963

**Description:** For mounting on shaft or coupling. The V-bracket fits shafts with diameters 20–450 mm [0.8–17.7"]. The standard chain included can be used on shaft diameters up to 150 mm [6"]. Chain is

pre-mounted. Bracket width 18 mm [0.7"].

**Note:** Only for XT series. 2 pcs rods 120 mm [4.72"] included. Extension chains available [Part No. 12-1060] for shafts larger than diameter

150 mm [6"].





#### V-bracket with chain and rods 75 mm


Part No: 12-1366

**Description:** For mounting on shaft or coupling. The V-bracket fits shafts with diameters 20–450 mm [0.8–17.7"]. The standard chain included can be used on shaft diameters up to 150 mm [6"]. Chain is

pre-mounted. Bracket width 18 mm [0.7"].

**Note:** Only for XT series. 2 pcs rods 75 mm [2.95"] included. Extension chains available [Part No. 12-1060] for shafts larger than diameter 150 mm [6"].






### V-bracket with stainless steel chain and rods

Part No: 12-1040

**Description:** For mounting on shaft or coupling. The V-bracket fits shafts with diameters 20–450 mm [0.8–17.7"]. The standard chain included can be used on shaft diameters up to 150 mm [6"]. Chain is pre-mounted. Bracket width 18 mm [0.7"].

**Note:** Only for XT series. 2 pcs rods 120 mm [4.72"] included. Extension chains available [Part No. 12-1038] for shafts larger than diameter 150 mm [6"].





#### Standard chains

Part No: 12-0625

**Description:** Standard chains for shaft alignment brackets.

Note: 2 pcs. Includes plastic box.





#### Extension chain, set

Part No: 12-0128

Description: For standard chains. For shaft diameters 150–450 mm

[5.9-17.7"].

Note: 2 pcs. included, with plastic box.





#### Extension chain, set

Part No: 12-1060

Description: For standard chains. For shaft diameters 150–450 mm

[5.9-17.7"].

Note: 2 pcs. included, with plastic box.





#### Extension chain stainless steel, set

Part No: 12-1038

Description: For extension of stainless steel chains. For shaft diam-

eters 150–450 mm [5.9–17.7"].

Note: 2 pcs. included, with plastic box.





#### Thin chain bracket

Part No: 12-1012

**Description:** For use for example when the space between coupling and machine is limited. Width: 12 mm [0.5"]. For shaft diameters

20-450 mm [0.8-17.7"].

Note: Includes thin chain and tightening tool. Photos show old thread-

ings, but are otherwise correct.



## Shaft bracket with chain, stainless steel

Part No: 12-0337

**Description:** Bracket mainly for use with the D550 system which has a rod C–C of 70 mm. Pre-mounted chain and rods. For shaft diameters 20–150 mm [0.8–5.9"].

Note: -



## Extension chain, stainless steel

Part No: 12-0363

**Description:** For use together with 12-0337. For shaft diameters 150–320 mm [5.9–12.6"]. Two extension

chains: -500 mm [-19.6"]

Note: 1 pc. included. Does not fit

with standard chains.





#### Offset bracket

Part No: 01-1165

**Description:** Allows axial displacement between measuring units to be able to rotate past projecting machine parts. For both E and D series. **Note:** 2 screws M6x16 also needed (Part No. 03-0045). V-bracket and

rods not included.





#### Offset bracket

Part No: 12-1008

**Description:** Allows axial displacement between measuring units to be able to rotate past projecting machine parts. Also works as a converter between rod C–C 40 mm (D and E series) and C–C 56 mm (XT series)

so older brackets can be used.

Note: 2 screws M6x16 included.





#### DM Bracket, complete set

Part No: 12-1130

**Description:** For measuring dynamic movements. Includes 2 pcs DM brackets, 4 pcs mounting plates, 2 pcs bolt mounting plates, glue Locktite 4070, 4 pcs screw M8x20, hexagon wrench 6 mm, Quick Manual. Delivered in plastic case.

Note: -





#### **DM Bracket**

Part No: 12-1125

**Description:** For measuring dynamic movements. For complete set,

please see Part No. 12-1130 instead. **Note:** Measuring unit not included.





#### **DM Bracket extension**

Part No: 12-1129

Description: Extension for bracket 12-1125. For complete set, please

see Part No. 12-1130 instead.

Note: Parts included as pictured on leftmost picture.





### **Sliding bracket**

Part No: 12-1010

**Description:** For shaft alignment. The spherical feet can be placed in two different positions for adaption to small or large shaft diameters.

Min./Max. diameters 90-600 mm [3.5-23.6"].

Used when the shafts cannot be rotated. Mounted with standard

chains (not included).

Note: Photos show old threadings, but are otherwise correct.





#### Sliding bracket with magnets

Part No: 12-0303

**Description:** The spherical feet can be placed in two different positions for adaption to small or large shaft diameters. With attachment magnets. Can also be mounted with standard chains (not included).

Note: -





### Sliding bracket with magnets and probe

Part No: 12-0138

**Description:** For plumb measurement of e.g. generator shafts. The spherical feet can be placed in two different positions for adaption to small or large shaft diameters. With attachment magnets. Can also be mounted with standard chains (not included).

Note: -





#### Sliding bracket with turnable head

Part No: 12-0137

**Description:** For roll parallelism measurement. The spherical feet can be placed in two different positions for adaption to small or large roll diameters. With attachment magnets. Can also be mounted with standard chains (not included).

Note: -





#### Cardan bracket set

Part No: 12-1151

 $\textbf{Description:} \ \textbf{For alignment of cardan/offset mounted machines.} \ \textbf{Offset}$ 

range 0-900 mm.

**Note:** Delivered in plastic carrying case. For XT- and E-series. Please see rightmost picture for example of attachment for E or XT unit. Weight: 8 kg [17.6 lbs], WxHxD: 500x380x140 [19.7x15.0x5.5"]



Rod, 30 mm [1.18"] Part No: 01-0938 Description: Stainless steel. Diameter 10 mm. Extendable. Note: 1 pcs.



Rods, 60 mm [2.36"]

Part No: 12-0059

**Description:** Stainless steel. Diameter 10 mm. Extendable. Plastic holder included.

Note: 4 pcs.



Rods, 75 mm [2.95"]

Part No: 12-1161

**Description:** Stainless steel. Diameter 10 mm. Extendable. Plastic holder included.

Note: 4 pcs.



## Rods, 120 mm [4.72"]

Part No: 12-0987

**Description:** Stainless steel. Diameter 10 mm. Extendable. Plastic holder included.

Note: 4 pcs.



### Rods, 120 mm [4.72"]

Part No: 12-0324

**Description:** Stainless steel. Diameter 10 mm. Extendable. Plastic holder included.

Note: 8 pcs.



#### Rods, 240 mm [9.44"]

Part No: 12-0060

**Description:** Stainless steel. Diameter 10 mm. Extendable. Plastic holder included.

Note: 4 pcs.





## Tube adapters for detector E9/XT9

Part No: 01-0777

**Description:** Adapters mainly for mounting of detector when used for

extruder measurements. For use in single barrels.

**Note:** Manufactured on request to your specified diameter from 50 mm [1.97"] up to 250 mm [9.84"]. 2 pcs included. Includes items as

pictured leftmost.





## Tube adapters for detector E9/XT9, for dual barrels

Part No: 01-2222

**Description:** Adapters mainly for mounting of detector when used for extruder measurements. These adapters are designed specifically for

Note: Manufactured on request to your specified diameter from 50 mm [1.97"] up to 250 mm [9.84"]. 2 pcs included. Includes items as

pictured leftmost.





### Tube adapters with metal points

Part No: 12-1346

**Description:** Adapters mainly for mounting of detector E9/XT9 and used for extruder measurements. With metal points of your choice

and adapted for your application.

Note: Manufactured on request to your specified diameter from 50

mm [1.97"] up to 250 mm [9.84"]. 2 pcs included.





## Extension Kit for precision level for large diameters

Part No: 12-0901

Description: For using the E290 or XT290 Precision Level on diameters

55-800 mm [2.16-31.50"].

Note: Includes 2 legs, 4 magnets and mounting screws.





## Slide bracket Width 25 mm [0.99"]

Part No: 12-0768

**Description:** Bracket for straightness measurement of bores with a width of down to 25 mm [0.99"]. For bores diam. 80– mm [3.15"–]. Magnetic feet holds the bracket safely also upside down. With positioning guide (extended on picture to the right). Guide can be removed. **Note:** Designed to fit with rod adapter 12-0767 and detectors E9/XT9. If used with other detectors and adapters, it is those which determines the minimum measurable diameter.





#### Rod adapter with built in target C-C 40 mm

Part No: 12-0767

**Description:** For detector E9 and XT9. With slidable target. For mounting of the detector on regular rods with 40 mm center-to-center distance. Can be used on Slide bracket 12-0768 or any other suitable bracket

Note: Detector not included.





### Rod adapter with built in target C-C 56 mm

Part No: 12-1351

**Description:** For detector E9 and XT9. With slidable target. For mounting of the detector on regular rods with 56 mm center-to-center

distance. Note: Detector not included.



#### Slide bracket Small

Part No: 12-0455

**Description:** For bore straightness measurement. With magnetic feet.

**Note:** For information on measurable diameters, please see section *Technical specifications*.



#### Slide bracket Medium

Part No: 12-0543

**Description:** For bore straightness measurement. With magnetic feet.

**Note:** For information on measurable diameters, please see section *Technical specifications*.



#### Slide bracket Large

Part No: 12-0510

**Description:** For bore straightness measurement. With magnetic feet.

**Note:** For information on measurable diameters, please see section *Technical specifications*.



## Small magnet base with turnable head

Part No: 12-0696

**Description:** With On/Off function and 360° turnable head. Removable rotation lock screw included.

Note: Includes 2 rods 75 mm

[2.95"].





## **Axial support for Slide bracket**

Part No: 12-1368

**Description:** For mounting on slide brackets Small, Medium and Large. Includes 2 screws for the countersunk holes as pictured. Slide bracket not included.

**Note:** For information on measures, please see section *Technical specifications*.



Foot set for linebore arms

Part No: 12-0134

**Description:** For use with linebore detector arms. Included in 12-0314.

Note: -



## Foot set for diameter 120–150 mm

Part No: 12-0143

**Description:** For use with linebore detector 12-0032 and bracket 12-0553. Included in 12-0314.

Note: -





#### Bore bracket adapter plate

Part No: 12-0553

Description: Bracket for use with detector D5, D157 or E9.

Note: Detector and arm set not included. Suitable Arm set is Part No.

12-0314. Detector D5 and D157 is discontinued.





#### **Detector arms Linebore**

Part No: 12-0314

**Description:** For bracket 12-0553. For bores diameter 120–500 mm [4.72–19.68"], with the possibility to use the longest three arms as extension arms.

Note: Also includes Foot set 12-0134 and 12-0143 (the rightmost

picture).





#### Offset hub with counterlock

Part No: 12-0661

**Description:** For laser transmitter D75, Part No. 12-0075.

Note: -





#### Offset hub with counterlock and tilt function

Part No: 12-0537

**Description:** For laser transmitter D25, Part No. 12-0594.

Note: -





## Offset hub with counterlock and tilt function for transmitter E30

Part No: 12-0828

Description: For laser transmitter E30, Part No. 12-0823.



#### Arm kit with magnets

Part No: 12-0707

**Description:** For offset hub 12-0661 and 12-0537. Arms for bores diameter 100–500 mm [3.94–19.68"].

Note: -



#### Offset hub arms

Part No: 12-0384

**Description:** For offset hub 12-0661 and 12-0537. For bores diameter 100–500 mm [3.94–19.68"]. Also

includes centering plug.

Note: -



#### **Extension arms Linebore**

Part No: 12-0282

**Description:** For extension of the Linebore offset hub arms. For bores diameter 500–1000 mm [19.68–

39.36"] **Note:** -



## Magnets for offset hub

arms Part No: 12-0154

Description: For arms 12-0384.

With plastic holder.

Note: -





#### Adjustable magnet for offset hub arms

Part No: 12-0990

**Description:** To use when the mounting surfaces for the hub arms aren't in same level. Adjustable 0–14mm [0–0.55"] compared to stan-

dard magnet level.

Note: -





#### **Axial extension arms, Linebore**

Part No: 12-0580

Description: Used for making it possible to reach the Linebore detec-

tor from the same side of the bore as the transmitter.

Note: 3 arms with magnets etc. as pictured on the left picture.





#### Laser transmitter bracket Turbine/Bore alignment

Part No: 12-0385

**Description:** For use with offset hub 12-0661 and laser transmitter D75. Included in system E950-B, E960-A, E960-B. 2 aluminium beams,

length 1100 mm and 500 mm.

Note: Transmitter and hub not included.






#### **Rod bracket for laser D75**

Part No: 12-0149

**Description:** For mounting of laser transmitter D75 on standard rods. Laser beam can point from the bracket or through the bracket.





#### **Bracket for laser D75**


Part No: 12-0187

**Description:** To use on shaft ends, flywheels etc. Laser beam can point

from the bracket or through the bracket.

Note: A. 3 super magnets.






#### Multi bracket for XT laser transmitters

Part No: 12-1275

**Description:** For more mounting possibilities of the laser transmitters. **Note:** For XT20 and XT22. The set of mounting screws for XT laser-transmitter (Part No. 12-1300) might also be needed if you do not already have it. Please see the *Technical specification* pages for example

of use.





### Adapter plate for tilt table to magnet base

Part No: 12-0874

**Description:** For mounting D22 laser transmitter on a magnet base, or a magnet base with turnable head. Possible to turn unit 90° on bracket

(mount in holes A instead).

Note: 4 screws M6x16 also needed (not included).

A: C-C=40 mm B: C-C=106 mm





#### Tilt table

Part No: 12-0110

**Description:** Tilt table mainly for transmitter D26, D22 and D23, but can also be used together with transmitter D75, for example.

Note: Tool kit 12-0622 is not included (as before) but instead has to be

ordered separately.





#### Tilt table, turnable


Part No: 12-0864

**Description:** Tilt table mainly for transmitter E30 Long Range. For fine adjustment of horizontal and vertical angle. Can be used with magnets

or mounted on tripod.

Note: -





#### Tool kit for tilt table

Part No: 12-0622

**Description:** Tool kit for Tilt table Part No. 12-0110. Safety strap screw (01-1402), Machine/magnet base pin (01-0139), set of Hexagon wrenches, Rod tightening tool (03-0048), Feet with flat points (3 pcs). **Note:** Safety strap is separate part. Safety regulations differ from coun-

try to country.





## Magnet base pin for D22 and D26, short

Part No: 01-0139

Description: Clamping pin diameter 16 mm[0.63"], clamping length 30

mm [1.18"].

Note: This pin is included in the tilt table tool kit.





### Magnet base pin for D22/D26/XT20/XT22, Long

Part No: 01-1333

**Description:** Clamping pin diameter 20 mm[0.79"], clamping length 60

mm [2.36"].

Note: Also for laser transmitters XT20/XT22 when used with Multi

bracket Part No. 12-1275.





### Bracket with rotatable bore probe, XT-series

Part No: 12-1277

**Description:** For bore measurements. Smallest diameter 220 mm [8.67"] when mounted as pictured. This is just one example of how the bracket can be assembled, and other magnetic or non-magnetic brackets with C–C 56 mm can also be used. The detector unit can be turned, allowing the laser beam to pass through the hole in the bracket and hit the PSD. Includes 2 rods 30 mm and 4 rods 60 mm (not pictured).

Note: Items marked with X is not included.





#### Bracket with rotatable bore probe, E-series

Part No: 12-1282

**Description:** For bore measurements. Smallest diameter 170 mm [6.70"] when mounted as pictured. This is just one example of how the bracket can be assembled, and other magnetic or non-magnetic brackets with C–C 40 mm can also be used. The detector unit can be turned, allowing the laser beam to pass through the hole in the bracket and hit the PSD. Includes 2 rods 30 mm and 4 rods 60 mm (not pictured).

**Note:** Items marked with X is *not* included.





## Self centering bracket, Linebore

Part No: 12-0341

**Description:** For sterntube measurement. Smallest diameter 300 mm [11.81"]. Includes extension beams and rods for diameters up to 1200

mm [47.24"].

Note: Includes items as pictured leftmost. No detector included.






## Detector bracket "short stroke", Turbine

Part No: 12-0438

**Description:** With slidable beam. Makes it possible to reach several measurement positions without moving the entire bracket. One aluminium beam 1100 and one 600 mm included. For diameter 150–1700mm [5.9–66.9"].

Note: Detector not included.





## Detector bracket "long stroke", Turbine

Part No: 12-0715

Description: Measures diameters 200-1700 mm [7.8-67"] as stan-

dard. Stroke: 60 mm [2.36"].

Two aluminium beams 1100 mm [43.3"], one 600 mm [23.6"], rods 5x240 mm [9.44"], 4x120 mm [4.72"], 2x60 mm [2.36"], 1x30 mm [1.18"] included. For diameter 200–1700mm [7.8–66.9"].

Note: Detector not included.





#### **Tube bracket**

Part No: 12-0814

Description: Included with Part No. 12-0438 and 12-0715.

Note: -



## Aluminium beam, 500 mm [19.68"]

Part No: 03-0769
Description: Cross section
measures 44x44 mm [1.73x1.73"].

Note: -



## Aluminium beam, 600 mm [23.62"]

**Part No:** 03-0770

**Description:** Cross section measures 44x44 mm [1.73x1.73"].

Note: -



## Aluminium beam, 1100 mm [43.31"]

Part No: 03-0771

**Description:** Cross section

measures 44x44 mm [1.73x1.73"].

Note: -



## Connecting strip (with set screws)

Part No: 03-0633

Description: Used to extend the

aluminium beams.

**Note:** 1 pc. It is recommended to use minimum three connecting

strips (three sides).



### **Ball top probe**

Part No: 12-0439

**Description:** Probe for turbine

measurement. **Note:** -



### Short ball top probe

Part No: 12-0490

**Description:** Probe for turbine

measurement.

Note: -



## Measuring probe Ruby diameter 5 mm

Part No: 12-0805

**Description:** Probe for turbine measurement. With ruby top.

Note: -



## Measuring probe Ruby diameter 2.5 mm

Part No: 12-0801

**Description:** Probe for turbine measurement. With ruby top.



Gauge block Part No: 03-1291

**Description:** For use mainly in turbine applications. Nominal measure 8 mm [size of block 30x8x9 mm].

Note: -



## Measuring probe, cylindrical

Part No: 12-1047

**Description:** For use in turbine

applications.
Note: -





### **Centering target, Turbine**

Part No: 12-0443

Description: For rough alignment of laser beam. 1 m + 0.5 m exten-

sion. Note: -





#### Tripod

Part No: 12-0269


**Description:** For use with Laser transmitter and Angular prism.

Min./Max. height 500-2730 mm [ 19.7-107.5"]

Note: Includes tripod head Part No. 03-1338, with 5/8-11 UNC

threads.





#### **Parallelity kit**

Part No: 12-0203

**Description:** For parallelism measurement of rolls. Includes Magnet base 12-0045, Sliding bracket 12-0137, Sliding table 12-0202, 2 x Large

target base line. Delivered in plastic case.

Note: Detector not included.





### Sliding table for tripod

Part No: 12-0202

**Description:** Sliding table to mount on a tripod. For laser transmitters and angular prism. Mounted using 5/8-11 UNC thread.

Allows for 150 mm [5.9"] slide of the unit, for example to point the laser beam to a detector on a rod or flange without moving the tripod.

**Note:** Also for laser transmitters XT20/XT22 when used with Multi

bracket Part No. 12-1275.





#### Angular prism Mk2

Part No: 12-1352

**Description:** Angular prism with built-in penta prism which deflects the beam 90°. With the rotatable angular prism you can reach a detector at any height on a flange or a roll when measuring parallelity. With fine turning mechanism.

**Note:** Includes prism and bracket for mounting a detector/measuring unit at the front, as pictured to the right. Angular prism rod C–C 40 mm. Bracket for detector rod C–C 40 mm and 56 mm.





## Angular prism Mk2, kit for E-series

Part No: 12-1363

Description: Angular prism kit in rugged carrying case.

Note: Carrying case plus items as pictured leftmost included (prism, bracket for detector unit, laser transmitter alignment targets 12-1188 (small hole) 12-1261 (large hole), magnet base, sliding table for magnet base, 4 pcs rods 120 mm [4.72"]), Quick Guide. Interior precut to also fit 1 pc 12-0202 (accessory). Case measures WxHxD: 375x300x180 [14.7x11.8x7.1"], kit weight 5.0 kg [11.0 lbs].





#### Angular prism Mk2, kit for XT-series

Part No: 12-1376

**Description:** Angular prism kit in rugged carrying case.

Note: Carrying case plus items as pictured leftmost included (prism, bracket for detector unit, XT22 laser transmitter alignment target (12-1379), magnet base, sliding table for magnet base, 4 pcs rods 120 mm [4.72"]), Quick Guide. Interior precut to also fit 1 pc 12-0202 (accessory). Case measures WxHxD: 375x300x180 [14.7x11.8x7.1"], kit

weight 5.0 kg [11.0 lbs].





## Target for XT22

Part No: 12-1379

Description: Target to place on laser transmitter XT22 when pre-align-

ing the Angular Prism Mk2.

Note: Included as standard with 12-1376.





#### Tripod adaptor for Angular prism

Part No: 01-2232

Description: To be used for mounting of Angular prism on tripod. Pref-

erably on sliding table 12-0202 as pictured.

Note: Item as pictured leftmost included. Can be used for other applications if suitable. Rod C-C 40 and 56 mm. Note that rightmost picture

shows old design of prism.





### Sliding table for magnet base

Part No: 12-1200

Description: For precision adjustment, mainly of angular prism. For

rod C-C 40 mm. To be mounted on magnet base 12-0013. Note: Includes 4 pcs screws. Magnet base not included.





#### Target 100x100 mm

Part No: 12-0544

Description: Rough alignment target for flatness measurement. Adjustable height (to align with either D22 or D23) and magnet base.






### Target D550 cardan

Part No: 12-0402

**Description:** Large target for use when aligning cardan/offset mounted machines. The target clamps onto the front of the D550 measuring

Note: -





#### **Large target E-series**

Part No: 12-0588

**Description:** The target is mounted with magnet attachment onto the front of detectors 12-0509, 12-0752 and 12-0702, as well as measur-

ing units 12-0433 and 12-0434.

Note: -





#### Target E-series 20 x 20

Part No: 12-0794

**Description:** Rough alignment target for measuring units ES/EM, detectors E4, E5 and E7. Can be mounted to cover laser opening, functioning as dust cover and protection. With reflective centre point. **Note:** Only one target included per Part No., i.e. if you order targets

for a pair of measuring units, you will need two 12-0794.





#### Large target extruder


Part No: 12-0810

**Description:** Transparent target with adjustable magnets for mounting

on tube end. Splits in two, to fit in the transportation case.

Note: A=Min.-Max. diameter 45-200 mm [1.77-7.87"] approximately.

Target diameter 200 mm [7.87"]





### Target cardan


Part No: 12-0139

**Description:** Large target for use when aligning cardan/offset mounted machines. The target clamps onto the front of the D-series measuring

units.

Note: -





## Wireless unit (Version 1)

Part No: 12-0436

**Description:** Unit for wireless communication. No internal battery.

Note: For all E-series units: Part No. 12-0702, 12-0752, 12-0434, 12-

0433, 12-0789, 12-0790 and 12-0824.





## Splitter cable B, for charging

Part No: 12-0725

**Description:** To connect two Easy-Laser® units when charging.

Note: Only for charging, the cable cannot be used to transfer any mea-

surement data. Not for use with 12-0738.





### Splitter cable A, for charging two 12-0738

Part No: 12-0728

**Description:** For charging two wireless units with battery, Part No.

12-0738.

**Note:** Only for charging 12-0738, the cable cannot be used to transfer

any measurement data.





#### DC to USB adapter

Part No: 12-0751

**Description:** Adaptor to be used with cable 12-0989 and 12-0750.

**Note:** Cannot transfer any measurement data.



## DC split cable for charging

Part No: 12-0989

**Description:** Cable for charging the units of system E420, E540 and XT440, XT550, XT660, XT770,

XT980.

Note: This cable cannot transfer

any measurement data.



## "Red cable", 2.0 m [78.7"]

Part No: 12-0074

**Description:** For connecting Easy-Laser® measurement equipment.

With Push-Pull connectors.

Note: -



## "Red cable", extension, 5.0 m [16.4']

Part No: 12-0108

**Description:** For connecting Easy-Laser® measurement equipment. With Push-Pull connectors.

Note: Extension cable.



## "Red cable", extension, 10.0 m [32.8']

Part No: 12-0180

**Description:** For connecting Easy-Laser® measurement equipment. With Push-Pull connectors.

Note: Extension cable.



### **Cable support**

Part No: 12-0321

**Description:** If the cable is accidentially pulled with great force, this support will prevent the connector from damage. It will also minimise the risk of moving the detector out of position.

Note: -



#### **Printer cable**

Part No: 03-0241

**Description:** For connection of the thermal printers 03-0341 and 03-0032 to display unit D279.



PC cable ("null modem")

**Part No:** 03-0333

**Description:** Length 1.8 m [71"]

Note: -



## USB/RS232 adaptor

Part No: 03-0722

**Description:** Adaptor and cable

extension.

**Note:** Requires internet connection

and Windows update.



#### **USB A - USB B cable**

Part No: 03-0822

Description: Cable with USB A to

USB B connectors.

Note: -



## Charger for E-series display unit

Part No: 03-1243 Description: -

**Note:** Wall socket connection cable (charger cable) also needed, choose part depending on country of use.



## Charger for XT-series\*

Part No: 03-1256 Description: -

**Note:** \*Not for system XT550 or XT50 units. Wall socket connection cable also needed, choose part depending on country of use.



## Charger for XT550 and XT50 units

Part No: 12-1281 Description: -

**Note:** Wall socket connection cable (charger cable) also needed, choose part depending on country of use.



## Charger cable, EUR

Part No: 03-0892 Description: -

Note: Charger unit also needed.



#### Charger cable, USA

Part No: 03-0893 Description: -

Note: Charger unit also needed.



### Charger cable, UK

Part No: 03-0894 Description: -

Note: Charger unit also needed.



### Charger cable, AUS

Part No: 03-0895 Description: -

Note: Charger unit also needed.



#### **HDMI** to **HDMI** cable

Part No: 03-0901 Description: Length 3 m.

**Description:** Length 3 m.

Note: -




#### **VGA to VGA cable**

Part No: 03-0902

**Description:** Length 3 m.






#### **Printer for E-series**

Part No: 03-1004

Description: Battery operated thermal printer. With USB cable and 110–220V charger. For connection to all systems with E-series display units. Wall socket connection cable also needed, choose part depending on country of use.

Note: 1 paper roll included. Spare rolls, Part No. 03-0041.





## VGA/HDMI kit, for serial number 94177 and newer


Part No: 12-0840

Description: Makes it possible to show the display unit screen on a TV or projector. Includes cable 03-0901 (HDMI), cable 03-0902 (VGA),

converter and VGA circuit board.

Note: Only for Display unit 12-0418 (E51) with serial number 94177 and higher. The VGA kit (the circuit board) must be ordered at system purchase for factory installation, it cannot be mounted afterwards.





### Carrying case Medium for XT440/XT660/XT770

Part No: 12-0973


**Description:** Carrying case with pre-shaped interior for system XT440,

XT660 and XT770.

Note: The interior has space for display unit XT12. If other display unit is to be placed in the case, please note the shape and dimension of the cutout (picture to the left). W=266 mm [10.4"], H= 195 mm [7.6"].

Note 2: No system name sticker is included if not asked for.





## **Carrying case Large for XT770 + laser transmitter**


Part No: 12-1132

**Description:** With wheels. Pre-shaped interior for system XT770 with XT laser transmitter. Please note: No pre-cut space for BTA or VIB accessories, but the general space under the XT12 might be used.

Note: The interior has space for display unit XT12. If other display unit is to be placed in the case, please note the shape and dimension of the cutout (picture to the left). W=266 mm [10.4"], H= 195 mm [7.6"].

Note 2: No system name sticker is included if not asked for.





### Carrying case for XT laser transmitters

Part No: 12-1290

Description: Carrying case with pre-shaped interior for laser transmit-

ter XT20 or XT22, plus associated accessories.

Note: No system name sticker is included if not asked for.



## Transportation case

Part No: 12-0237 Description: -Note: Uncut foam.



## Carrying case Large for system E540

Part No: 12-1020

**Description:** Carrying case with

interior for system E540.

Note: Pre-cut also for accessories, just remove foam blocks (blocks

removed on picture).





## Transportation case for system E180 and XT190

Part No: 12-0804

**Description:** Carrying case with interior for belt alignment units. **Note:** No system name sticker is included if not asked for.





#### Plastic case for small items

Part No: 03-0792

**Description:** Transportation case with foam interior.

Note: This is the standard case included with Easy-Laser systems.



## **Transportation case**

Part No: 03-0909

**Description:** Rigid case for D22 or D23, or other accessories of your chairs

choice.

**Note:** The foam is cut to order. Specify what the case will be used for. Otherwise it will be delivered with foam uncut.



# Protective case for display unit E51, E52 and

E53

Part No: 01-1379

Description: With strap.

Note: -



## Shoulder strap for display unit E-series

Part No: 12-0495 Description: -Note: -



## Safety strap

Part No: 03-1406

**Description:** Bahco 3875-LY2, for 3 kg [6.6 lbs] weight. For use with laser transmitter D22/D23/XT20/XT22 and Digital Levels E290 and

XT290.

**Note:** Screw 01-1402 for fastening the strap might also be needed.



## Screw for safety strap

Part No: 01-1402

**Description:** For fastening the safety strap Part No. 03-1406

Note: -



### **Hexagon wrench set**

Part No: 03-0967

**Description:** Hexagon wrench set with dimensions 1.27, 1.5, 2, 2.5, 3,

4, 5 and 6 mm. Ball end.

Note: -



## Measuring tape, 3 m [9.8']

Part No: 03-0824

Description: Fits the cases for the

E- and XT-systems.

Note: -



## Measuring tape, 5 m [16.4']

Part No: 03-0842

Description: Fits the cases for the

E-series systems.





#### **Demo unit Shaft**

Part No: 12-0416

**Description:** For shaft alignment training. Can simulate both coupled

and uncoupled shafts. With two shims 1.00 mm included. Dimensions: appr. 400x200x200 mm [ 15.7x7.8x7.8"].

**Note:** To simulate an actual alignment, shims (Type A) of different thicknesses can be used. Measuring units and brackets not included.





#### Demo unit Shaft, steel

Part No: 03-1332

**Description:** For shaft alignment training. Can simulate both coupled and uncoupled shafts. Two units or more can be connected in series to simulate machine train. With two shims 1.00 mm included. Dimensions: WxHxD appr. 640x275x255 mm [25.2x10.8x10.0"]. **Note:** To simulate an actual alignment, shims (Type A) of different thicknesses can be used. Measuring units and brackets not included.





#### **Demo unit Sheave**

Part No: 12-0236

**Description:** Can be placed standing or lying down.

WxHxD: 660x200x100 mm. Weight: 8 kg. **Note:** BTA and targets not included.





#### Stinger for XT280

Part No: 03-1326

**Description:** Accessory probe for the XT280 Vibrometer.

Note: Length 100 mm.





#### **Accelerometer magnet for XT280**

Part No: 03-1327

**Description:** Accessory probe for the XT280 Vibrometer.

Note: -





## XT Laser transmitter upgrade Kits for older XT770 systems (two versions)

Part No: 12-1320 (with XT20) or 12-1321 (with XT22).

**Description:** Includes laser transmitter as indicated above, plus 12-1132 Large Case GEO, 12-1275 Multi bracket, 12-1133 Magnet base with turnable head, 12-0987 Set of rods 120 mm, 03-1256 Charger, 12-0751 DC to USB Adapter, 12-0989 DC split cable, 03-0967 Hexagon weeps 12-0878 Classing cloth 05-0003 Quiek Guide

wrench, 03-0878 Cleaning cloth, 05-0993 Quick Guide.



Top for D23

Part No: 01-0618 + 03-0505

Description: For protection of the

rotating head.

Note: Top and screw are separate

articles.



Target for BTA, 18 mm

Part No: 12-0394

**Description:** Suitable for laser transmitter 12-0309, 12-0390, and

12-1325. **Note:** 1 pc.





Target for BTA, 15 mm

Part No: 12-0213

**Description:** Suitable for Easy-

Laser® D80. **Note:** 1 pc.





**Barrel nut** 

Part No: 01-0045

Description: For the standard

chain. Note: -



Nut

Part No: 01-0042

**Description:** For the standard

chain.
Note: -



Chain, stainless steel

Part No: 12-0386

**Description:** For use with 12-0337. **Note:** Does not fit with standard

Note: Does not not chains.

| D | E |



Part No: 12-0130

**Description:** For mounting on shaft

or coupling.

Note: Just bracket, no chain.



Screw M6x14

Part No: 03-0061 Description: -

Note: -



Rod tightening tool,

4 mm

Part No: 01-0048 Description: -

Note: -



**Locking screw** 

Part No: 01-0039

**Description:** Fits measuring units; 12-0001, 12-0002, 12-0119, 12-0120, 12-0114, 12-0116, 12-0776, 12-0777, 12-0698, 12-0697, 12-0746, 12-0747. Detectors; 12-0005,

12-0201, 12-0255.

Note: -



**Locking screw** 

Part No: 01-1953

**Description:** Fits measuring units; 12-0434, 12-0433. Detectors; 12-0702, 12-0509, 12-0752.

Note: -



**Locking screw** 

Part No: 01-1866

**Description:** Fits measuring units; 12-0943, 12-0944, 12-1028, 12-1029, 12-1026, 12-1027, 12-1045,

12-1046. **Note:** -



## Spare locks for carrying cases

Part No: -

**Description:** Spare locks for different models of Easy-Laser® carrying cases.

**Note:** Ask us for more details on pricing and availability. *Always measure width before ordering!* 



#### Padded case for BTA

Part No: 03-0591

**Description:** Padded case with belt

strap.
Note: -




### **Cleaning cloth**

**Part No:** 03-0878

**Description:** For cleaning of optical surfaces such as laser aperture and

PSD window. **Note:** -




## LCD display protection film for E51/E52/E53

Part No: 03-0972

**Description:** Thin film for scratch protection of the LCD display.

Note: -



## LCD display protection film for XT11

Part No: 01-1945

**Description:** Thin film for scratch protection of the LCD display.

Note: -



#### Thermo paper roll

Part No: 03-0041

**Description:** Paper roll for printer

03-0032 and 03-0341.

Note: -



#### **Batteries**

**Description:** 

A. 3.6 V, Lithium (for BTA Ex),
Part Nr 03-0730
B. 1.5 V, LR6 Alkaline,
Part Nr 03-0247
C. 1.5 V, LR14 Alkaline,
Part Nr 03-0242
D. 9V, 6LR61 Alkaline,
Part Nr 03-0642



## Vapor capsule Zerust VC2-2

Part No: 03-1184

**Description:** Protects metals against rust and corrosion. Estimat-

ed life span 2 years.

Note: For use in system cases. With

adhesive backing.



## Sticker "This machine is aligned with"

Part No: 04-0053

**Description:** To stick on aligned machines. With writable surface for date and operator signature.

Note: 25 stickers.



#### QR code sticker

Part No: 04-0307

**Description:** To stick on machines. Read it from within the XT app for easy access to machine data etc. **Note:** 10 stickers with unique

numbers.



#### Laser target sticker

Part No: 04-0146

**Description:** To be used as reference point when doing geometrical measurements. Red reflectice cross

for higher visibility.


**Note:** Size 35x35 mm [1.38x1.38"]



#### **Screwdriver Torx T8**

Part No: 03-1429 Description: -Note: -





#### Shims case 1, 180 shims


Part No: 12-0258

Description: 180 shims, 10 pcs of each shim included. Weight 3.9 kg. Shims type 1, thickness 0.05, 0.10, 0.20, 0.50, 0.70, 1.00 mm. Shims type 2, thickness 0.05, 0.10, 0.20, 0.50, 0.70, 1.00 mm. Shims type 3, thickness 0.05, 0.10, 0.20, 0.50, 0.70, 1.00 mm.

Shims type 1, A: 55 mm, B: 50 mm, C: 15 mm

Shims type 2, A: 75 mm, B: 70 mm, C: 23 mm Shims type 3, A: 90 mm, B: 80 mm, C: 32 mm





### Shims case 2, 360 shims


Part No: 12-0259

Description: 360 shims, 20 pcs of each shim included. Weight 6.1 kg. Shims type 1, thickness 0.05, 0.10, 0.20, 0.50, 0.70, 1.00 mm. Shims type 2, thickness 0.05, 0.10, 0.20, 0.50, 0.70, 1.00 mm. Shims type 3, thickness 0.05, 0.10, 0.20, 0.50, 0.70, 1.00 mm.

Shims type 1, A: 55 mm, B: 50 mm, C: 15 mm Shims type 2, A: 75 mm, B: 70 mm, C: 23 mm

Shims type 3, A: 90 mm, B: 80 mm, C: 32 mm





### Shims case 3, shims of your choice


Part No: 12-0743

**Description:** For this case you choose number of shims yourself, from type 1, 2, 3, 4. Thickness 0.05–1.00 mm 10pcs/pack, 2.00 mm 5pcs/ pack, 3.00 mm 2pcs/pack. Weight, case without shims 3.2 kg.

Shims type 1, A: 55 mm, B: 50 mm, C: 15 mm Shims type 2, A: 75 mm, B: 70 mm, C: 23 mm Shims type 3, A: 90 mm, B: 80 mm, C: 32 mm

Shims type 4, A: 125 mm, B: 105 mm, C: 44 mm





#### Shims

Part No: See price list.

**Description:** Blister packs. Thickness 0.05–1.00 mm delivered 10pcs/

pack, 2.00 mm 5pcs/pack, and 3.00 mm 2pcs/pack. Type 1, thickness [mm] 0.05, 0.10, 0.20, 0.40, 0.50, 0.70, 1.00, 2.00, 3.00.

Type 2, thickness [mm] 0.05, 0.10, 0.20, 0.40, 0.50, 0.70, 1.00, 2.00, 3.00. Type 3, thickness [mm] 0.05, 0.10, 0.20, 0.40, 0.50, 0.70, 1.00, 2.00, 3.00.

Type 4, thickness [mm] 0.05, 0.10, 0.20, 0.40, 0.50, 0.70, 1.00, 2.00, 3.00. Type 5, thickness [mm] 0.05, 0.10, 0.20, 0.40, 0.50, 0.70, 0.80, 1.00, 2.00, 3.00.

Dimensions [mm]: Type 1, A: 55, B: 50, C: 15. Type 2, A: 75, B: 70, C: 23. Shims type 3, A: 90,

B: 80, C: 32. Type 4, A: 125, B: 105, C: 44. Type 5, A: 200, B: 200, C: 85.





#### Display unit E-series: E52

Part No: 12-0700

Description: Available in different measurement program configurations. Which programs are available depends on in which system the display unit is included. Connectors: USB A, USB B, Easy-Laser® equipment, charger.

Note: Dust and splash guard for connectors removed on upper right



## Tripod head

Part No: 03-1338

**Description:** For use on tripod 12-0269 with e.g. D22 and Angular

prism. Note: -



#### Extruder cardan joint

Part No: 12-1279

**Description:** For the extruder

bracket. Note: -

SPARE PARTS

Easy-Laser® Product overview



**Extruder rod handle** 

Part No: 12-1280

**Description:** For the extruder

bracket.
Note: -



## Velcro clip with pin

Part No: 01-1703

**Description:** For the extruder

bracket. Note: -



# Charger for E-series printer

Part No: 03-1459

**Description:** Replacement charger for printer Seiko DPU-S445.

**Note:** Wall socket connection cable (charger cable) also needed, choose part depending on country of use.



# Mounting screws for XT laser transmitters

Part No: 12-1300

**Description:** Screws for mounting the unit on different brackets. **Note:** Rod tightening tool, Screw for safety strap, 6 pcs M6x16 mm MC6S, 8 pcs M6x20 mm MC6S, 4 pcs Set screw 6x8 mm. In plastic box.



#### Cap

Part No: 13-0004

**Description:** Cap made of 100% cotton. Easy-Laser® embroidery on front. With strap for size adjust-

ment.

Note: Not always in stock. Price

upon request.



#### **USB** memory

Part No: 03-0914

**Description:** 4 GB memory stick USB. Easy-Laser® logo engraved on

one side as on picture. **Note:** Price upon request.



#### Pen

Part No: 13-0006

**Description:** With blue ink. Easy-Laser® logo as pictured. Good

quality pen.

Note: Not always in stock. Price

upon request.



#### **Key holder**

Part No: 01-1095

**Description:** With snap-hook and

string for mobile phone.

Note: Not always in stock. Price

upon request.



#### Logo sticker

Part No: 04-0125 (small), 04-0124

(large

**Description:** Durable sticker with strong adhesive. Same sticker as on the system cases. Available in two sizes: 200x44 mm [7.87x1.73"] and

305x67 mm [12.01x2.64"]. **Note:** Price upon request.



#### **Keychain with spirit level**

**Part No:** 13-0013

**Description:** Keychain with spirit level (plastic block 40x15x15 mm). Easy-Laser® logo as pictured. For give-away purpose/not calibrated. **Note:** Not always in stock. Price

upon request.





#### **Playing cards**

Part No: 13-0007

**Description:** Deck of cards. International symbols. Easy-Laser® logo and web address "www.easylaser.com" printed as on picture.

Note: Not always in stock. Price upon request.





#### Notebook for the technician

Part No: 05-0792

**Description:** Notebook measuring 90x140 mm that fits easily into a pocket in your work clothes, with an insert comprising 38 pages of graph paper and conversion tables on the inside of the cover. Laser

facts on back cover.

Note: Not always in stock. Price upon request.

**EASY-LASER®** 

# TECHNICAL SPECIFICATIONS

#### **READ THIS INFORMATION CAREFULLY:**

#### **Crucial software and electronics updates**

• The unit for wireless communication has been available in two versions. The only model available now is Part No. 12-0436. It supports all units mentioned below without limitations. For a period between November 2022 and September 2023 there was a model with Part No. 12-1336, which had a UKCA (UK Conformity Assessed) marking on the label (see image to the right).

These units for wireless communication are used with detectors and measuring units in the E-series, namely 12-0509 (E5)/12-0702 (E4)/12-0752 (E7)/12-0434 (EM)/12-0433 (ES)/12-0790 (EMH)/ 12-0789 (ESH), 12-0824 (E7H).

**Note!** Wireless unit 12-1336 only works with above mentioned detectors and measuring units which *also* have the UKCA mark, except for the 12-0509 (E5) detector with which 12-1336 is compatible in any case.

- As of November 2022, the XT alignment app no longer supports the XT11 rev 1 Display unit (serial number 129231 or lower).
  - XT alignment app version 8.1 and higher will not be compatible with XT11 rev 1.
- XT measuring units produced in November 2022 or later will not be compatible with the XT11 rev 1 Display unit (serial number 129231 or lower). If you want to purchase new measuring units and are currently using an XT11 rev 1 Display unit, please contact your local distributor for advice before placing an order.
- To be able to connect/pair an XT app with the Easy-Laser PLUS™, XT app version 9.0 or higher is required.







#### Compatibility between D, E and XT

Easy-Laser® measurement systems are extremely versatile in their standard form. By using clever accessories, you can adapt the systems for your own needs, now and in the future as your measurement requirements change. You can also combine parts from one system with another. This is cost-effective! However, there are some differences you need to know:

- The D-series, E-series and XT-series detectors and display units can only be used within
  its own product series. Note! One exception is the sheave alignment detector 12-1054,
  which can be connected to XT12, XT11, E51 and E52.
- The XT20/22 laser transmitters requires use of the XT Alignment app for calibration.
- Brackets for D- and E-series has a rod C–C of 40 mm, XT-series rod C–C is 56 mm. The
  XT offset bracket (12-1008) function as an adaptor for these two measures, but doesn't
  fit all older brackets.

#### Software communication








**Brackets** 





# **Explanation of technical drawings and data**

- On the following pages technical specifications for the most common units can be found. We will not list all products here.
- You should always also read the complete product description to find out about compatibility with other Easy-Laser® products.
- Please note that the measurement range for laser transmitters is the maximum range, and in reality depends on the detector used and the application.
- Operating times also depends on the actual application, therefore it is not specified for all products. See system specifications in each brochure for more detailed information.
   Li-lon battery condition also affect the operating time.
- The drawings show the most important measures. Because of limited space we cannot always place the projections according to Europen drawing projection, but that is otherwise the method used.
- Specifications are quoted to 95% confidence level (coverage factor k=2).



# Specifications for built-in rechargeable batteries (2024-01-31):

Easy-Laser Part No.	MSDS Document	Туре	Nominal Voltage	Nominal Capacity	Energy	Included in
12-1100	Α	Li-lon	3.65 V	11400 mAh	41.61 Wh	12-0418 Display unit E51
				İ		12-0700 Display unit E52
						12-0748 Display unit E53
03-0765	В	Li-lon	3.7 V	660 mAh	2.5 Wh	12-0433 Measuring unit S 20x20
				İ		12-0434 Measuring unit M 20x20
						12-0509 Detector E5
				İ		12-0752 Detector E7
						12-0759 Detector E9
						12-0789 Measuring unit ESH 20x20
						12-0790 Measuring unit EMH 20x20
						12-0799 Detector E3
						12-0824 Detector E7H
						12-0846 Precision level E290
						12-1350 Detector XT9 (2 pcs)
03-1052	С	Li-lon	3.7 V	330 mAh	1.22 Wh	12-0746 Measuring unit ELM 20
						12-0747 Measuring unit ELS 20
						12-0776 Measuring unit ELM 40
						12-0777 Measuring unit ELS 40
						12-1054 Detector BTA XT190
03-0971	D	Li-lon	3.6 V	2600 mAh	9.36 Wh	12-0618 Battery pack wireless
						12-0823 Laser transmitter E30
						12-0845 Detector E2
12-0953	F	Li-lon	3.7 V	2000 mAh	7.4 Wh	12-0943 Measuring unit XT40-M
						12-0944 Measuring unit XT40-S
						12-1028 Measuring unit XT60-M
				İ		12-1029 Measuring unit XT60-S
				İ		12-1045 Measuring unit XT70-M
						12-1046 Measuring unit XT70-S
						12-1241 Precision level XT290
12-1301	F	Li-lon	7.4 V	2000 mAh	2x7.4 Wh	12-1272 Laser transmitter XT20
(2 x 12-0953)						12-1273 Laser transmitter XT22
12-1307	К	Li-lon	3.7 V	1960 mAh	7.25 Wh	12-1026 Measuring unit XT50-M
						12-1027 Measuring unit XT50-S
N/A	Н	Li-lon	3.8 V	4450 mAh	16.91 Wh	12-1196 Ecom Tablet for XT550
						12-1086 Ecom Tablet for XT550
N/A	L	Li-lon	3.85 V	4900 mAh	18.87 Wh	12-1327 Ecom Tablet for XT550
12-1099	1	Li-lon	7.3 V	5700 mAh	41.64 Wh	12-0961 Display unit XT11 (2 pcs)
12-1328	J	Li-lon	3.6 V	18900 mAh	68.04 Wh	12-1291/12-1292 Display unit XT12



## **Information about chargers**

Part No. 03-1243, Charger for E-series

Model: GPE024P-120200-D

AC Input: 100–240 V AC ~0,75 A, 50–60 Hz DC Output: 12.0 V DC 2.0 A, 24.0 W

 $Efficiency: \geq 86.2\% \ (avg.) \ at \ 115 Vac/60 Hz \ or \ 230 Vac/50 Hz \ input \ voltage \ and \ 10\%, \ 25\%, \ 50\%, \ 75\% \ or \ 100\% \ of \ max \ output \ current.$ 

≤0.1 W at no load power consumption, at normal line input.

Part No. 12-1281, Charger for XT50/XT550

Model: GPE024P-120200-D

AC Input: 100–240 V AC ~0,75 A, 50–60 Hz DC Output: 12.0 V DC 2.0 A, 24.0 W

Efficiency: ≥86.2% (avg.) at 115Vac/60Hz or 230Vac/50Hz input voltage and 10%, 25%, 50%, 75% or 100% of max output current.

≤0.1 W at no load power consumption, at normal line input.

Part No. 03-1256, Charger for XT-series

Model: EA10682N-150

AC Input: 100–240 V AC ~2.0 A, 50–60 Hz DC Output: 15.0 V DC 4.0 A, 60.0 W

Efficiency: ≥89.0% (avg.) at 115Vac/60Hz or 230Vac/50Hz input voltage and 25%, 50%, 75% or 100% of max output current.


≥79.0% at 115Vac/60Hz or 230Vac/50Hz input voltage and 10% of max output current.


≤0.15W at no load power consumption, at normal line input.


# Display unit XT12, Part No. 12-1291 / 12-1292

mm [inch]

XT	C€
Type of display/size	8" LCD capacitive multi-touch colour display
Battery type	Heavy duty Li Ion rechargeable
Operating time	Up to16 h continuously
Connections	USB A, USB C, Charger, AV (HDMI)
Communication	Wireless technology, WiFi
Camera, with LED diode	13 Mp autofocus
IR camera (Only in model 12-1292)	FLIR LEPTON® 0-400 °C [32-752 °F]
Help functions	Built-in manual
Environmental protection	IP66/67, designed for outdoor use (pollution degree 4)
Operating temperature	-10–50 °C [14–122 °F]
Storage temperature	-20–50 °C [-4–122 °F]
Relative humidity	10–95%
Loudspeakers	Built-in, rear-facing
Charger	15 V
Housing material	PC/TPE or PC/TPU
Dimensions	WxHxD: 269.0x190.0x49.4 mm [10.59x7.48x1.95"]
Weight	1400 g [49.4 oz]











#### Display unit E51, Part No. 12-0418




# Display unit E52, Part No. 12-0700

		C€
Type of display/size	VGA 5.7" colour screen, backlit LED	
Displayed resolution	0.001 mm / 0.05 thou	
Internal battery	Heavy duty Li Ion chargeable	
Temperature range	-10-50 °C [14-122 °F]	
Connections	USB A, USB B, Easy-Laser® units, Charger	
Communication	BT wireless technology	
Internal memory	>100 000 measurements can be saved	
Help functions	Calculator, Unit converter	
Environmental protection	IP class 65	
Housing material	PC/ABS + TPE	
Dimensions	WxHxD: 250x175x63 mm [9.8x6.9x2.5"]	
Weight	1020 g [2.3 lbs]	

mm [inch]









# E290 Digital Precision Level, Part No. 12-0846


	C€
Displayed resolution	OLED: 0.01 mm/m (0.001°)/App: 0.001 mm/m (0.001°)
Range	± 2 mm/m
Measurement accuracy	Range ±1 mm/m: accuracy within ±0.02 mm/m of displayed value.  Range ±2 mm/m: accuracy within ±0.04 mm/m of displayed value.
Type of display	OLED
Communication	BT wireless technology
Environmental protection	IP Class 67
Operating temperature	-10–50 °C [14–122 °F]
Internal battery	Li lon
Material	Anodized aluminium , ABS plastics
Dimensions	WxHxD: 149x40x35 mm [5.9x1.6x1.4"]
Weight	530 g [18.7oz]

mm [inch]





# Extension kit for Precision Level, Part No. 12-0901




EASY-LASER®


#### XT290 Digital Precision Level, Part No. 12-1241

Displayed resolution 0.1, 0.01, 0.001 mm/m [mils/inch] 0.001, 0.0001, 0.00001 inch/foot 10, 1, 0.1 arcsec 0.01, 0.001, 0.0001 degree Precision level range ±20 mm/m [±20 mils/inch] (pitch) ±0.02 mm/m ±1% [±0.02 mils/inch ±1%] Precision level accuracy 0.001 mm/m [0.001 mils/inch] Precision level sensitivity Inclinometer range ±180° (pitch and roll) ±0.2° (within range ±5°), ±1° (within range ±180°) Inclinometer accuracy TFT 240x240 pixels, RGB colour Type of display Communication BT wireless technology, 20 m [65'] range **Environmental protection** IP Class 66/67 Warning sensors Temperature change and vibration Operating temperature -10-50 °C [14-122 °F] -20-50 °C [-4-122 °F] Storage temperature Operating time Up to 20 h continuously Internal battery Material Corrosion resistant hardened steel, PC/ABS plastics WxHxD: 149x37.3x47.1 mm [5.86"x1.47"1.85"] Dimensions Weight 548 g [19.3 oz]

mm [inch]





# Extension kit for Precision Level, Part No. 12-0901








#### Laser transmitter D22, Part No. 12-0022













#### Laser transmitter D22, Part No. 12-0022

# \*

LASER




#### **Examples of use**

The D22 can be mounted in various ways. Below are just some examples. The important thing is to always tighten rods, screws and magnets firmly. Also be sure the surface where the magnets are attached is clean. If possible use the safety strap.




On tripod (Part No. 12-0269).



With super magnets on tilt table (included) directly on surface.



Feet with points (included), on non magnetic surface.




On sliding table for tripod Part No. 12-0202. For easy alignment to detector.




In a machine spindle. Spindle/magnet base pin Part No. 01-1333.



Vertical mounting on roll. Adapter plate Part No. 12-0874.




Rigid mounting, still easy to height adjust. Use rods of suitable length.




With magnet bases, very rigid mounting.



Rigid mounting, horizontal sweep.



With magnet bases, very rigid mounting.








mm [inch]


#### Laser transmitter D23 Spin, Part No. 12-0168














Weight


#### Laser transmitter D75, Part No. 12-0075


CE **LASER** Type of laser Diode laser 630-680 nm Laser wavelength Laser Safety Class Class 2 AVERAGE POWER < 0.6 mW. PULSE ENERGY < 20 nJ. Output power PULSE DURATION 10-17 µs. Beam diameter 6 mm [1/4"] at aperture Working distance 40-metre [130'] Type of battery 1 x R14 (C) Operating time/battery approx. 15 hours Operating temperature 0-50 °C [32-122 °F] Laser adjustment 2 ways ±2° (± 35 mm/m) Housing material Aluminium Dimensions D75 WxHxD: 60x60x120 mm [2.36x2.36x4.72"]

780 g [27.5 oz]

mm [inch]









mm [inch]

#### Laser transmitter D25 with offset hub, Part No. 12-0706



#### Laser transmitter D25, Part No. 12-0594





CE



LASER









56,8

#### Laser transmitter E30 Long range, Part No. 12-0823


mm [inch]







0

# Laser transmitter E30 Long range, with tilt table, Part No. 12-0858












#### Laser transmitter XT20, Part No. 12-1272



mm [inch]










Easy-Laser® is manufactured by Easy-Laser AB, Alfagatan 6, 431 49 Mölndal, Sweden, +46 31 708 63 00, info@easylaser.com, www.easylaser.com © Easy-Laser AB. We reserve the right to make modifications without prior notification. Easy-Laser® is a registered trademark of Easy-Laser AB.


126,25 [4.970]


#### Laser transmitter XT22, Part No. 12-1273



mm [inch]









#### Mounting possibilities for XT20/XT22 and Multi-bracket





**A/B:** Use the Multi-bracket as adapter for mounting on tripod, vertically or horizontally. C: Use it to mount the transmitter vertically on a magnet base.


D: The three super magnets can be mounted at many different positions, making it possible to also place the transmitter on a small surface, when needed. Here are three examples shown.


E: Use rods on regular magnet bases to position the transmitter at required height. For example when you need to place the transmitter on a lower position than the surface to be measured.

**F**: Mount one or two magnet bases directly on the tilt table.






















# Multi bracket for XT lasertransmitter, Part No. 12-1275



#### mm [inch]









#### Magnet base, Part No. 12-0013









mm [inch]

# Magnet base with turnable head, Part No. 12-0045










#### Magnet base with turnable head, Part No. 12-1133












# Small magnet base with turnable head, Part No. 12-0696









EASY-LASER®

#### 12-1125 DM Bracket








#### Offset bracket, Part No. 12-1008




Blue circles are threaded holes.






# Mounting of 12-0661



**EASY-LASER®** 

# 12-1277 (for XT-series)




Min. diameter 220 mm [8.67"]

**Note:** This bracket can be assembled in many different ways, and used also with magnet base, magnetic bracket, etc. Then the minimum measurable diameters are other than specified here. Please consult your local distributor for more information.



=possible interference point for minimum diameters.

# 12-1282 (for E-series)




Min. diameter 170 mm [6.70"]


**Note:** This bracket can be assembled in many different ways, and used also with magnet base, magnetic bracket, etc. Then the minimum measurable diameters are other than specified here. Please consult your local distributor for more information.



# 12-0455 Slide bracket Small 12-0543 Slide bracket Medium 12-0510 Slide bracket Large




#### When used with XT70-M:






# 12-1368 Axial support on Slide brackets (12-0455 pictured)



With 12-0543: 52.5 mm [2.07"]


With 12-0510: 42.5 mm [1.67"]

# 12-1373 Flange clamping bracket







#### Angular prism, Part No. 12-1352




mm [inch]







#### Detector XT9, Part No. 12-1350



Note: when using the XT9 detector in long tubes with small diameters (<80 mm, 3.15"] wireless communication can be affected. Always consult your distributor before purchase. For normal bore alignment applications there is no problem.

194 g [6.8 oz]

M5 deep 7 (8x)


Distance to PSD


20 [0,787]

Ø30 [1,181]

99,9 [3,933]


#### Detector E9, Part No. 12-0759








#### Miscellaneous







#### Detector E7, Part No. 12-0752





#### Detector E5, Part No. 12-0509



mm [inch]













#### Detector E3, Part No. 12-0799




mm [inch]










## Measuring unit ELM40 / ELS40, Part No. 12-0776 / 12-0777










ELM40/ELS40 ELM20/ELS20






## Measuring unit XT40-M, XT40-S, Part No. 12-0943 / 12-0944

mm [inch]

Measuring unit PSD 30 mm. XT40	LASER 2 CE			
Type of detector	TruePSD 30 mm [1.2"]			
Communication	BT wireless technology			
Battery type	Heavy duty Li Ion chargeable			
Operating time	Up to 24 h continuously			
Resolution	0.001 mm [0.05 mils]			
Measurement accuracy	±5μm ±1%			
Measurement range	Up to 10 m [33 feet]			
Type of laser	Diode laser			
Laser wavelength	630–680 nm			
Laser class	Safety class 2			
Laser output	AVERAGE POWER < 0.6 mW. PULSE ENERGY < 8 nJ.			
	PULSE DURATION 4-6 µs.			
Electronic inclinometer	0.1° resolution			
Environmental protection	IP class 66 and 67			
Operating temperature	-10–50 °C [14–122 °F]			
Storage temperature	-20–50 °C [-4–122 °F]			
Relative humidity	10–95%			
OLED display	128x64 pixels			
Housing material	Anodized aluminium + PC/ABS + TPE			
Dimensions	WxHxD: 76x76.5x39.3 mm [3.0x3.0x1.5"]			
Weight	245 g [8.6 oz]			






mm [inch]


#### Measuring unit XT60-M, XT60-S, Part No. 12-1028 / 12-1029



Measuring unit PSD 20x20 mm. XT60-M: Part No. 12-1028, XT60-S: Part No. 12-1029 1-axis TruePSD 20x20 mm [0.79x0.79"] Type of detector Communication BT wireless technology Battery type Heavy duty Li Ion chargeable Up to 24 h continuously Operating time Resolution 0.001 mm [0.05 mils] Measurement accuracy ±1µm ±1% Measurement range Up to 20 m [66 feet] Diode laser Type of laser Laser wavelength 630-680 nm Laser class Safety class 2 AVERAGE POWER < 0.6 mW. PULSE ENERGY < 20 nJ. Laser output PULSE DURATION 10-17 µs. WAVELENGTH 630-680 nm. Electronic inclinometer 0.1° resolution **Environmental protection** IP class 66 and 67 -10-50 °C [14-122 °F] Operating temperature -20-50 °C [-4-122 °F] Storage temperature 10-95% Relative humidity **OLED** display 128x64 pixels Housing material Anodized aluminium + PC/ABS + TPE Dimensions WxHxD: 76x76.5x45.9 mm [3.0x3.0x1.8"] Weight 272 g [9.6 oz]




#### Measuring unit XT70-M, XT70-S, Part No. 12-1045 / 12-1046



272 g [9.6 oz]

WxHxD: 76x76.5x45.9 mm [3.0x3.0x1.8"]





Dimensions

Weight


mm [inch]

#### Measuring unit XT50-M, XT50-S, Part No. 12-1026 / 12-1027





Measuring unit PSD 20x20 mm. XT50-M: Part No. 12-1026, XT50-S: Part No. 12-1027				
Type of detector	TruePSD 1 axis 20x20 mm [0.79x0.79"]			
Communication	BT wireless technology			
Battery type	Heavy duty Li Ion chargeable			
Operating time	Up to 20 h continuously			
Resolution	0.001 mm [0.05 mils]			
Measurement accuracy	±1µm ±1%			
Measurement range	Up to 20 m [66 feet]			
Type of laser	Diode laser			
Laser wavelength	630–680 nm			
Laser class	Safety class 2			
Laser output	AVERAGE POWER < 0.6 mW. PULSE ENERGY < 20 nJ.			
	PULSE DURATION 10-17 µs. WAVELENGTH 630-680 nm.			
Electronic inclinometer	0.1° resolution			
Environmental protection	IP class 66 and 67			
Operating temperature	-10–50 °C [14–122 °F]			
Storage temperature	-20–50 °C [-4–122 °F]			
Relative humidity	10–95%			
OLED display	128x64 pixels			
Housing material	Anodized aluminium + PC/ABS + TPE			
Dimensions	WxHxD: 76x76.5x50.9 mm [3.0x3.0x2.0"]			
Weight	316 g [11.1 oz]			





#### The EX rating is valid for the XT50 measuring units only,

Part No. 12-1026 and 12-1027. Brackets, fixturing equipment, case, and other accessories are not subject to any EX classification, and must be assessed by the user before use in EX environment. Easy-Laser does not take responsibility for the EX safety of accessories.

EX certificate number: Presafe 17 ATEX 10552X, IECEx PRE 17.0049X

III=Product group. Indicates that the instrument is approved for all areas except mines.

2G=Product category for gas atmosphere. Intrinsically safe equipment for zones 1 and 2 (likely occurrence of explosive gas atmosphere – gases, mists and vapours).
2D=Product category for dust atmosphere. Intrinsically safe equipment for zones 21 and 22 (likely occurrence of explosive dust atmosphere).

ib op is =Type of EX protection (intrinsic safety and safe laser radiation levels).
 IIC=Explosion group for gas atmosphere. Example gases: Hydrogen & Acetylene.
 IIIC=Dust classification. Indicates that the instrument is approved for dust from flammable fibres, non conductive dust and conductive dust.

**T4**=Temperature class for gas atmosphere. The temperature class indicates the maximum temperature of the exposed surface of the product, corresponding to a maximum temperature of 135°C.


**T135°C**= Temperature class for dust atmosphere. Indicates that the maximum temperature of the exposed surface of the product is 135°C.

Gb=Equipment protection level for gas atmosphere. Corresponds to zone 1 and 2.

Db=Equipment protection level for dust atmosphere. Corresponds to zone 21 and 22.

Ta=Ambient temperature. Indicates that the product is safe for use in EX environments in the ambient temperature range as stated only.

Do not charge the units in potentially explosive environment!






#### E- and XT-series wireless detector for BTA, Part No. 12-1054

CE Sheave diameters >60 mm [2.5"] 40 mm to 3 m [1.6" to 10'] (laser LOW power mode) Measurement distance 0.5 m to 10 m [20" to 33'] (laser HIGH power mode) Measurement range Axial offset: ±3 mm [0.12"]. Angular value: ±8° Displayed resolution Offset: 0.1°, Angle: 0.01° Yellow OLED 96x96 pixels Display type Connection BT wireless technology Battery type Li lon rechargeable **Battery operation** Up to 5 hours continuously Material ABS plastics / Anodized aluminium WxHxD: 95x95x36 mm [3.7x3.7x1.4"] Dimensions Weight 190 g [6.7 oz] 17,6 [0,693] 0


mm [inch]




# Laser transmitter BTA, Part No. 12-1325

93,66 [3,688





Reference surfaces height 0.4 [0.016]





Note: New products in rev24 marked with **Bold** letters. Discontinued products marked with *inclined* letters.


19-1039   Locating screws	Part No.	Description	Page	03-1203	DC cable extension 1.5 m	vv
01-0004  Serie for Chain		<del>-</del>	_			
Display   Barrel nut						
10-1046   Rot (pithering) to J. 4 mm.   70						
10-1076   Other broader, D. series   xx						
10-1019		•				
10-10-177						
10-0779   Libe adapters of P3 and D167.   55   03-1338   Fipod head.   7.2					-	
10.0038   Rod, 20 mm						
10-998   Rod. 20 mm					•	
11-105						
11-1165						
1-1333   Machine/Magnet base pin for D22, long						
19-1362   Survisor for DE						
11-1379   Protective case for display unit E418   68   04-0145   Easy-LaserG logo sticker, small   7.4						
101-1402   Screw for safety strap.   68						
11-1703   Veltro Gip with jn jn   73   04-0147   Ber code stricter   xx						
11-1762		- •				
101-1865   Looking screw for XT units						
11-1945						
11-1952   Replaced by 12-1039   xx   06-0001   CD   xx   xx   06-0001   CD   xx   xx   xx   xx   xx   xx   xx						
1-1953   Locking screw						
10-2222   Tube adapters for dual barrels   .55   12-0002   Measuring unt S, D-seres, PSD 10x10mm						
01-2222						
03-0022   Printer 220 V						
03-0041   Thermo paper roll						
03-0042   Protective case for older display units   Xx						
03-0061 Screw M6k14						
0.3-0.241   Printer cable						
03-03434         Printer 110 V.         xx         12-0033         Standard chain.         xx           03-0533         PC cable.         66         12-0034         System 0650 Linebore         xx           03-0591         Padded case for BTA         71         12-0045         Magnet base with turnable head         4.9           03-0592         Protective case for display unit D279.         xx         12-0046         Angular phase with turnable head         4.9           03-0532         Connecting strip (with set screws)         61         12-0059         Rods, 60 mm [2.36"]         54           03-0736         Case for BTA Ex.         xx         12-0060         Rods, 20 mm [9.44"]         .55           03-07792         UsB/RS232 adaptor         66         12-0060         Rods, 20 mm [9.44"]         .55           03-07693         Aluminium beam, 500 mm [19.68"]         61         12-0075         Laser transmitter D75         .43           03-07791         Aluminium beam, 600 mm [23.62"]         61         12-0110         Red cable, extension, 5.0m [16.4"]         .65           03-0771         Aluminium beam, 100 mm [43.31"]         61         12-0110         Red cable, extension, 5.0m [16.4"]         .65           03-07892         Plastic case for small items.         68 <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>						
03-0333         PC cable         66         12-0034         System D650 Linebore         xx           03-0505         Screw for D23 top cover         70         12-0039         Siding bracket         xx           03-0592         Potactive case for BTA         71         12-0046         Magnet base with turnable head         49           03-0592         Protective case for display unit D279         xx         12-0046         Angular prism D46         xx           03-0732         Case for BTA         Xx         12-0059         Rods, 60 mm [2.36"]         54           03-0732         Case for BTA Ex         xx         12-0060         Rods, 20 mm [9.44"]         55           03-0736         Case for BTA Ex         xx         12-0074         Red cable 2.0 m [78.7"]         65           03-0770         Aluminium beam, 500 mm [19.68"]         61         12-0075         Laser transmitter D75         43           03-0771         Aluminium beam, 100 mm [43.31"]         61         12-0110         Tit table         65           03-0772         Plastic case for small items.         68         12-0110         Measuring unit M, D-series, PSD 18x18mm, 2xis.xx           03-0782         Replaced by 01-1953.         70         12-0120         Measuring unit M, D-series, PSD 18x18mm, 2						
0.3-0505   Paddect case for BTA   71   12-0045   Magnet base with turnable head   49   0.3-0592   Protective case for display unit D279   xx   12-0046   Angular prism D46   xx   12-0046   Angular prism D46   xx   13-0059   Protective case for display unit D279   xx   12-0046   Angular prism D46   xx   13-0059   Rods, 60 mm [2.36"]   54   55   53-0736   Case for BTA Ex   xx   12-0060   Rods, 240 mm [9.44"]   55   53-0736   Case for BTA Ex   xx   12-0074   Red cable 2.0 m [78.7"]   6.55   0.3-0769   Aluminium beam, 500 mm [19.68"]   61   12-0075   Laser transmitter D75   4.3						
03-0591   Padded case for BTA.						
03-0592         Protective case for display unit D279.         xx         12-0046         Angular prism D46.         xx           03-0633         Connecting strip (with set screws).         61         12-0059         Rods, 60 mm [2.36°].         .54           03-0722         USB/RS232 adaptor         66         12-0060         Rods, 240 mm [9.44°].         .55           03-0736         Case for B78 Ex.         xx         12-0074         Red cable 2.0 m [78.7°].         .65           03-0779         Aluminium beam, 500 mm [19.68°].         61         12-0075         Red cable, extension, 5.0m [16.4°].         .65           03-0771         Aluminium beam, 1100 mm [43.31°].         61         12-0110         Red cable, extension, 5.0m [16.4°].         .65           03-0791         Protective case for singlatum [100 mm [43.31°].         61         12-0110         Measuring unit M, D-series, PSD 18x18mm, 2 axis.         xx           03-0799         Protective case for display unit D336.         xx         12-0119         Measuring unit M, D-series, PSD 18x18mm, 2 axis.         xx           03-0810         Replaced by 01-1953.         70         12-0120         Measuring unit M, D-series, PSD 18x18mm, xx           03-0822         USB A - USB B cable         66         12-0125         Cardan bracket set D-series.         xx		•				
03-0633 Connecting strip (with set screws) 61 12-0069 Rods, 60 mm [2.36"] 54 03-0720 USB/RS232 adaptor 66 12-0060 Rods, 240 mm [9.44"] 55 03-0736 Case for BTA Ex xx 12-0074 Red cable 2.0 m [78.7"] 665 03-0769 Aluminium beam, 500 mm [19.68"] 61 12-0075 Laser transmitter D75 43 03-0770 Aluminium beam, 500 mm [23.62"] 61 12-0108 Red cable 2.0 m [78.7"] 65 03-0771 Aluminium beam, 1100 mm [43.31"] 61 12-0110 Red cable 2.0 m [78.7"] 65 03-0792 Plastic case for small items 68 12-0116 Measuring unit M, D-series, PSD 18x18mm, 2 axis xx 03-0799 Protective case for display unit D336. xx 12-0119 Measuring unit M, D-series, PSD 18x18mm xx 03-0810 Replaced by 01-1953 70 12-0120 Measuring unit M, D-series, PSD 18x18mm xx 03-0821 Replaced by 03-1243 66 12-0125 Cardan bracket set D-series xx 03-0822 USB A – USB B cable 66 12-0128 Extension chain, set 52 03-0824 Measuring tape, 3 m [9.8"] 68 12-0130 V-bracket 70 03-0842 Measuring tape, 5 m [16.4"] 68 12-0130 V-bracket 70 03-0849 Measuring tape, 5 m [16.4"] 68 12-0130 V-bracket 70 03-0893 Charger cable, UK 66 12-0134 Foot set for linebore arms 57 03-0894 Charger cable, UK 66 12-0134 Foot set for linebore arms 57 03-0893 Charger cable, UK 66 12-0139 Target Cardan 64 03-0991 HDMI to HDMI cable 66 12-0139 Target Cardan 64 03-0991 HDMI to HDMI cable 66 12-0139 Target Cardan 64 03-0991 Graper cable, UK 66 12-0139 Target Cardan 64 03-0991 Tarsportation case 68 12-0146 Laser transmitter D146 xx 03-0907 USB memory 74 12-0158 Red cable strensmitter D23 xx 03-0907 Tarsportation case 68 12-0149 Rod bracket with magnets and probe 54 03-0901 Dd Bracket with use the set of set						
03-0722 USB/RS232 adaptor 66 12-006 Rods, 240 mm [9.44*]						
03-0736         Case for BTA Ex.         xx         12-0074         Red cable 2.0 m [78.7"]         65           03-0769         Aluminium beam, 500 mm [19.68"]         61         12-0075         Laser transmitter D75         43           30-0770         Aluminium beam, 600 mm [23.62"]         61         12-0110         Tilt table         50           03-0771         Aluminium beam, 1100 mm [43.31"]         61         12-0110         Tilt table         59           03-0792         Plastic case for small tlems         68         12-0116         Measuring unit M, D-series, PSD 18x18mm, 2 axisxx           03-0799         Protective case for small tlems         68         12-0119         Measuring unit M, D-series, PSD 18x18mm, xx           03-0810         Replaced by 01-1953         70         12-0120         Measuring unit M, D-series, PSD 18x18mm, xx           03-0821         Replaced by 03-1243         66         12-0125         Cardan bracket set D-series.         xx           03-0822         LUSB A – USB B cable         66         12-0128         Extension chain, set         52           03-0824         Measuring tape, 3 m [9.8"]         68         12-0132         Offset hub for D75         xx           03-0842         Measuring tape, 3 m [16.4"]         <						
03-0769         Aluminium beam, 500 mm [19.68"]         .61         12-0075         Laser transmitter D75         .43           03-0770         Aluminium beam, 600 mm [23.62"]         .61         12-0108         Red cable, extension, 5.0m [16.4"]         .65           03-0771         Aluminium beam, 1100 mm [43.31"]         .61         12-0110         Tilt table         .59           03-0799         Plastic case for small items         .68         12-0119         Measuring unit M, D-series, PSD 18x18mm, 2 axis. xx           03-0810         Replaced by 01-1953         .70         12-0120         Measuring unit M, D-series, PSD 18x18mm. xx           03-0821         Replaced by 01-1953         .70         12-0120         Measuring unit M, D-series, PSD 18x18mm. xx           03-0812         LSB A – USB B cable         .66         12-0128         Extension chain, set         .52           03-0824         Measuring tape, 3 m [9.8]         .68         12-0130         V-bracket.         .70           03-0842         Measuring tape, 5 m [16.4"]         .68         12-0132         Offset hub for D75         .xx           03-0878         Cleaning cloth         .71         12-0133         System D600 Machine         .xx           03-0892         Charger cable, USA         .66         12-0134		•				
03-0770         Aluminium beam, 600 mm [23.62"].         .61         12-0108         Red cable, extension, 5.0m [16.4"].         .65           03-0771         Aluminium beam, 1100 mm [43.31"].         .61         12-0110         Tilt table.         .59           03-0792         Protective case for display unit D336.         .xx         12-0119         Measuring unit M, D-series, PSD 18x18mm.         .xx           03-0810         Replaced by 01-1953.         .70         12-0120         Measuring unit M, D-series, PSD 18x18mm.         .xx           03-0821         Replaced by 03-1243.         .66         12-0125         Cardan bracket set D-series.         .xx           03-0822         USB A – USB B cable         .66         12-0128         Extension chain, set         .52           03-0824         Measuring tape, 3 m [9.8"].         .68         12-0132         Offset hub for D75         .xx           03-0882         Measuring tape, 5 m [16.4"].         .68         12-0132         Offset hub for D75         .xx           03-0893         Charger cable, EUR.         .66         12-0133         System D600 Machine.         .xx           03-0893         Charger cable, UK.         .66         12-0134         Foot set for linebore arms.         .57           03-0895         Charger cable, UK						
03-0771         Aluminium beam, 1100 mm [43.31"].         61         12-0110         Tilt table         59           03-0792         Plastic case for small items         68         12-0116         Measuring unit M, D-series, PSD 18x18mm, 2 axis .xx           03-0799         Protective case for display unit D336.         xx         12-0119         Measuring unit M, D-series, PSD 18x18mm         xx           03-0810         Replaced by 01-1953.         70         12-0120         Measuring unit S, D-series, PSD 18x18mm         xx           03-0821         Replaced by 03-1243.         66         12-0125         Cardan bracket set D-series.         xx           03-0822         USB A – USB B cable         66         12-0128         Extension chain, set         52           03-0824         Measuring tape, 3 m [9.8"]         68         12-0130         V-bracket         52           03-0842         Measuring tape, 5 m [16.4"]         68         12-0132         Offset hub for D75         xx           03-0892         Charger cable, LUS         66         12-0133         System D600 Machine         xx           03-0893         Charger cable, USA         66         12-0134         Foot set for linebore arms         57           03-0894         Charger cable, USA         66         12-013						
03-0792         Plastic case for small items         68         12-0116         Measuring unit M, D-series, PSD 18x18mm, 2 axis .xx           03-0799         Protective case for display unit D336         xx         12-0119         Measuring unit M, D-series, PSD 18x18mm         xx           03-0810         Replaced by 01-1953         70         12-0120         Measuring unit M, D-series, PSD 18x18mm         xx           03-0821         Replaced by 03-1243         66         12-0125         Cardan bracket set D-series         xx           03-0822         USB A – USB B cable         66         12-0128         Extension chain, set         52           03-0824         Measuring tape, 3 m [9.8]         68         12-0130         V-bracket         70           03-0842         Measuring tape, 5 m [16.4]         68         12-0130         Offset hub for D75         xx           03-0842         Measuring tape, 5 m [16.4]         68         12-0130         Offset hub for D75         xx           03-0892         Charger cable, EUR         66         12-0133         System D600 Machine         xx           03-0893         Charger cable, USA         66         12-0137         Sliding bracket with turnable head         54           03-0894         Charger cable, AUS         66         12-						
03-0799         Protective case for display unit D336					THE COOK I	
03-0810         Replaced by 01-1953         70         12-0120         Measuring unit S, D-series, PSD 18x18mm         xx           03-0821         Replaced by 03-1243         66         12-0125         Cardan bracket set D-series         xx           03-0822         USB A – USB B cable         66         12-0128         Extension chain, set         52           03-0824         Measuring tape, 3 m [9.8]         68         12-0130         V-bracket         70           03-0842         Measuring tape, 5 m [16.4]         68         12-0132         Offset hub for D75         xx           03-0878         Cleaning cloth         71         12-0133         System D600 Machine         xx           03-0892         Charger cable, USA         66         12-0134         Foot set for linebore arms         57           03-0893         Charger cable, UK         66         12-0137         Sliding bracket with turnable head         54           03-0894         Charger cable, AUS         66         12-0138         Sliding bracket with magnets and probe         54           03-0895         Charger cable, AUS         66         12-0139         Target Cardan         64           03-0901         HDMI to HDMI cable         66         12-0149         Foot set f					•	
03-0821         Replaced by 03-1243         66         12-0125         Cardan bracket set D-series         xx           03-0822         USB A - USB B cable         66         12-0128         Extension chain, set         52           03-0824         Measuring tape, 3 m [9.8]         68         12-0130         V-bracket         70           03-0824         Measuring tape, 5 m [16.4]         68         12-0132         Offset hub for D75         xx           03-0878         Cleaning cloth         71         12-0133         System D600 Machine         xx           03-0892         Charger cable, USA         66         12-0134         Foot set for linebore arms         57           03-0893         Charger cable, USA         66         12-0138         Sliding bracket with urnable head         54           03-0894         Charger cable, AUS         66         12-0138         Sliding bracket with magnets and probe         54           03-0991         HDMI to HDMI cable         66         12-0143         Foot set for linebore for 100-150mm         57           03-0902         VGA to VGA cable         66         12-0143         Foot set for linebore for 100-150mm         57           03-0909         Transportation case         68         12-0149         Rod bracket for						
03-0822         USB A – USB B cable         66         12-0128         Extension chain, set         52           03-0824         Measuring tape, 3 m [9.8*]         68         12-0130         V-bracket         70           03-0842         Measuring tape, 5 m [16.4*]         68         12-0132         Offset hub for D75         xx           03-0878         Cleaning cloth         71         12-0133         System D600 Machine         xx           03-0892         Charger cable, EUR         66         12-0134         Foot set for linebore arms         57           03-0893         Charger cable, USA         66         12-0137         Sliding bracket with turnable head         54           03-0894         Charger cable, UK         66         12-0138         Sliding bracket with magnets and probe         54           03-0895         Charger cable, AUS         66         12-0138         Sliding bracket with magnets and probe         54           03-0901         HDMI to HDMI cable         66         12-0143         Foot set for linebore for 100-150mm         57           03-0902         VGA to VGA cable         66         12-0143         Foot set for linebore for 100-150mm         57           03-0901         HDMI to HDMI cable         66         12-0149         Rod						
03-0824         Measuring tape, 3 m [9.8]         68         12-0130         V-bracket         70           03-0842         Measuring tape, 5 m [16.4]         68         12-0132         Offset hub for D75         xx           03-0878         Cleaning cloth         71         12-0133         System D600 Machine         xx           03-0892         Charger cable, EUR         66         12-0134         Foot set for linebore arms         57           03-0893         Charger cable, USA         66         12-0137         Sliding bracket with turnable head         54           03-0894         Charger cable, UK         66         12-0138         Sliding bracket with magnets and probe         54           03-0895         Charger cable, AUS         66         12-0139         Target Cardan         64           03-0901         HDMI to HDMI cable         66         12-0143         Foot set for linebore for 100-150mm         57           03-0902         VGA to VGA cable         66         12-0143         Foot set for linebore for 100-150mm         57           03-091         HDMI to HDMI cable         66         12-0143         Foot set for linebore for 100-150mm         57           03-092         VGA to VGA cable         66         12-0149         Rod bracket for laser						
03-0842         Measuring tape, 5 m [16.4*]         68         12-0132         Offset hub for D75         xx           03-0878         Cleaning cloth         71         12-0133         System D600 Machine         xx           03-0892         Charger cable, EUR         66         12-0134         Foot set for linebore arms         57           03-0893         Charger cable, USA         66         12-0137         Sliding bracket with turnable head         54           03-0894         Charger cable, UK         66         12-0138         Sliding bracket with magnets and probe         54           03-0895         Charger cable, AUS         66         12-0139         Target Cardan         64           03-0901         HDMI to HDMI cable         66         12-0143         Foot set for linebore for 100-150mm         57           03-0902         VGA to VGA cable         66         12-0143         Foot set for linebore for 100-150mm         57           03-0914         USB memory         74         12-0149         Rod bracket for laser D75         58           03-0914         USB memory         74         12-0154         Magnets for offset hub arms         58           03-0914         USB gon wrench set         68         12-0154         Magnets for offset hub arms <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>						
03-0878         Cleaning cloth         .71         12-0133         System D600 Machine         xx           03-0892         Charger cable, EUR         .66         12-0134         Foot set for linebore arms         .57           03-0893         Charger cable, USA         .66         12-0137         Sliding bracket with turnable head         .54           03-0894         Charger cable, UK         .66         12-0138         Sliding bracket with magnets and probe         .54           03-0895         Charger cable, AUS         .66         12-0139         Target Cardan         .64           03-0901         HDMI to HDMI cable         .66         12-0143         Foot set for linebore for 100-150mm         .57           03-0902         VGA to VGA cable         .66         12-0143         Foot set for linebore for 100-150mm         .57           03-0909         Transportation case         .66         12-0143         Foot set for linebore for 100-150mm         .57           03-0914         USB memory         .66         12-0144         Laser transmitter D146         .xx           03-092         VGA to VGA cable         .68         12-0149         Rod bracket for laser D75         .58           03-094         USB memory         .74         12-0154         Magnets for	03-0824			12-0130	V-bracket	70
03-0892         Charger cable, EUR         66         12-0134         Foot set for linebore arms         57           03-0893         Charger cable, USA         66         12-0137         Sliding bracket with turnable head         54           03-0894         Charger cable, UK         66         12-0138         Sliding bracket with magnets and probe         54           03-0895         Charger cable, AUS         66         12-0139         Target Cardan         64           03-0901         HDMI to HDMI cable         66         12-0143         Foot set for linebore for 100-150mm         57           03-0902         VGA to VGA cable         66         12-0143         Foot set for linebore for 100-150mm         57           03-0902         VGA to VGA cable         66         12-0143         Foot set for linebore for 100-150mm         57           03-0902         VGA to VGA cable         66         12-0144         Laser transmitter D146         xx           03-0914         USB memory         74         12-0149         Rod bracket for laser D75         58           03-094         Hexagon wrench set         68         12-0149         Magnets for offset hub arms         58           03-097         LCD display protection film         71         12-0168         Laser						
03-0893         Charger cable, USA         66         12-0137         Sliding bracket with turnable head         54           03-0894         Charger cable, UK         66         12-0138         Sliding bracket with magnets and probe         54           03-0895         Charger cable, AUS         66         12-0139         Target Cardan         64           03-0901         HDMI to HDMI cable         66         12-0143         Foot set for linebore for 100-150mm         57           03-0902         VGA to VGA cable         66         12-0146         Laser transmitter D146         xx           03-0909         Transportation case         68         12-0149         Rod bracket for laser D75         58           03-0914         USB memory         74         12-0154         Magnets for offset hub arms         58           03-0967         Hexagon wrench set         68         12-0157         Detector D157         xx           03-0972         LCD display protection film         71         12-0168         Laser transmitter D23         43           03-1004         Printer for E-series         67         12-0169         Rotating detector bracket for rods         49           03-1045         Back pack system get system get and E530         xx         12-0189         Re	03-0878			12-0133	System D600 Machine	XX
03-0894         Charger cable, UK         66         12-0138         Sliding bracket with magnets and probe         54           03-0895         Charger cable, AUS         66         12-0139         Target Cardan         64           03-0901         HDMI to HDMI cable         66         12-0143         Foot set for linebore for 100-150mm         57           03-0902         VGA to VGA cable         66         12-0146         Laser transmitter D146         xx           03-0909         Transportation case         68         12-0149         Rod bracket for laser D75         58           03-0914         USB memory         74         12-0154         Magnets for offset hub arms         58           03-0967         Hexagon wrench set         68         12-0157         Detector D157         xx           03-0972         LCD display protection film         71         12-0168         Laser transmitter D23         43           03-1004         Printer for E-series         67         12-0169         Rotating detector bracket for rods         49           03-1007         Carrying case for system E540 and E530         xx         12-0179         Red cable 1.0m [39.3"]         xx           03-1044         Back pack system, medium         xx         12-0180         Red cable,	03-0892			12-0134		
03-0895         Charger cable, AUS         66         12-0139         Target Cardan         64           03-0901         HDMI to HDMI cable         66         12-0143         Foot set for linebore for 100-150mm         57           03-0902         VGA to VGA cable         66         12-0146         Laser transmitter D146         xx           03-0909         Transportation case         68         12-0149         Rod bracket for laser D75         58           03-0914         USB memory         74         12-0154         Magnets for offset hub arms         58           03-0967         Hexagon wrench set         68         12-0157         Detector D157         xx           03-0972         LCD display protection film         71         12-0168         Laser transmitter D23         43           03-1004         Printer for E-series         67         12-0169         Rotating detector bracket for rods         49           03-1007         Carrying case for system E540 and E530         xx         12-0179         Red cable 1.0m [39.3"]         xx           03-1043         USB cable for streaming values         xx         12-0180         Red cable, extension, 10.0 m [32.8"]         65           03-1044         Back pack system, large         xx         12-0185	03-0893	Charger cable, USA	66	12-0137		
03-0901         HDMI to HDMI cable         66         12-0143         Foot set for linebore for 100–150mm         57           03-0902         VGA to VGA cable         66         12-0146         Laser transmitter D146         xx           03-0909         Transportation case         68         12-0149         Rod bracket for laser D75         58           03-0914         USB memory         74         12-0154         Magnets for offset hub arms         58           03-0967         Hexagon wrench set         68         12-0157         Detector D157         xx           03-0972         LCD display protection film         71         12-0168         Laser transmitter D23         43           03-1004         Printer for E-series         67         12-0169         Rotating detector bracket for rods         49           03-1007         Carrying case for system E540 and E530         xx         12-0179         Red cable 1.0m [39.3"]         xx           03-1043         USB cable for streaming values         xx         12-0180         Red cable, extension, 10.0 m [32.8"]         65           03-1044         Back pack system, medium         xx         12-0185         System D660 Turbine         xx           03-1045         Luggage trolley         xx         12-0188	03-0894	Charger cable, UK	66	12-0138	Sliding bracket with magnets and probe	54
03-0902       VGA to VGA cable.       66       12-0146       Laser transmitter D146.       xx         03-0909       Transportation case       68       12-0149       Rod bracket for laser D75       58         03-0914       USB memory.       74       12-0154       Magnets for offset hub arms       58         03-0967       Hexagon wrench set       68       12-0157       Detector D157       xx         03-0972       LCD display protection film.       71       12-0168       Laser transmitter D23       43         03-1004       Printer for E-series       67       12-0169       Rotating detector bracket for rods       49         03-1007       Carrying case for system E540 and E530       xx       12-0179       Red cable 1.0m [39.3"]       xx         03-1043       USB cable for streaming values       xx       12-0180       Red cable, extension, 10.0 m [32.8']       65         03-1044       Back pack system, medium       xx       12-0185       System D660 Turbine       xx         03-1045       Back pack system, large       xx       12-0187       Bracket for laser D75       59         03-1046       Luggage trolley       xx       12-0188       Side support for D5       xx         03-1059       Carrying case for system E	03-0895	Charger cable, AUS	66	12-0139	Target Cardan	64
03-0909         Transportation case         68         12-0149         Rod bracket for laser D75         58           03-0914         USB memory         74         12-0154         Magnets for offset hub arms         58           03-0967         Hexagon wrench set         68         12-0157         Detector D157         xx           03-0972         LCD display protection film         71         12-0168         Laser transmitter D23         43           03-1004         Printer for E-series         67         12-0169         Rotating detector bracket for rods         49           03-1007         Carrying case for system E540 and E530         xx         12-0179         Red cable 1.0m [39.3"]         xx           03-1043         USB cable for streaming values         xx         12-0180         Red cable, extension, 10.0 m [32.8"]         65           03-1044         Back pack system, medium         xx         12-0185         System D660 Turbine         xx           03-1045         Back pack system, large         xx         12-0187         Bracket for laser D75         59           03-1046         Luggage trolley         xx         12-0188         Side support for D5         xx           03-1059         Carrying case for system E420         xx         12-0189	03-0901	HDMI to HDMI cable	66	12-0143	Foot set for linebore for 100–150mm	57
03-0914       USB memory.       74       12-0154       Magnets for offset hub arms.       58         03-0967       Hexagon wrench set.       68       12-0157       Detector D157.       xx         03-0972       LCD display protection film.       71       12-0168       Laser transmitter D23.       43         03-1004       Printer for E-series.       67       12-0169       Rotating detector bracket for rods.       49         03-1007       Carrying case for system E540 and E530.       xx       12-0179       Red cable 1.0m [39.3"].       xx         03-1043       USB cable for streaming values.       xx       12-0180       Red cable, extension, 10.0 m [32.8'].       65         03-1044       Back pack system, medium.       xx       12-0185       System D660 Turbine.       xx         03-1045       Back pack system, large.       xx       12-0187       Bracket for laser D75.       59         03-1046       Luggage trolley.       xx       12-0188       Side support for D5.       xx         03-1059       Carrying case for system E420.       xx       12-0189       Side support for D75.       xx         03-1184       Vapor capsule.       71       12-0193       System D630 Extruder.       xx	03-0902			12-0146	Laser transmitter D146	XX
03-0967         Hexagon wrench set         68         12-0157         Detector D157         xx           03-0972         LCD display protection film         71         12-0168         Laser transmitter D23         43           03-1004         Printer for E-series         67         12-0169         Rotating detector bracket for rods         49           03-1007         Carrying case for system E540 and E530         xx         12-0179         Red cable 1.0m [39.3"]         xx           03-1043         USB cable for streaming values         xx         12-0180         Red cable, extension, 10.0 m [32.8"]         65           03-1044         Back pack system, medium         xx         12-0185         System D660 Turbine         xx           03-1045         Back pack system, large         xx         12-0187         Bracket for laser D75         59           03-1046         Luggage trolley         xx         12-0188         Side support for D5         xx           03-1059         Carrying case for system E420         xx         12-0189         Side support for D75         xx           03-1184         Vapor capsule         71         12-0193         System D630 Extruder         xx	03-0909	Transportation case	68	12-0149	Rod bracket for laser D75	58
03-0972       LCD display protection film       71       12-0168       Laser transmitter D23       .43         03-1004       Printer for E-series       67       12-0169       Rotating detector bracket for rods       .49         03-1007       Carrying case for system E540 and E530       xx       12-0179       Red cable 1.0m [39.3"]       xx         03-1043       USB cable for streaming values       xx       12-0180       Red cable, extension, 10.0 m [32.8"]       .65         03-1044       Back pack system, medium       xx       12-0185       System D660 Turbine       xx         03-1045       Back pack system, large       xx       12-0187       Bracket for laser D75       59         03-1046       Luggage trolley       xx       12-0188       Side support for D5       xx         03-1059       Carrying case for system E420       xx       12-0189       Side support for D75       xx         03-1184       Vapor capsule       71       12-0193       System D630 Extruder       xx	03-0914	USB memory	74	12-0154	Magnets for offset hub arms	58
03-1004       Printer for E-series       67       12-0169       Rotating detector bracket for rods       49         03-1007       Carrying case for system E540 and E530       xx       12-0179       Red cable 1.0m [39.3"]       xx         03-1043       USB cable for streaming values       xx       12-0180       Red cable, extension, 10.0 m [32.8"]       65         03-1044       Back pack system, medium       xx       12-0185       System D660 Turbine       xx         03-1045       Back pack system, large       xx       12-0187       Bracket for laser D75       59         03-1046       Luggage trolley       xx       12-0188       Side support for D5       xx         03-1059       Carrying case for system E420       xx       12-0189       Side support for D75       xx         03-1184       Vapor capsule       71       12-0193       System D630 Extruder       xx	03-0967	Hexagon wrench set	68	12-0157	Detector D157	XX
03-1004       Printer for E-series       67       12-0169       Rotating detector bracket for rods       49         03-1007       Carrying case for system E540 and E530       xx       12-0179       Red cable 1.0m [39.3"]       xx         03-1043       USB cable for streaming values       xx       12-0180       Red cable, extension, 10.0 m [32.8"]       65         03-1044       Back pack system, medium       xx       12-0185       System D660 Turbine       xx         03-1045       Back pack system, large       xx       12-0187       Bracket for laser D75       59         03-1046       Luggage trolley       xx       12-0188       Side support for D5       xx         03-1059       Carrying case for system E420       xx       12-0189       Side support for D75       xx         03-1184       Vapor capsule       71       12-0193       System D630 Extruder       xx	03-0972	LCD display protection film	71	12-0168	Laser transmitter D23	43
03-1043       USB cable for streaming values       xx       12-0180       Red cable, extension, 10.0 m [32.8']       .65         03-1044       Back pack system, medium       xx       12-0185       System D660 Turbine       xx         03-1045       Back pack system, large       xx       12-0187       Bracket for laser D75       .59         03-1046       Luggage trolley       xx       12-0188       Side support for D5       xx         03-1059       Carrying case for system E420       xx       12-0189       Side support for D75       xx         03-1184       Vapor capsule       71       12-0193       System D630 Extruder       xx	03-1004			12-0169	Rotating detector bracket for rods	49
03-1044       Back pack system, medium       xx       12-0185       System D660 Turbine       xx         03-1045       Back pack system, large       xx       12-0187       Bracket for laser D75       59         03-1046       Luggage trolley       xx       12-0188       Side support for D5       xx         03-1059       Carrying case for system E420       xx       12-0189       Side support for D75       xx         03-1184       Vapor capsule       71       12-0193       System D630 Extruder       xx	03-1007	Carrying case for system E540 and E530	XX	12-0179	Red cable 1.0m [39.3"]	XX
03-1044       Back pack system, medium       xx       12-0185       System D660 Turbine       xx         03-1045       Back pack system, large       xx       12-0187       Bracket for laser D75       59         03-1046       Luggage trolley       xx       12-0188       Side support for D5       xx         03-1059       Carrying case for system E420       xx       12-0189       Side support for D75       xx         03-1184       Vapor capsule       71       12-0193       System D630 Extruder       xx	03-1043					
03-1045         Back pack system, large         xx         12-0187         Bracket for laser D75         59           03-1046         Luggage trolley         xx         12-0188         Side support for D5         xx           03-1059         Carrying case for system E420         xx         12-0189         Side support for D75         xx           03-1184         Vapor capsule         71         12-0193         System D630 Extruder         xx	03-1044			12-0185		
03-1046       Luggage trolley       xx       12-0188       Side support for D5       xx         03-1059       Carrying case for system E420       xx       12-0189       Side support for D75       xx         03-1184       Vapor capsule       71       12-0193       System D630 Extruder       xx	03-1045			12-0187		
03-1059         Carrying case for system E420	03-1046					
03-1184 Vapor capsule	03-1059			12-0189		
	03-1184					
	03-1193	·		12-0199		


12-0201	Detector D6		12-0440	System E710 Shaft	
12-0202	Sliding table for tripod		12-0442	Carrying case for system E710	
12-0203	Parallelity kit		12-0443	Centering target for turbine	
12-0205	AC adaptor for D22 and D75	XX	12-0455	Slide bracket 120mm	. 56
12-0207	System D505 Shaft		12-0456	Transportation case Ex large	. XX
12-0213	Target for BTA, 15 mm	70	12-0476	Cam shaft bracket	
12-0220	System D800 Spin		12-0490	Short ball top probe	.61
12-0224	System D670 Parallelism		12-0494	Red cable 0.16m [6.3"]	. XX
12-0230	Magnet base with linear digital scale	XX	12-0495	Shoulder strap for display unit E418	.68
12-0231	System D525 Shaft	XX	12-0503	Bracket (Set square) for transmitter	.51
12-0235	System D525 B Shaft/Geometry	XX	12-0508	Radial support for magnet base	. 50
12-0236	Demo unit Sheave	69	12-0509	Detector E5	. 45
12-0237	Transportation case cardan	67	12-0510	Slide bracket 300mm	.56
12-0246	Laser transmitter D246		12-0525	System E910 Flange	. 39
12-0248	Detector bracket Long stroke for turbine	XX	12-0526	System E915 Flange Spin	.38
12-0255	Detector 30mm	XX	12-0537	Offset hub with counterlock and tilt function	.57
12-0256	Measuring unit M, D-series, PSD 30x30 mm	XX	12-0538	Detector Extruder 20mm	. XX
12-0258	Shims case, 180 shims	72	12-0543	Slide bracket 200mm	.56
12-0259	Shims case, 360 shims	72	12-0544	Target 100x100m	.63
12-0260	Measuring unit S, D-series, PSD 30x30 mm	XX	12-0552	System D640 Machine tool	. XX
12-0269	Tripod	62	12-0553	Bore bracket adapter plate	.57
12-0279	Display unit D279	XX	12-0568	Mounting pin for D146	
12-0282	Extension arms linebore	58	12-0573	VGA kit	. XX
12-0283	Vibrometer probe D283	XX	12-0579	Magnet base with adapter Ex	. XX
12-0289	Red cable 0.4m [15.7"]	XX	12-0580	Axial extension arms, linebore	. 58
12-0294	AC adaptor for D23		12-0583	Pointing bracket on magnet base	.50
12-0300	System D450 Shaft		12-0585	Charger 12–36 V for car	. XX
12-0303	Sliding bracket with magnets		12-0587	Sun visor for E-series	
12-0308	Detector/display unit for belt alignment		12-0588	Target E-series	
12-0309	Laser transmitter for sheave alignment systems		12-0590	AC adaptor for display unit D279	
12-0310	System D150 BTA		12-0592	Sun visor for Ex units	
12-0314	Detector arms Linebore		12-0594	Laser transmitter D25	
12-0319	Extension chain		12-0597	Splitter box	
12-0320	Rod adapter for D157		12-0603	Handheld detector bracket	
12-0321	Cable support		12-0608	Magnet base with turnable head, for D157	
12-0324	Rods, 120 mm [4.72"] 8 pcs		12-0615	Cardan bracket for E-series	
12-0329	Magnet base bracket for linebore detector		12-0617	Battery pack	
12-0334	Measuring unit M, Ex		12-0618	Battery pack with built-in wireless unit	
12-0335	Measuring unit S, Ex		12-0619	Barcode reader	
12-0336	Display unit D336 Ex		12-0622	Tool kit for tilt table	
12-0337	Shaft bracket with chain, stainless steel		12-0625	Standard chains	
12-0340	System D550 Shaft Extreme™		12-0628	Bracket for non-magnetic flanges, with handheld det	XX
12-0341	Self centering bracket		12-0652	System D652 Linebore	
12-0343	Slide bracket 100mm		12-0656	Vibrometer probe E285	
12-0360	Tool kit for system D550		12-0657	Detector for belt alignment E-series	
12-0362	Cable tester		12-0659	E170 BTA	
12-0363	Extension chain, stainless steel		12-0661	Offset hub with counterlock, for D75	
12-0364	Offset hub with arms		12-0662	System D662 Turbine	
12-0384	Offset hub arms		12-0663	System D663 Turbine	
12-0385	Laser transmitter bracket turbine		12-0664	System D664 Turbine	
12-0386	Chain, stainless steel		12-0676	System E950-A	
12-0390	Laser transmitter for sheave alignment Ex		12-0677	System E950-B	33
12-0394	Target for BTA, 18 mm		12-0695	System E530 Shaft	
12-0400	System D130 BTA Ex		12-0696	Small magnet base with turnable head	
12-0402	Target Ex cardan		12-0697	Measuring unit ELS 30	
12-0402 12-0403	Detector for belt alignment D-series		12-0097	Measuring unit ELM 30	
12-0404	Display unit for sheave/pulley alignment		12-0700	Display unit E52	
12-0404 12-0411	System D160 BTA		12-0700	Detector E4	
12-0411 12-0412			12-0702	Laser transmitter D25 with offset hub	
	Replaced by 12-1012				
12-0413 12-0415	Replaced by 12-1147		12-0707 <i>12-0709</i>	Arm kit with magnets	
	System D90 BTA			Measuring unit holder for Angular prism	
12-0416	Demo unit Shaft		12-0710 12-0711	System E960-A	29 20
12-0417	Height adjustment bracket for detector D6			System E960-B	
12-0418	Display unit E51 (formerly E418)		12-0715	Detector bracket "Long stroke" Turbine	
12-0422	System D480 Shaft		12-0725	Splitter cable for charging	
12-0423	Measuring unit M, D-series, PSD 10x10mm, Incl		12-0727	System E980 Sawmill	
12-0424	Measuring unit S, D-series, PSD 10x10mm, Incl		12-0728	Splitter cable for charging two 12-0738	
12-0433	Measuring unit S, E-series, PSD 20x20mm		12-0735	Red cable with angled connector	
12-0434	Measuring unit M, E-series, PSD 20x20mm		12-0738	BT wireless unit with battery	
12-0436	BT wireless unit		12-0739	BT wireless units kit for E530	
12-0438	Detector bracket Short stroke for turbine		12-0740	Batterypack with wireless unit, Kit	
12-0439	Ball top probe	២ l	12-0742	Tilt table with magnet base	. XX

12-0743	Shim case 3		12-0990	Adjustable magnet for offset hub arms	
12-0745	System E420 Shaft		12-0992	Replaced by 12-1017	51
12-0746	Measuring unit ELM 20		12-1008	Offset bracket	
12-0747	Measuring unit ELS 20		12-1010	Sliding bracket	
<i>12-0748</i> 12-0750	Display unit E53		12-1011	Replaced by 12-1147	
12-0750	Replaced by 12-0989  DC to USB adapter		12-1012 12-1017	Thin chain bracket	
12-0751	Detector E7		12-1017	Angular adapter for detector, 90°	
12-0755	Shim case 4		12-1019	Titanium rods, set of 3	
12-0758	Detector E8, 1-axis PSD		12-1020	Carrying case Large for system E540	
12-0759	Detector E9, 2-axis PSD		12-1025	Carrying case Small for system E540	
12-0761	System E940 Machine tool		12-1026	Measuring unit XT50-M Ex/ATEX	
12-0762	"Red cable", extension 0.5 m [1.6']	XX	12-1027	Measuring unit XT50-S Ex/ATEX	47
12-0767	Rod adapter with built-in target		12-1028	Measuring unit XT60-M	
12-0768	Slide bracket, width 25 mm [0.99"]		12-1029	Measuring unit XT60-S	
12-0771	System E920 Geometric		12-1031	System XT550 Ex/ATEX without Display unit	
12-0772	System E950-C		12-1038	Extension chain stainless steel, set	
12-0775 12-0776	System E540-B		12-1039	Pin for hubV-bracket with stainless steel chain and rods	
12-0776 12-0777	Measuring unit ELM 40 Measuring unit ELS 40		12-1040 <i>12-1043</i>	System E540-A	
12-0787	Spindle bracket for measuring unit		12-1045	Measuring unit XT70-M	
12-0788	System E930 Extruder		12-1046	Measuring unit XT70-S	
12-0789	Measuring unit ESH, HyperPSD™		12-1047	Measuring probe, cylindrical	
12-0790	Measuring unit EMH, HyperPSD™		12-1048	Measuring probe, cylindrical, with magnet	
12-0791	E-series wireless detector for belt alignment	XX	12-1049	Carrying case L for system XT440/XT660/XT770	XX
12-0794	Target E-series 20x20		12-1051	System XT660 with Display unit, case M	
12-0796	System E180 BTA		12-1052	System XT660 with Display unit, case L	
12-0797	System Vestas 4		12-1053	System XT190 BTA	
12-0799	Detector E3		12-1054	Detector unit for system XT190 BTA	
12-0801 12-0804	Measuring probe Ruby diameter 2.5mm		12-1058 <i>12-1059</i>	System XT660 without Display unit, case M	
12-0804	Transportation case for BTA systems  Measuring probe Ruby diameter 5mm		12-1059	System XT660 without Display unit, case L Extension chain, set for E- and XT-series	
12-0803	Large target extruder		12-1064	Laser transmitter D26	
12-0814	Tube bracket		12-1086	ECOM Tab Display unit	
12-0815	Adapter bracket for rod distance 40 mm		12-1090	XT280 Vibrometer, complete set	
12-0823	Laser transmitter E30 Long Range		12-1092	Small magnet base	
12-0824	Detector E7H, HyperPSD™		12-1095	System XT770 with Display unit	
12-0825	System Vestas 3	XX	12-1096	System XT770 without Display unit	14
12-0828	Offset hub with counterlock and tilt function		12-1097	System XT550 Ex/ATEX with Display unit	
12-0840	VGA kit, for serial number 94177 and newer		12-1113	GA1 system+brackets for coupling assembled	
12-0845	Detector E2		12-1114	GA1 brackets for coupling removed	
12-0846	Digital Precision Level E290		12-1118	System Easy-Laser® GA1	
12-0849 12-0850	Roll bracket System E180 without laser transmitter 12-0309		12-1123 12-1124	Extension for set square 12-1087, 295 mm Extension for set square 12-1087, 430 mm	50
12-0853	System E970 Parallelism		12-1124	DM-bracket	50 53
12-0854	System E975 Roll Alignment		12-1027	System XT770, with GEO Kit, with Display unit	
12-0855	Upgrade kit Long stroke		12-1128	System XT770 Shaft + GEO, with XT20	
12-0856	Roll alignment kit		12-1129	Extension for DM-bracket	
12-0857	Digital Precision Level, complete kit	46	12-1130	DM-bracket, complete set	
12-0858	Laser transmitter E30 Long Range, with tilt table		12-1132	Carrying case large for XT770, with XT20/XT22	
12-0864	Tilt table, turnable		12-1133	Magnet base with turnable top	
12-0874	Adapter plate for tilt table to magnet base		12-1136	Angular prism	
12-0885	Large roll kit		12-1142	Vestas 6 wind shaft system	
12-0901 <i>12-0915</i>	Extension kit for large diameters		12-1143 12-1147	Vestas 5 wind shaft system Magnetic bracket	
12-0913 12-0937	Safety strap Height adjustment bracket for detector		12-1147	Cardan bracket set	
12-0943	Measuring unit XT40-M		12-1161	Rods, 75 mm [2.95"], 4 pcs	
12-0944	Measuring unit XT40-S		12-1183	Vestas Installation kit upgrade	
12-0949	Replaced by 12-1118		12-1188	Target (small hole), for Angular prism alignment.	
12-0954	System E950-D Bore alignment		12-1196	ECOM Tab-Ex 02 Display unit	
12-0955	System E720 Shaft/Geo	XX	12-1200	Sliding table for magnet base	63
12-0961	XT11 Display unit for Generation XT		12-1205	Sun visor for XT40	
12-0963	Shaft bracket with chain and rods		12-1209	Rotating detector bracket for rods, E and XT	
12-0966	System XT440 without Display unit		12-1210	Magnet bracket long, with turnable head	
12-0967	System XT440 with Display unit XT11		12-1211	Magnet bracket short, with turnable head	
12-0968 12-0972	IR Camera added to XT11		12-1221 12-1225	Angular prism, kit	
12-0972 12-0973	Carrying case Small for system XT440 Carrying case Medium for system XT440/XT660		12-1225 12-1239	AC adaptor for D23  Carrying case Small for system XT440	
12-0973 12-0985	Camera removed from XT11		12-1239 12-1244	System XT290 Digital precision level	
12-0987	Rods, 120 mm [4.72"], 4 pcs		12-1244	Target (large hole), for Angular prism alignment	
12-0988	Bar bracket		12-1262	Detector bracket for centering on wire position	
12-0989	DC split cable for charging		12-1270	Extruder bracket for fluited barrels	

12-1272	XT20 Laser transmitter	43
12-1273	XT22 Laser transmitter	43
12-1275	Multi-bracket XT laser	59
12-1277	Bracket with rotatable bore probe, XT	60
12-1279	Extruder cardan joint	72
12-1280	Extruder bracket handle	
12-1281	Charger for XT550/XT50	66
12-1282	Bracket with rotatable bore probe, E-series	60
12-1284	Vestas 5.5 - Mechanical bracket Kit	20
12-1290	Case for laser transmitters XT20/XT22	67
<b>1</b> 2-1291	XT12 Display unit	42
12-1292	XT12 Display unit with IR camera	
12-1293	XT20 Kit in case	
12-1294	XT22 Kit in case	43
12-1296	XT980 Sawmill system with Display unit	XX
12-1300	Mounting screws for XT transmitters	73
12-1320	XT Laser transmitter upgrade Kit with XT20	
12-1321	XT Laser transmitter upgrade Kit with XT22	69
12-1325	BTA Laser transmitter with 2 power modes	44
12-1327	ecom TabEx 03	42
12-1332	System D92 BTA	23
12-1334	System XT770 Shaft + GEO, with XT22	
12-1335	System XT980 without display unit	
12-1336	Wireless unit (Version 2, ESP32-MINI-1)	
12-1346	Tube adapters with metal points	
12-1350	Detector XT9	45
12-1351	Rod adapter with built-in target, C–C 56 mm.	
12-1352	Angular prism Mk2	
12-1354	Bore bracket kit, with D75	
12-1355	Bore Upgrade kit, with XT9	
12-1356	System XT950 Bore alignment, with D75	
12-1366	Shaft bracket with chain and rods 75 mm	
12-1362	Removal of camera on XT12	
12-1363	Angular prism Mk2, kit for D22	
13-1368	Side support for slide bracket	
12-1373	Flange clamping bracket	51
12-1376	Angular prism Mk2, kit for XT22	
12-1378	Bracket accessory kit in box	
12-1379	Target for XT22	
12-1389	System XT660 Shaft SG1	
12-1393	System XT660 Shaft WMB	
13-0004	Cap	
13-0006	Pen Playing cards	
13-0007 <i>13-0012</i>	A5 Notes	
13-0012	Keychain with spirit level	
13-0013	neyonanı wini spini ievel	/ 4

Note: New products in rev24 marked with **Bold** letters. Discontinued products marked with *inclined* letters.







Easy-Laser® is manufactured by Easy-Laser AB, Alfagatan 6, SE-431 49 Mölndal, Sweden
Tel +46 31 708 63 00, Fax +46 31 708 63 50, e-mail: info@easylaser.com, www.easylaser.com
© 2024 Easy-Laser AB. We reserve the right to make changes without prior notification.
Easy-Laser® and Easy-Laser PLUS are a registered trademarks of Easy-Laser AB. Android, Google Play, and the Google Play logo are trademarks of Google Inc. Apple, the Apple logo, iPhone, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc. Other trademarks belong to their respective owners.













